



Texecom Integration Module Settings Guide

Last update 29/04/2020

Table of contents

1	Introduction into Texecom Integration Module Settings Guide	3
1.1	Purpose and Structure of the Guide	3
1.2	General information about the Texecom integration module	3
2	Supported hardware and licensing of the Texecom integration module	4
3	Configuring the Texecom integration module	6
3.1	Setting up the Texecom FSA connection	6
3.2	Managing the Texecom configuration	7
3.3	Setting up the Texecom output	7
3.4	Setting up the Texecom area	8
3.5	Setting up the Texecom zone	9
4	Working with the Texecom integration module	10
4.1	General information about working with the Texecom integration module	10
4.2	Managing the Texecom area	10
4.3	Managing the Texecom zone	11
4.4	Managing the Texecom output	12

1 Introduction into Texecom Integration Module Settings Guide

On the page:

- [Purpose and Structure of the Guide](#)
- [General information about the Texecom integration module](#)

1.1 Purpose and Structure of the Guide

The *Texecom* Integration Module Settings Guide is a reference manual designed for *Texecom* Module users.

This Guide presents the following materials:

1. General information about the *Texecom* integration module;
2. Configuration of the *Texecom* integration module in the *ACFA Intellect* software;
3. Working with the *Texecom* integration module.

1.2 General information about the Texecom integration module

The *Texecom* integration module is a part of Security Alarm system built on the basis of the *ACFA Intellect* Software System. It is designed to monitor devices of the *Texecom* module. It is designed to ensure the interaction of Texecom FSA with *ACFA Intellect* software (monitoring and control).

Note.

Detailed information about the *Texecom* FSA is presented in official documentation for the system (Texecom manufacturer).

Before you start configuring the *Texecom* module, do the following:

1. install the *Texecom* hardware on the site (see *Texecom* documentation);
2. connect the *Texecom* hardware to *Intellect* Server (see *Texecom* documentation).

2 Supported hardware and licensing of the Texecom integration module

Manufacturer	Texecom St. Crispin Way, Haslingden, Lancashire, BB4 4PW, UK Tel: +44 (0)1706 234800 https://www.texecom.com
Integration type	Low-level protocol
Equipment connection	Ethernet, RS-232

Supported equipment

Equipment	Function	Features
Premier Elite 12-W\12-W LINE	Control panel	<ul style="list-style-type: none"> • 8 supported wireless zones of the ricochet type • 4 wired zones • 2 areas • 8 user access codes • Up to 2 keyboards supported (Premier Elite 12-W only) • Integrated LCD Keyboard with Prox Reader (Premier Elite 12-W LINE only) • 250 events log • Standards PD6662: 2010, EN50131-3, EN50131-5-3 Grade 2 Class II
Premier Elite 24\24-W	Control panel	<ul style="list-style-type: none"> • 8 zones, can be expanded to 24 • 2 areas • 25 user access codes • 500 events log • Pluggable Digimodems • Interfaces: PSTN / GSM / GPRS / IP (Premier Elite 24 only) • Standards EN50131-1, EN50131-3 Grade 3 Class II (Premier Elite 24 only) • Standards EN50131-1, EN50131-3 Grade 2 Class II (Premier Elite 24-W only) • Supports up to 16 wireless ricochet devices (Premier Elite 24-W only) • 4 integrated wired zones (Premier Elite 24-W only)
Premier Elite 48\48-W	Control panel	<ul style="list-style-type: none"> • 8 zones, can be expanded to 24 (Premier Elite 48 only) • Supports up to 32 wireless ricochet devices (Premier Elite 48-W only) • 4 integrated wired zones (Premier Elite 48-W only) • 4 areas • 50 user access codes • 500 events log • Pluggable Digimodems • Interfaces: PSTN / GSM / GPRS / IP (Premier Elite 48 only) • Standards PD6662: 2017 Grade 3 Class II (Premier Elite 48 only) • Standards PD6662: 2010 Grade 2 Class II (Premier Elite 48-W only)

Equipment	Function	Features
Premier Elite 88	Control panel	<ul style="list-style-type: none"> • 8 zones, can be expanded to 88 • 8 areas • 100 user access codes • 1000 event log • Pluggable Digimodems • Interfaces: PSTN / GSM / GPRS / IP • Standards PD6662: 2017 Grade 3 Class II
Premier Elite 168	Control panel	<ul style="list-style-type: none"> • 8 zones, can be expanded to 168 • 16 areas • 200 user access codes • 2000 events log • Pluggable Digimodems • Interfaces: PSTN / GSM / GPRS / IP • Standards PD6662: 2017 Grade 3 Class II
Premier Elite 640	Control panel	<ul style="list-style-type: none"> • Can be expanded to 640 zones • 64 areas • 1000 user access codes • 5000 events log • Interfaces: PSTN / GSM / GPRS / IP

Protection


Per 1 control panel.

3 Configuring the Texecom integration module


3.1 Setting up the Texecom FSA connection

The *Texecom* FSA connection is configured as follows:


1. Go to the settings panel of the **Texecom panel** object, which is created on the basis of the **Computer** object on the **Hardware** tab of the **System Settings** dialog box.



2. From the **Connection** drop-down list (1), select the panel connection method:
 - **PC-COM** - connection using a Premier Elite PC-Com device. From the **Com port** drop-down list (2), select the connection COM port.



- **COMIP** - connection using the ComIP module. In the **IP Address** and **IP Port** fields (2), enter the IP address and IP port of the connection, respectively.



3. In the **Reply timeout, ms** field (3), enter the time in milliseconds during which a response is expected from the panel.
4. In the **Reply count** field (4), enter the number of attempts to reconnect to the panel in case of communication loss.
5. From the **Panel type** drop-down list (5), select the type of panel to be connected.

6. If the panel is connected using the Premier Elite PC-Com device, then in the **UDL Passcode** field (6), enter the UDL password or the engineer's factory code if the UDL password is not programmed.
7. Click **Apply** (7) to save the changes.

Note


If the connection is successful, the protocol version of the data exchange protocol will be displayed in the **Protocol version** field (8), and the panel type and firmware version on which the panel controller is running will be displayed in the **Panel identification** field (8).

The *Texecom* FSA connection is now configured.

3.2 Managing the Texecom configuration

The *Texecom* configuration is managed as follows:

1. Go to the settings panel of the **Texecom panel** object, which is created on the basis of the **Computer** object on the **Hardware** tab of the **System Settings** dialog box.




2. Click the **Get current panel time** button (1) if it is necessary to get the current panel time.
3. Click the **Get power supply current/voltage values** button (2) if it is necessary to get the current values of the current and voltage of the panel power supply.
4. Click the **Set date and time** button (3) if it is necessary to synchronize the date and time of the panel with the *ACFA-Intellect* Server.
5. Click the **Read configuration** button (4) if it is necessary to read the panel configuration.
6. Click the **Send users** button (5) if it is necessary to record the user data from the *Access Manager* module to the panel.
7. Select the **Dynamic user update** checkbox (6) if it is necessary to automatically record user data from the *Access Manager* module to the panel.
8. Click **Apply** (7) to save the changes.

Texecom configuration management completed.

3.3 Setting up the Texecom output

The *Texecom* output is configured as follows:

1. Go to the settings panel of the **Texecom output** object, which is created on the basis of the **Texecom panel** object.




2. From the **Number** drop-down list (1), select the output number. The output number should match the physical output number of the panel.
3. From the **Location** drop-down list (2), select the output location on the panel.
4. Click **Apply** (3) to save the changes.

The *Texecom* output is now configured.

3.4 Setting up the Texecom area

The *Texecom* area is configured as follows:

1. Go to the settings panel of the **Texecom area** object, which is created on the basis of the **Texecom panel** object.



2. From the **Number** drop-down list (1), select the area number. The area number should match the physical area number of the panel.
3. In the **Text** field (2), enter a brief description of the area that will be displayed on the panel screen.

- Click **Apply (4)** to save the changes.

Note


Parameters in the field **(3)** are displayed upon reading the panel configuration.

The *Texecom* area is now configured.

3.5 Setting up the Texecom zone

The *Texecom* zone is configured as follows:

- Go to the settings panel of the **Texecom zone** object, which is created on the basis of the **Texecom panel** object.



- From the **Number** drop-down list **(1)**, select the zone number. The zone number should match the physical zone number of the panel.
- From the **Zone type** drop-down list **(2)**, select the panel zone type.
- In the **Text** field **(3)**, enter a brief description of the zone that will be displayed on the panel screen.
- Set the checkboxes for the necessary areas **(4)**, which should be included in this zone (see [Setting up the Texecom area](#)).
- Click **Apply (5)** to save the changes.

The *Texecom* zone is now configured.

4 Working with the Texecom integration module

4.1 General information about working with the Texecom integration module

The following interface objects are used to operate the *Texecom* integration module:

1. **Map**
2. **Event log**

Information on how to configure the **Map** and **Event log** interface objects is presented in the [Intellect Software package: Administrator's Guide](#).

Operation of the specified interface objects is described in detail in the [Intellect Software package: Operator's Guide](#).

4.2 Managing the Texecom area



The *Texecom* area is managed in the **Map** interactive window using the **Texecom area** functional menu.




The commands for managing the *Texecom* area are described in the table:

Command	Function
Full arm	Arm the entire area
Reset alarm	Reset the alarm
Disarm	Disarm the area
Part arm 3	Arm the part 3 of the area
Part arm 2	Arm the part 2 of the area
Part arm 1	Arm the part 1 of the area

The *Texecom* area can have the following states:

<p>Texecom area 1.1 [1.1]</p> 	Disarmed
<p>Texecom area 1.1 [1.1]</p> 	Exit

Texecom area 1.1 [1.1] 	Entry
Texecom area 1.1 [1.1] 	Armed
Texecom area 1.1 [1.1] 	Part armed
Texecom area 1.1 [1.1] 	Alarm

4.3 Managing the Texecom zone




The *Texecom* zone is managed in the **Map** interactive window using the **Texecom zone** functional menu.








Texecom zone 1.1 [1.1]
Show last events
Omit zone
Un-omit zone

The commands for managing the *Texecom* zone are described in the table:

Command	Function
Omit zone	Skip the zone (make the zone inactive)
Un-omit zone	Restore zone (make the zone active)

The *Texecom* zone can have the following states:



Texecom zone 1.1 [1.1] 	Secure
Texecom zone 1.1 [1.1] 	Active
Texecom zone 1.1 [1.1] 	Tampered

Texecom zone 1.1 [1.1] 	Short
Texecom zone 1.1 [1.1] 	Zone in fault
Texecom zone 1.1 [1.1] 	Failed test
Texecom zone 1.1 [1.1] 	Alarmed
Texecom zone 1.1 [1.1] 	Manual bypassed
Texecom zone 1.1 [1.1] 	Auto bypassed
Texecom zone 1.1 [1.1] 	Zone masked

4.4 Managing the Texecom output

The *Texecom* output is not controlled in the **Map** interactive window.

The commands for managing the *Texecom* output are described in the table:

Texecom output 1.1 [1.1] 	Active
Texecom output 1.1 [1.1] 	Off