



FSG Settings Guide

ACFA PSIM 1.1

Last update 05/03/2024

Table of Contents

1	List of terms used in FSG Settings Guide	3
2	Introduction into FSG Settings Guide	4
2.1	Purpose of the document	4
2.2	General information about the FSG integration module	4
3	Configuration of the FSG integration module	5
3.1	Configuration procedure for the FSG integration module.....	5
3.2	Activate the FSG integration module	5
3.3	Search for FSG devices.....	5
3.4	Configure rules for FSG channels	7
3.4.1	Configure rule of state transitions of FSG channels	8
3.4.2	Configure rule of change state indicator of FSG channels	9
3.4.3	Assign rule to FSG channel	10
3.5	Switch the FSG device to service mode	11
4	Working with FSG integration module.....	13
4.1	General information on working with FSG integration module	13
4.2	Control analog and integer FSG value	13
4.3	Control FSG binary output.....	14
4.4	Control FSG binary value	15
4.5	Control FSG program	15
4.6	Control FSG device.....	16

1 List of terms used in FSG Settings Guide

FSG program — micro code built-in device by manufacturer.

Auto mode of channel working — mode in which device sets values of channel (opens and closes dumpers) according to its internal program. Channel switches to manual mode when values are set by operator while performing other commands using a card or script, macros, etc.

Service mode of device — special mode of working which allows to set values of some parameters directly by user and makes special commands available which are not available in normal mode.

2 Introduction into FSG Settings Guide

On the page:

- [Purpose of the document](#)
- [General information about the FSG integration module](#)

2.1 Purpose of the document

The *FSG integration module settings guide* provides comprehensive setup and operational guidance for *FSG* module operators.

This Guide presents the following materials:

1. general information about the *FSG* module;
2. *FSG* module settings;
3. working with the *FSG* module.

2.2 General information about the FSG integration module

FSG integration module is designed for connecting IPID Sterownik *FSG* controller. *FSG* allows to perform data exchange, receive events from this controller and perform rules for connected devices.

FSG integration module supports the following functions:

1. open/close of fire dumper;
2. set the angle of fire dumper;
3. receive the current state of connected devices;
4. receive states of fire dumper (open, close, damage);
5. control program which control all fire dumpers in case of damage;
6. show temperatures inside the ventilation tunnels;
7. control smoke exhaust fan.

3 Configuration of the FSG integration module

3.1 Configuration procedure for the FSG integration module


The *FSG* integration module is configured as follows:

1. [Activate the *FSG* integration module.](#)
2. [Search for *FSG* devices.](#)
3. [Configure rules for *FSG* channels.](#)

Also device can be switched to service mode optionally.

3.2 Activate the FSG integration module


To activate the *FSG* integration module create the **FSG** object on the basis of **Computer** object on the **Hardware** tab of the **System settings** dialog box.



3.3 Search for FSG devices


To search *FSG* devices in local network, do the following:

1. Go to the settings panel of the **FSG** object.



2. Click the **Start device search** button.

Search of *FSG* devices will be performed and corresponding objects will be created in the object tree as a result.




Note.
 If there are several network connections on the PC where search for devices is performed it is recommended to disable all connections except that connection which provides connection to local network with *FSG* devices.

It is possible to receive the following information on the settings panel of created object:

- Parameters of connection IP panel of *FSG* device are displayed in the settings panel of the **FSG** object.



- Information about found device is displayed in the settings panel of the **FSG device** object.



- On the settings panel of objects corresponding to channels of the *FSG* devices there is the **Out of service** checkbox which is not available for editing and has informing manner. The checkbox is set if channel of

device is not in use. In such case value from channel is not read.

1.1.12345 FSG analog value 1.1.12345.1

Device id Out of service

FSG device Disable

FSG device 1.1.12345

Info

Device name

4. States of the corresponding object are displayed on the settings panels of the **FSG binary input** object.

1.1.12345 FSG binary input 1.1.12345.1

Device id Out of service

FSG device Disable

FSG device 1.1.12345

Info

Device name

Device type

States


Value below 500 Ohm	1. Active
Value 500-1500 Ohm	1. Active
Value 1500-2500 Ohm	1. Active
Value 2500-3500 Ohm	1. Active
Value above 3500 Ohm	1. Active

3.4 Configure rules for FSG channels

The following types of rules for *FSG* devices are available:

1. State transition in the system while taking element on a value from the specified range.
2. Change of state indicator taking element on a value from the specified range.

Configuring of rules is performed on the settings panel of the **FSG rule** object which is created on the basis of the **FSG** object.



This object is a group of rules in which rules of any types can be included. Only one group of rules can be assigned to each parameter and FSG channel.

3.4.1 Configure rule of state transitions of FSG channels

Rules of state transition allows to generate events in case of value of parameter or channel will come into the specified interval.

To configure this rule it is required to set the following parameters in the **Events** tab on the settings panel of the **FSG rule** object.

1. In the **Min value** column enter the begin of interval.
2. In the **Max value** column enter the end of interval.
3. Set the **Use** checkbox to activate interval.
4. In the **Event text** column enter message which will be received while taking element on a value from the specified range.

State #	Min value	Max value	Event text	Use
01	0	100	Event 1	<input checked="" type="checkbox"/>
02	101	200	Event 2	<input checked="" type="checkbox"/>
03				<input type="checkbox"/>
04				<input type="checkbox"/>
05				<input type="checkbox"/>
06				<input type="checkbox"/>
07				<input type="checkbox"/>
08				<input type="checkbox"/>
09				<input type="checkbox"/>
10				<input type="checkbox"/>

⚠ Attention!

Parameter will be in several states (multistate) if value of parameter or channel comes into several intervals.

3.4.2 Configure rule of change state indicator of FSG channels

Rule of change the indicator state allows to know how to change indicator of object on the map while coming value of parameter in the specified interval.

Configuring of this rule is performed on the **Indicators** tab on the settings panel of the **FSG rule** object. Description of parameters is presented in the following table. It is possible to specify not more than 10 states of indicator.

Parameter	Description of parameter
Rule #	Number of rule
Min value , Max value	Range of element values for rule

Min scale, Max scale	Range of values which indicator will take according to the rule
Use	Activation of interval
Red, Green, Blue	Set color of indicator by RGB model

Click the **Apply** button to save changes.

Indicator and its value are displayed in the map.

The screenshot shows a software interface for configuring FSG rules. At the top, there are input fields for '1.1' and 'FSG rule 1.1', a 'Disable' checkbox, and a dropdown menu showing 'FSG 1'. Below this is a table with columns: Rule #, Min value, Max value, Min scale, Max scale, Red, Green, Blue, and Use. Rule 01 is selected with a checkmark in the 'Use' column. At the bottom, there are 'Apply' and 'Undo' buttons.

Rule #	Min value	Max value	Min scale	Max scale	Red	Green	Blue	Use
01	0	1000	0	100	0	0	255	<input checked="" type="checkbox"/>
02	0	1000	0	100	0	0	255	<input type="checkbox"/>
03	0	1000	0	100	0	0	255	<input type="checkbox"/>
04	0	1000	0	100	0	0	255	<input type="checkbox"/>
05	0	1000	0	100	0	0	255	<input type="checkbox"/>
06	0	1000	0	100	0	0	255	<input type="checkbox"/>
07	0	1000	0	100	0	0	255	<input type="checkbox"/>
08	0	1000	0	100	0	0	255	<input type="checkbox"/>
09	0	1000	0	100	0	0	255	<input type="checkbox"/>
10	0	1000	0	100	0	0	255	<input type="checkbox"/>

3.4.3 Assign rule to FSG channel

The rule can be assigned to channels of the **FSG analog value**, **FSG binary value** and **FSG integer value** types. To assign rule to channels or parameter, do the following:

1. Go to the settings panel of the corresponding channel or parameter.

The screenshot shows a settings panel for an FSG device. At the top left, there is a text input field containing '1.1.12345' and a label 'FSG analog value 1.1.12345.1'. Below this is a section for 'FSG device' with a 'Disable' checkbox and a dropdown menu showing 'FSG device 1.1.12345'. To the right, there is a 'Device id' text input field, an 'Out of service' checkbox, and a 'Rule' dropdown menu. Below these is an 'Info' section with a 'Device name' text input field. At the bottom of the panel are two buttons: 'Apply' and 'Undo'.

2. Select the required rule – **FSG rule** object from the **Rule** drop-down list.
3. Click **Apply** button to save changes.

Assigning rule to channels or parameter is completed.

3.5 Switch the FSG device to service mode

Service mode of device is a special mode of working which allows user to set values of some parameters and make available some commands.

To switch device to service mode, do the following:

1. Go to the settings panel of the **FSG device** object.

The screenshot shows a configuration interface for an FSG device. At the top left, there is a text input field containing '1.1.12345' and a label 'FSG device 1.1.12345'. Below this is a section for 'FSG panel' with a 'Disable' checkbox and a dropdown menu showing 'FSG panel 1.1'. To the right, under 'Settings', there is an 'Instance' field with the value '12345'. The 'Device info' section contains six fields: 'Model name', 'Vendor name', 'Firmware', 'Device name', 'Vendor id' (with the value '260'), and 'Software'. The 'Service mode' section has a 'Password' field and a 'Set service mode' button. At the bottom of the panel are 'Apply' and 'Undo' buttons.

2. In the **Password** field enter password for switching device to service mode.

Note

Password is specified in documentation of device manufacturer.

3. Click the **Set service mode** button.

As a result device will be switched to the service mode.

4 Working with FSG integration module

4.1 General information on working with FSG integration module

Events of *FSG* devices are sent to the *Events protocol*.

Icon and indicator of state and value of parameter or FSG channel can be displayed on the map.


Information about configuring the **Events protocol** and **Map** interface objects is given in details in [Axxon PSIM software package. Administrator's Guide](#) document.

Working with **Events protocol** and **Map** interface objects is given in details in [Axxon PSIM software package. Operator's Guide](#) document.

It is possible to configure reactions on some values of elements with the help of scripts and macros. Working with scripts and macros is given in details in [Axxon PSIM software package. Programming Guide](#) and [Axxon PSIM software package. Programming Guide \(Jscript\)](#) documents.

It is possible to add *FSG* channels to the map in three views (perhaps simultaneously):

1. As sign of state (**1**).
2. As sign of state and indicator (**2**).
3. In the text view (value of element, **3**).



Note


View of object displaying on the map is selected while the object adding (see [Axxon PSIM software package. Administrator's Guide](#)).

Note

Current versions of all specified documents are stored in the [AxxonSoft documentation repository](#).

4.2 Control analog and integer FSG value


Control analog and integer *FSG* value is performed from the function menu of the corresponding object on the map.



The **Automatic mode** is designed for switching channel to the auto mode of working. In this mode, the device sets values by itself (opens and closes dumper) according to its internal program. In manual mode, operator sets values using the **Set new value** command. Values specified in manual mode are more high-priority.

To change values of channel (present value) select the **Set new value** item in the context menu.


In the opened **Set value** window, enter new value and click **Set**.



As a result the new value will be assigned to channel and indicator will take a value and color according to the rule (see [Configure rules for FSG channels](#)).

4.3 Control FSG binary output

Control *FSG* binary output is performed using the functional menu of the **FSG binary output** object.




Available commands in the context menu are described in the table.

Command	Description
Fire test run	Test commands. Close dumper shortly simulating fire and then slowly restore the previous state of dumper.
Free dumper test	
Adaptation	Adaptation.
Automatic mode	Switch channel to auto mode.
Synchronization	Synchronization.

Clear error	Reset of error connected with integrity damage of pressure sensor. <div style="border: 1px solid #ccc; padding: 5px;"> <p>Note. Other types of errors are reset automatically while error correction.</p> </div>
Manual open	Open dumper.
Manual close	Close dumper.

4.4 Control FSG binary value

Control *FSG* binary value is performed using the functional menu of the **FSG binary value** object.




Available commands in the context menu are described in the table.

Command	Description
Set	Set value 1 to channel
Automatic mode	Set auto mode to channel
Reset	Set value 0 to channel

4.5 Control FSG program

Control *FSG* program is performed using the functional menu of the **FSG binary output** object.



Available commands in the context menu are described in the table.

Command	Description
Disable the program	Disable program
Restart	Restart program
Enable the program	Enable program
Halt	Interrupt program
Run	Launch program
Unload	Unload program
Load	Load program
Ready	Switch over program to the ready state

4.6 Control FSG device

FSG integration module allows to control FSG device from the map using function menu of the **FSG device** object. Function menu of this object allows to switch over device to service mode using the Set service mode command (see also [Switch the FSG device to service mode](#)).

