

AxxonSoft

INTELLECT™ Software Package

**Installing and configuring
security system components guide**

Version 1.0.2

Moscow 2013

Contents

CONTENTS.....	2
1 INTRODUCTION.....	7
1.1 Purpose and structure of the guide	7
1.2 Purpose of the INTELLECT™ software package	7
2 INSTALLATION OF SECURITY SYSTEM COMPONENTS.....	8
2.1 Assembly and installation of video surveillance subsystem hardware	8
2.1.1 Installing video capture cards into computer case	8
2.1.2 Installing drivers for video capture cards.....	10
2.1.3 Testing installation of drivers for video capture cards	14
2.1.4 Testing installation of drivers for video capture cards using the Codereader.exe utility	16
2.2 Installing the expansion card for analog video out	17
2.3 Connecting the hardware performance tester.....	19
2.3.1 Connecting the Watchdog hardware performance tester.....	19
2.3.2 Connecting the USB Watchdog hardware performance tester	22
2.4 Connecting DI/DO cards	24
2.4.1 Connecting 4/4 and 16/4 DI/DO cards.....	24
2.4.2 Connecting 4/4 DI/DO (low profile) cards.....	29
2.4.3 Connecting SL USBIO («4x4», «16x8», «24x4») cards.....	30
2.4.4 Connecting MO USBIO 4x4 cards	31
2.4.5 Connecting DI/DO (Stretch)	33
2.4.5.1 Connecting DI/DO cards to Stretch (VRC6004, VRC6008, VRC6416) cards	33
2.4.5.2 Connecting DI/DO cards to Stretch VRC7008L card	34
2.5 Connecting MO USBIO 4x4 external module	35
2.6 Assembly and installation of audio subsystem hardware components	35
2.6.1 Supported sound cards and other audio input devices	36
2.6.2 Options for increasing the number of audio input channels when standard sound cards are used	36
2.6.3 Installing audio input devices.....	36
2.6.4 Installing microphones and loud speakers.....	36
2.7 Connecting PTZ units and control panels.....	37
2.8 Connecting and configuring network devices	37
3 CONFIGURING SECURITY SYSTEM COMPONENTS IN INTELLECT™ SOFTWARE.....	39
3.1 Configuring video capture cards in INTELLECT™ software.....	39
3.1.1 Video subsystem configuration	39
3.1.1.1 Creating and configuring the Video capture card object	39
3.1.1.2 Creating and configuring the Camera object	41

3.1.1.3	Configuring the analog video output	43
3.1.1.4	Configuring Stretch video capture card	45
3.1.1.5	Configuring HikVision video capture card	47
3.1.2	Audio subsystem configuration	47
3.1.2.1	Creating and configuring the Audio card object	47
3.1.2.2	Creating and configuring the Microphone object	49
3.1.3	Initial configuration wizard	51
3.1.4	Configuring the Watchdog hardware performance tester	53
3.2	Configuring IP devices	55
3.2.1	General information about IP devices	55
3.2.2	Configuring video acquisition from IP devices	55
3.2.3	Configuring audio acquisition from IP devices	56
3.2.4	IP Wizard	56
3.2.5	Features of IP device configuration	59
3.2.5.1	Features of Beward IP cameras configuration	59
3.2.5.2	Features of Panasonic IP devices (i-Pro series) configuration	59
3.2.5.3	Features of TrendNet IP device configuration	60
3.2.5.4	Features of Pelco Spectra IV IP device configuration	60
3.2.5.5	Features of AEBELL IP device configuration	60
3.2.5.6	Features of Dynacolor IP device configuration	60
3.2.5.7	Features of Stream Labs IP device configuration	61
3.2.5.8	Features of Cisco IP device configuration	62
3.2.5.9	Features of Mobotix IP device configuration	62
3.3	Configuring DI/DO devices in INTELLECT™ software	63
3.3.1	Creating and configuring the Relay system object	63
3.3.2	Creating and configuring the Sensor system object	64
3.3.3	Configuring DI/DO expansion cards	65
3.3.3.1	Connecting relays	65
3.3.3.2	Connecting sensors via 4/4 DI/DO card	68
3.3.3.3	Connecting sensors via 16/4 DI/DO card	70
3.3.4	Configuring DI/DO expansion cards (low profile)	73
3.3.4.1	Connecting relays	73
3.3.4.2	Connecting sensors	74
3.3.5	Configuring SL USBIO card	76
3.3.5.1	Connecting relays	76
3.3.5.2	Connecting sensors	76
3.3.6	Configuring MO USBIO 4x4 device	76
3.3.6.1	Connecting relays	76
3.3.6.2	Connecting sensors	77
3.3.7	Configuring DI/DO (Stretch) cards	78
3.3.7.1	Connecting relays	78
3.3.7.2	Connecting sensors	79
3.3.8	Configuring sensors and relays connected via IP devices	79
3.4	Telemetry configuration	80
3.4.1	Use of PTZ devices in the digital video surveillance system	80
3.4.2	Priorities of PTZ control	81
3.4.3	PTZ device (telemetry) configuration	83
3.4.3.1	Sequence of PTZ device configuration	83
3.4.3.2	Configuration of Server ports and remote workplace for PTZ connection	83
3.4.3.3	PTZ device configuration in the INTELLECT™ software	84
3.4.4	Telemetry control panel configuration	85

3.4.4.1	Features of BOSCH 12c-KBD-Digital control panel configuration and operation	86
3.4.4.2	Features of Axis T8310 control panel configuration and operation	88
3.4.5	PTZ IP cameras configuration.....	91
3.4.6	Telemetry panel configuration	91
3.4.7	Creation and configuration of the Operator dialog box for telemetry control.....	93
3.4.8	Configuration of the Monitor for telemetry control.....	95
3.4.9	Joystick configuration for telemetry control.....	95
3.4.9.1	Joystick configuration procedure	95
3.4.9.2	Testing joystick performance	96
3.4.9.3	Assignment of the commands to joystick keys for telemetry control.....	97
4	CONCLUSION	100
5	APPENDIX 1. FEATURES OF VIDEO CAPTURE CARD CONFIGURATION.....	101
5.1	Drivers for video capture cards integrated into the INTELLECT™ software	101
5.2	Features of video subsystem configuration	101
5.3	Features of audio subsystem configuration	103
6	APPENDIX 2. IP-DEVICE CONFIGURATION IN THE WINDOWS OS.....	106
6.1	Configuration of IP-devices by the example of Axis camera	106
6.1.1	Search for IP-devices	106
6.1.2	Assigning network addresses to IP devices.....	107
6.1.3	How to call the Web-server home page of IP device.....	111
6.1.4	Configuration of network parameters for IP-devices using the Web-server	113
6.2	Features of configuring Axis IP-device	116
6.3	Features of configuring IP-devices using the Web-interface	116
6.3.1	Features of configuring Panasonic IP-devices (i-Pro series) using the Web-interface.....	116
6.3.2	Features of configuring Samsung IP-devices using the Web-interface.....	117
6.3.3	Features of configuring Mobotix IP-devices using the Web-interface.....	117
6.3.4	Features of configuring Sony IP-devices using the Web-interface	117
7	APPENDIX 3. INSTALLING THE MATRIX LINUX SERVER AND LINUXHUB.....	119
7.1	Introduction	119
7.2	Installing the Linux Server (LinuxHub)	120
7.2.1	Introduction	120
7.2.2	Connecting and running the Linux Server (LinuxHub)	120
7.2.3	Network identification of the Linux Server (LinuxHub).....	121
7.2.4	Configuring the Linux Server for the INTELLECT™ operation.....	124
7.2.5	Configuring the LinuxHub for the INTELLECT™operation	126
7.3	The Linux Server (LinuxHub) Web interface.....	128
7.3.1	Introduction	128
7.3.2	Access to the Web interface	129

7.3.3	Viewing the video	129
7.3.4	Monitoring rays and relays status.....	130
7.3.5	Monitoring the Linux Server (LinuxHub) operability.....	131
7.3.6	Configuring the Linux Server (LinuxHub) network parameters	132
7.3.7	Configuring the Linux Server (LinuxHub) logging.....	133
7.3.8	Configuring parameters of video stream displaying	133
7.3.9	Setting the the Linux Server (LinuxHub) security.....	134
7.3.10	Resetting the Linux Server (LinuxHub) configuration	135
7.3.11	Viewing the Linux Server (LinuxHub) logs	136
7.3.12	Working with memory dumps.....	137
7.4	Updating the Linux Server (LinuxHub) firmware.....	138
8	APPENDIX 4. TECHNICAL SPECIFICATIONS OF VIDEO CAPTURE CARDS	140
9	APPENDIX 5. VIDEO CAPTURE CARDS PINS.....	149
9.1	FS-5 video capture card pins.....	149
9.2	FS-6 video capture card pins.....	149
9.3	FS-16(Exp) video capture card pins.....	150
9.4	FS-8 video capture card pins.....	151
9.5	WS-7 video capture card pins	152
9.6	WS-16 video capture card pins	153
9.7	WS-17 video capture card pins	154
9.8	WS216 video capture card pins	155
9.9	FS15 video capture card pins.....	156
9.10	FX8 video capture card pins	156
9.11	FX4 video capture card pins	157
9.12	FX16 video capture card pins.....	157
9.13	FS115 video capture card pins	158
9.14	FX116 video capture card pins.....	158
9.15	FX416 video capture card pins.....	159
9.16	VRC6004 video capture card pins	159
9.17	VRC6008 video capture card pins	160
9.18	VRC6416 video capture card pins	160

9.19	VRC7008L video capture card pins.....	161
9.20	VRC6404 HD video capture card pins.....	161
9.21	FX HD4 video capture card pins.....	162
9.22	DS-4016HCI(R) video capture card pins	162

10 APPENDIX 6. ELECTRICAL AND TECHNICAL SPECIFICATIONS OF DI/DO CARDS 164

10.1	Electrical and technical specifications of DI/DO cards	164
10.2	Electrical and technical specifications of 4/4 DI/DO (low profile) cards.....	164
10.3	Electrical and technical specifications of MO USBIO 4x4 devices.....	165
10.4	Electrical and technical specifications of SL USBIO («4x4», «16x8», «24x4») card	165

1 INTRODUCTION

1.1 Purpose and structure of the guide

The INTELLECT™ software package. Installing and configuring security system components guide is a reference and information guide that is designed for system administrators, installation and configuration engineers, users with the rights to administrate INTELLECT™-based digital video surveillance and audio surveillance systems.

This guide contains the following information:

1. Installation of security system components.
2. Configuration of security system components in the INTELLECT™ software.
3. Appendixes that contain supplemental information on security system components and features of their configuration.

1.2 Purpose of the INTELLECT™ software package

The INTELLECT™ software is designed for the deployment of industrial scalable, flexible (adjustable) integrated security systems, based on the digital video surveillance and audio monitoring systems.

The INTELLECT™ software possesses the following basic features:

1. Integration of digital video surveillance and audio monitoring systems with the existing data systems, various security equipment, auxiliary software of other developers, using integrated open interfaces of the data exchange.
2. Compatibility with diverse security devices and data systems, in particular, with the fire and security alarm and access control systems, video cameras, data analysis systems and systems for recognition of objects (events) and identification by their images.
3. Single-source registration and processing of events, generation of notifications and controlling response in accordance with the flexibly modified logics.

Ultimately unlimited capabilities for scaling, solution—specific adjustments, re-distribution of resources with changes in the number or quality of tasks in monitoring guarded locations and operating various equipment.

2 Installation of security system components

A security system based on the INTELLECT™ software consists of a hardware kit that fit the functionality of the basic software kit. This section outlines the procedures for configuring basic hardware components of the security system.

2.1 Assembly and installation of video surveillance subsystem hardware

The video surveillance subsystem of the INTELLECT™ software can include the following hardware components:

1. FS/WS/FX/VRC video capture cards and analogue video cameras connected to them. The installation procedure of video capture cards is described in the following chapter.
2. Network video cameras and network video servers connected to the Server via the TCP/IP telecommunication protocols. Installation and configuration procedures for this hardware are outlined in the documentation supplied with the network device.
3. Expansion cards for analogue video signal output that are installed in the video capture cards in order to transmit a video signal to analogue monitors.

2.1.1 Installing video capture cards into computer case

FS-5B, FS-6B, FS-6C, FS-8, WS-7, FS15 and FS115 video capture cards are connected to the PCI interface version 2.1 and higher; FS-16, WS16, WS216, WS-17, FX8, FX4, FX116, VRC6004, VRC6008 and VRC7008L video capture cards are connected to the PCI-express (PCI-E X1) interface, FX416, FX16, FX HD4, VRC6416 and VRC6404HD video capture cards are connected to the PCI-express (PCI-E X4) interface. Installation procedure of video capture cards resembles the installation procedure of standard PCI or PCI-express (sound, network, etc.) cards.

One or more video capture card is included into the kit of digital video surveillance system based on the INTELLECT™ software.

Note. Standard precautions should be observed while installing the video capture cards into a computer case.

To install video capture cards, do the following:

1. Turn the computer off, and disconnect the plug from the mains.
2. Remove the computer case cover (Figure 2.1-1).



Figure 2.1-1 Removal of the case cover

3. Install the video capture card in a free PCI-E X1 slot of the motherboard. Secure the video capture card with a screw (Figure 2.1-2, Figure 2.1-3).

Note. Before encasing video capture cards, make sure that your hands are free from static electricity, which can damage computer cards and video capture cards. To prevent damage to the cards, various special antistatic tools may be used (for instance, an antistatic wristband).



Figure 2.1-2 Example of FS-6C video capture card installation into a PCI slot




Figure 2.1-3 Example of FS-16 video capture card installation into a PCI-E X1 slot

4. Set the computer case cover (Figure 2.1-4).



Figure 2.1-4 Setting the case cover

5. Connect the interface cable with the numbered BNC-pins to the video capture card (Figure 2.1-5).



Figure 2.1-5 Connection of the interface cable

6. Connect video cameras to the interface cable (Figure 2.1-6).



Figure 2.1-6 Connection of video cameras to the interface cable

7. Connect the power cord of the computer case to the mains and turn the computer on.
8. While the operating system is loading, new hardware (video capture card) is found and the monitor displays the **Found New Hardware Wizard** dialog box.

If **INTELLECT™** is to be installed on the given computer, then click **Cancel** in the **Found New Hardware Wizard** dialog box. In this case, the driver of the video capture card is installed automatically during the INTELLECT™ software installation.

If **INTELLECT™** has already been installed and a new video capture card needs to be installed, then install the driver of the video capture card(s) using the **Found New Hardware Wizard** application (see *Installing drivers for video capture cards* section).

Installation of video capture cards is completed.

2.1.2 Installing drivers for video capture cards

When the video capture card is installed in the computer, the monitor displays the **Found New Hardware** message while the operating system is loading (Figure 2.1-7).




Figure 2.1-7 Displaying the Found New Hardware message

As a result the monitor automatically displays the **Found New Hardware Wizard** dialog box (Figure 2.1-8).



Figure 2.1-8 The Found New Hardware Wizard dialog box

*Note. If **INTELLECT™** is to be installed on the given computer, then click **Cancel** in the **Found New Hardware Wizard** dialog box. In this case, the driver of the video capture card is installed automatically during the **INTELLECT™** software installation.*

If **INTELLECT™** has already been installed and a new video capture card needs to be installed or a driver needs to be reinstalled, do the following:

Attention! It is recommended to shutdown antivirus software while installing the driver.

1. Select **No, not this time** and click **Next** in the **Found New Hardware Wizard** dialog box (Figure 2.1-8).
2. Select one of the following actions:
 - Install the software automatically (recommended) – driver search and follow-up installation.
 - Install from a list or specific location (advanced) – enables to select the necessary driver or a folder for manual driver search.

If the **Install the software automatically (recommended)** item is selected, then the description of installation continues with item 6.

3. Select **Install from a list or specific location** and click **Next** (Figure 2.1-9).




Figure 2.1-9 Selection of the Installation from a list of specific location item

4. Set the **Include this location in the search** checkbox in the search options dialog box and click **Browse**. In the **Browse for folders** specify the path to the folder that contains drivers for a video capture card and click **OK** (Figure 2.1-10).

*Note. Drivers for video capture cards are stored in the **Drivers** folder on the installation CD or in the **INTELLECT™** software installation directory. To install drivers for video capture cards select the folder, where the drivers for video capture cards are stored (see *Drivers for video capture cards integrated into the INTELLECT™ software* section).*




Figure 2.1-10 Example of selecting a folder that contains drivers for the hardware

5. After specifying the path to the folder click **Next** to start installation process (Figure 2.1-11).




Figure 2.1-11 Driver installation

6. Ignore Microsoft notification by clicking **Continue anyway** (Figure 2.1-12).




Figure 2.1-12 Installation process continues upon the Windows query

7. To complete installation click **Finish** (Figure 2.1-13).



Figure 2.1-13 Completing installation process for drivers of video capture cards

As a result the message (**Your new hardware is installed and ready to use**) is displayed on the Windows taskbar (Figure 2.1-14).




Figure 2.1-14 Displaying the Found New Hardware message

Installation of a driver for video capture card is completed.

Driver installation procedure for one video capture card is repeated in turn required number of times depending on number of ADCs on the video capture card (e.g., 1 time for FS-5 video capture card, 4 times for FS-6, FS-16, WS-7 video capture cards, 8 times for FS-8 video capture card).

2.1.3 Testing installation of drivers for video capture cards

When installation of the drivers for video capture cards is finished, driver availability in the Windows operating system should be tested with the help of the Device Manager. For this do the following:

1. Open the **System Properties** window by right-clicking on **My computer** icon on the desktop and select **Properties** in the contextual menu (Figure 2.1-15).

*Note. The **System Properties** window can be open by clicking **Start=> Control Panel=> System**.*




Figure 2.1-15 Launching the System Properties dialog box in the My computer context menu

2. In the **System properties** dialog box go to the **Hardware** tab and click **Device Manager** (Figure 2.1-16).




Figure 2.1-16 Running the Device Manager application

3. Go to **Sound, video and game controllers** in the Windows hardware tree and check if the displayed list of devices agrees with the types of installed video capture cards (Figure 2.1-17).




Figure 2.1-17 Example of Windows hardware tree in the Device Manager window if drivers for FS-6 video capture card are installed successfully

2.1.4 Testing installation of drivers for video capture cards using the Codereader.exe utility

To test installation of drivers for video capture cards use the Codereader.exe utility that is designed to read the codes of video capture cards and that is supplied together with the INTELLECT™ software.

Note. Some video capture cards (e.g., FX116 and FX416) are not equipped with a cryptochip. It is impossible to test installation of drivers for these video capture cards.

The utility is launched from the **Tools** folder of the INTELLECT™ software installation package. E.g., C:\Program Files\Intellect\Tools\codereader.exe.

The Codereader.exe utility can also be launched by selecting **Start ⇒ All programs ⇒ INTELLECT ⇒ Utilities ⇒ Code Reader**.

As soon as the utility is launched the monitor displays a window with the codes of video capture cards.

If the drivers for video capture cards are installed correctly, the utility window will display the codes of video capture cards (Figure 2.1-18). If there are several embedded ADCs in the video capture card, then the codes will be repeated as many times as there are ADCs in the video capture card.




Figure 2.1-18 Example of code reading of one FS-6 video capture card

If the Codereader.exe window does not display any code or displays it as “0000” (Figure 2.1-19), it means that:

1. A video capture card is not installed in the computer.
2. A video capture card is defective.
3. A driver for a video capture card is not installed.
4. Installed driver does not correspond to a video capture card in use.
5. Installed driver for a video capture card fails to perform.
6. A video capture card has no cryptochip (FX116/FX416).

Check if the video capture card is installed in the computer and re-install drivers for all ADCs of the video capture card. If after re-installation ADC codes still cannot be read by the Codereader.exe utility, then contact your distributor to check the video capture card.




Figure 2.1-19 Example of incorrect installation of a driver for a video capture card

2.2 Installing the expansion card for analog video out

For viewing video sequences from surveillance cameras with the analog monitors a special option – analog video output - is used. To activate this option with FS-5, FS-6 and FS-16 video capture cards, the supplementary card is used – analog video out card.

The analog video out card is used for direct video signal output from one of the cameras connected to the Server to the analog monitor (with no digitization).

The analog video out card has three connectors compatible with FS-5, FS-6 and FS-16 video capture cards (Figure 2.2-1).




Figure 2.2-1 The analogue video out card (front and back views)

To install the analog video out card, do the following:

1. Make sure that the video capture card power supply is off (either the computer with installed video capture card is off, or the video capture card is not installed).
2. Install the analog video out card on the video capture card, using special connectors on the video capture card (Figure 2.2-2 and Figure 2.2-3).




Figure 2.2-2 Connectors on the analog video out card and corresponding connectors on the video capture card




Figure 2.2-3 Connecting the analog video out card to corresponding connectors on the video capture card

3. Connect the interface cable of the analog monitor to the red BNC connector of the video-in cable connected to the video capture card (Figure 2.2-4).




Figure 2.2-4 Connector of the analog video-out

2.3 Connecting the hardware performance tester

Hardware performance tester is designed to automatically restart the computer whenever any failure in the Windows OS or basic modules of INTELLECT™ software occurs.

Hardware performance testing is done in one of two ways:

1. With the help of Watchdog used on servers with installed video capture cards that support the Watchdog hardware testing (see Appendix 4. Technical specifications of video capture cards).
2. With the help of USB-Watchdog used on servers and clients without installed video capture cards.

2.3.1 Connecting the Watchdog hardware performance tester

In case of the Watchdog hardware performance testing the Reset button is connected to the computer mother board through the video capture card with the help of special Watchdog cable (Figure 2.3-1).

Note. The Watchdog cable is included to the delivery package of video capture card optionally. If several video capture cards are installed on the Server then Watchdog is connected to only one card.




Figure 2.3-1 Cable for connecting the Watchdog hardware performance tester

A special four-pin connector (Figure 2.3-2) or two two-pin connectors (Figure 2.3-3) are installed on the video capture card to connect the Watchdog cable.




Figure 2.3-2 Four-pin connector for connecting the hardware tester of Watchdog pending (by the example FS-5 video capture card)




Figure 2.3-3 Two two-pin connectors for connecting the hardware tester of Watchdog pending (by the example FX-4 video capture card)

To connect the Watchdog hardware performance tester, do the following:

1. Make sure that mother board and video capture card are disconnected.
2. Connect the cable of the Reset button to the two-pin or four-pin connector of video capture card with the help of a pair of 1/0 or 2/0 connections (Figure 2.3-4). Connection of the Reset button cable to FS-5 video capture card is displayed in Figure 2.3-5.

Attention! Cables connection to the video capture card should be done taking into account the positioning of the main wire of four-pin connector (Figure 2.3-4). You can connect the Watchdog cable to two-pin connector of FX video capture cards any way without taking into account the positioning of the main wire.

Note. To specify the positioning of the main wire (earth conditioned «—/—») the multimeter may be used in the resistance test mode. In this case the main wire is determined by 0 resistance value between contacts.




Figure 2.3-4 Appearance and pinout of four-pin connector of video capture card: 0/0-main wire (earth conditioned «-/-»), 1/0 and 2/0- pairs of contacts for cables connections («+/-», «+/-»)



Figure 2.3-5 The Reset button cable connection to the four-pin connector of FS-5 video capture card

3. Connect the Watchdog cable to the vacant two-pin or four-pin connector of video capture card with the help of vacant pair of contacts (1/0 or 2/0) – Figure 2.3-4. The Watchdog cable connection to FS-5 video capture card is exemplified in Figure 2.3-6.




Figure 2.3-6 Connection of the Watchdog cable to four-pin connector of FS-5 video capture card

4. Connect the vacant end of the Watchdog cable to the connector on the mother board for the Reset button cable.

Connecting the Watchdog hardware performance tester is completed.

Note 1. Connecting the Watchdog hardware performance tester is not correct if there is no reboot after pressing the Reset button.

If all the steps of connecting are correct then the Watchdog inoperativeness can be connected with inobservance of polarity while connecting the Watchdog cable to the mother board. Interchange the cables and reconnect the Watchdog cable to the mother board.

Note 2. Program setting of the Watchdog function is necessary to activate the hardware performance tester (see Configuring the Watchdog hardware performance tester section).

2.3.2 Connecting the USB Watchdog hardware performance tester

In case of the USB Watchdog hardware performance testing the Reset button is connected to the computer mother board through the USB Watchdog device with the help of special Watchdog cable. The appearance of the USB Watchdog device is displayed in Figure 2.3-7



Figure 2.3-7 Appearance of the USB Watchdog hardware performance tester

Special four-pin connector is installed on the USB Watchdog device to connect the Watchdog cable (Figure 2.3-7).

To connect the USB Watchdog hardware performance tester, do the following:

1. Make sure that mother board is disconnected.
2. Connect the USB Watchdog device to USB connector on the mother board (Figure 2.3-8).




Figure 2.3-8 Connecting the USB Watchdog device to the mother board

3. Connect the Reset button cable to the four –pin connector of the USB Watchdog device with the help of a pair of contacts (1/0 or 2/0) (Figure 2.3-9). Connecting the Reset button cable to the USB Watchdog device is exemplified in Figure 2.3-10.

Attention! Cables should be connected taking into account the layout of the main wire of four-pin connector on the USB Watchdog device (Figure 2.3-9).

Note. To specify the positioning of the main wire (earth conditioned «-/-») the multimeter may be used in the resistance test mode. In this case the main wire is determined by 0 resistance value between contacts.




Figure 2.3-9 Appearance and pinout of four-pin connector of the USB Watchdog: 0/0-main wire (earth conditioned «-/-»), 1/0 and 2/0- pairs of contacts for cables connections («+/-», «+/-»)




Figure 2.3-10 Connection of the cables to four-pin connector of the USB Watchdog device

4. Connect the Watchdog cable to four-pin connector of the USB Watchdog device with the help of vacant pair of contacts (1/0, or 2/0) – Figure 2.3-10.
5. Connect the vacant end of the Watchdog cable to the connector on the mother board for the Reset button cable.

Connecting the USB Watchdog hardware performance tester is completed.

Attention! The USB Watchdog hardware performance tester is activated with the help of reboot system (see INTELLECT™ software . Administrator's Guide).

Note 1. Connecting the USB Watchdog hardware performance tester is not correct if there is no reboot after pressing the Reset button.

If all the steps of connecting are correct then the USB Watchdog inoperativeness can be connected with inobservance of polarity while connecting the Watchdog cable to the mother board. Interchange the cables and reconnect the Watchdog cable to the mother board.

Note 2. USB connector on the USB Watchdog may be used for connecting any external USB devices to the computer. Connected USB devices do not influence on the USB Watchdog hardware performance tester.

2.4 Connecting DI/DO cards

DI/DO card is connected to the video capture card and is used for connecting guard loops (DI) and DO to the control system - the server with installed INTELLECT™ software. General information about DI and DO is given in Table 2.4-1:

Table 2.4-1 General information on DI/DO

Type of device	Description	Functions	Operation conditions	Changes in operation condition	Examples of devices
DI (digital in)	Interface line of external sensor and control system	Informs the control system about changes in sensor status	Closed – logical one Open – logical zero	Opening/closing – when sensor detects the alarm	Annunciators (smoke, heat, window, etc.), button
DO (digital out)	Interface line of control system and executive device	Changes operation condition of executive device on command from the control system	Closed – logical one Open – logical zero	Opening/closing – on command from the control system.	Annunciators (light, sound, etc.), mechanized gates

Electrical and technical specifications of DI/DO cards are given in *Appendix 6. Electrical and technical specifications of DI/DO cards* section.

2.4.1 Connecting 4/4 and 16/4 DI/DO cards

Multichannel digital-analogue converting 4/4 and 16/4 DI/DO cards may be installed on the server depending on security system requirements (Figure 2.4-1).




Figure 2.4-1 The 4/4 and 16/4 DI/DO cards

The 4/4 DI/DO cards enable to process the signals from 4 digital in, and the 16/4 cards - from 16 digital in. Simultaneously with the DI signals processing, these cards perform digital-analogue converting and delivering up to 4 control signals to executive devices (DO).

The 4/4 and 16/4 DI/DO cards have power (24V) and grounding leads and are installed on the FS-5, FS-6, FS-16, FS-8 video capture cards.

To connect DI/DO cards, do the following:

1. Make sure that power supply of the video capture card is off.
2. Install the DI/DO card on the video capture card with the help of special connectors. (Figure 2.4-2, Figure 2.4-3, Figure 2.4-4).




Figure 2.4-2 Connector on the DI/DO card for connecting to the video capture card (is exemplified in 4/4 and 16/4 DI/DO cards)




Figure 2.4-3 Connector on the video capture card for connecting the DI/DO card (is exemplified in FS6 video capture card)




Figure 2.4-4 Installation of the DI/DO card on the video capture card (is exemplified in 4/4 and 16/4 DI/DO cards and FS6 video capture card)

3. Fix the DI/DO card on the video capture card with the help of screws included in the distribution kit of the DI/DO card.
4. Connect the interface cable included in the distribution kit of the DI/DO card, to the DI/DO card with the help of special connector (Figure 2.4-5, Figure 2.4-6, Figure 2.4-7, Figure 2.4-8)

Note. For interface cable connection the 4/4 DI/DO card has J6 connector, 16/4 DI/DO card has J6 and J7 connectors (Figure 2.4-6, Figure 2.4-7).

Attention! The first wire of the interface cable (marked red) should match the first pin of corresponding connector of the DI/DO card (Figure 2.4-6, Figure 2.4-7, Figure 2.4-8).




Figure 2.4-5 DI/DO interface cable




Figure 2.4-6 Connectors on the DI/DO card for the interface cable connection (is exemplified in 4/4 and 16/4 DI/DO cards)




Figure 2.4-7 J6 and J7 connector pinout



Figure 2.4-8 Example of the interface cable connection to the 4/4 DI/DO card

5. To connect DI/DO, unsolder the connector included in the distribution kit of the DI/DO card. Unsoldering is made in accordance with the external connector pinout of the DI/DO interface cable, taking into account power circuit of connected devices (Figure 2.4-9, Figure 2.4-10, Figure 2.4-11, Figure 2.4-12).




Figure 2.4-9 External connector pinout of the DI/DO interface cable




Figure 2.4-10 DI types and features of their connection




Figure 2.4-11 Example of power DO connection (with external power supply)




Figure 2.4-12 Example of low-power DO (power supply on the card)

6. Fix the unsoldered connector in the casing included in the distribution kit of the DI/DO card.
7. Connect ready-for-use connector to external connector of the DI/DO interface cable in order to connect DI/DO to the Server.

The DI/DO cards connection is completed.

2.4.2 Connecting 4/4 DI/DO (low profile) cards

Building security video subsystem with the use of FS115/FX4/FX8/FX16 video capture cards one can install 4/4 DI/DO cards (low profile) in order to connect external sensors (DI) and executive devices (DO) to the Server.

To connect the 4/4 DI/DO (low profile) card, do the following:

1. Make sure that the computer is turned off.
2. Connect the 4/4 DI/DO (low profile) card to the video capture card with the help of loop included in the distribution kit. The loop is connected to J2 and J3 connectors (Figure 2.4-13 and *Appendix 5. Video capture cards pins* section).




Figure 2.4-13 Diagram of the 4/4 DI/DO (low profile) card connection to FS115 card

3. Connect the cable of computer PSU (disk drive power supply) to J4 connector (Figure 2.4-13) of the 4/4 DI/DO (low profile) card.
4. Install the card into vacant computer slot and fix it in the casing with the help of screw.
5. To connect DI/DO, unsolder the connector. Unsoldering is made in accordance with the external connector pinout of the 4/4 DI/DO (low profile) card (Figure 2.4-14).




Figure 2.4-14 External connector pinout of the 4/4 DI/DO (low profile) card

6. Connect ready-for-use connector to external connector of the 4/4 DI/DO (low profile) card in order to connect DI/DO to the Server.

The 4/4 DI/DO (low profile) card connection is completed.

2.4.3 Connecting SL USBIO («4x4», «16x8», «24x4») cards

The SL USBIO card is an interface of external sensors (DI) and external executive devices (DO) as a part of video surveillance and fire and security alarm systems.






Figure 2.4-15 Connector layout of the SL USBIO card

To connect the SL USBIO card to the Server, do the following:

1. For each DI (sensor) setup a power supply by shifting the J1 jumper in corresponding contact set (Figure 2.4-15 and Figure 2.4-16).



Sensor functioning from power supply in device



Sensor functioning from external power supply
(polarity of external voltage is not important)

Figure 2.4-16 Setting sensor power supply

2. Switch the computer power supply off. Remove the system cover.
3. Install the SL USBIO card into vacant motherboard slot and fix it in the casing.
4. Connect the loop (included in the distribution kit) to the J2 connector and to vacant USB connector on computer motherboard (Figure 2.4-15).
5. To activate the hardware tester of pending, connect wires to the J3 connector (Figure 2.4-15) (see *Connecting the hardware performance tester* section).

Note. The SL USBIO 4x4 card does not have the J3 connector.

6. If it is necessary to connect via the USB port (USB cable of A-A type) or connect the USB device then use the J4 port (Figure 2.4-15).

Note. The SL USBIO 4x4 card does not have J4 port.

7. To connect DI/DO, unsolder the connector and fix it in the casing included in the distribution kit. Unsoldering is made in accordance with the external connector layout (see *Appendix 6. Electrical and technical specifications of DI/DO cards*).
8. Connect the ready-for-use connector to external connector of the SL USBIO card.

The SL USBIO card connection is completed.

2.4.4 Connecting MO USBIO 4x4 cards

The MO USBIO 4x4 card is an interface of external sensors (DI) and external executive devices (DO) as a part of video surveillance and fire and security alarm systems (Figure 2.4-17).




Figure 2.4-17 Connector layout of the MO USBIO 4x4 card

Device is controlled via the USB interface. Electrical and technical specifications of the card are given in *Electrical and technical specifications of MO USBIO 4x4* section.

To connect the MO USBIO 4x4 card to the Server, do the following:

1. Switch the computer power supply off. Remove the system cover.
2. Install the MO USBIO 4x4 card into vacant motherboard slot and fix it in the casing.
3. Connect the loop (included in the distribution kit) to the J1 pin and to vacant USB connector on computer motherboard (Figure 2.4-17).
4. To connect DI/DO, unsolder the connector included in the distribution kit. Unsoldering is made in accordance with the external connector pinout of the MO USBIO 4x4 card (Figure 2.4-18).




Figure 2.4-18 External connector pinout of the MO USBIO 4x4 card

5. Fix the unsoldered connector in the casing included in the distribution kit.
6. Connect ready-for-use connector to external connector of the card in order to connect DI/DO to the Server.

The MO USBIO 4x4 card connection is completed.

2.4.5 Connecting DI/DO (Stretch)

2.4.5.1 Connecting DI/DO cards to Stretch (VRC6004, VRC6008, VRC6416) cards

Building security video subsystem with the use of Stretch (VRC6004, VRC6008, VRC6416) video capture cards one can install DI/DO cards in order to connect external sensors (DI) and executive devices (DO) to the Server.

To connect DI/DO card, do the following:

1. Change the SW1 switch on DI/DO card (Figure 2.4-19) in accordance with Table 2.4-2.

Table 2.4-2 Changing the SW1 switch

DI/DO card	SW1 (1)	SW1 (2)
DI/DO card 1	OFF	OFF
DI/DO card 2	ON	OFF

2. If DI needs a power supply (active sensors), then put the J6 jumper on 2 and 3 contacts, otherwise – on 1 and 2 contacts (passive sensors) (Figure 2.4-19).

Note. The SW2 switch is used for the RS485 interface configuration.

3. Make sure that the computer is turned off.
4. Connect the DI/DO card to the video capture card with the help of a loop included in the distribution kit. The loop is connected to the J1 and J2 pins (see Figure 2.4-19 and *Appendix 5. Video capture cards pins section*).




Figure 2.4-19 Connection of DI/DO card to Stretch VRC6416 card

5. If it is necessary connect one more DI/DO card. Connect the loop to the J3 pin on the first and second DI/DO card (Figure 2.4-19).

6. Install the DI/DO card into vacant motherboard slot and fix it in the casing.
7. Connect DI and DO in accordance with the pinout of external pin of the DI/DO card (Figure 2.4-19).

Connection of the DI/DO card is completed.

2.4.5.2 Connecting DI/DO cards to Stretch VRC7008L card

Building security video subsystem with the use of Stretch VRC7008L video capture card one can install DI/DO cards in order to connect external sensors (DI) and executive devices (DO) to the Server.

To connect the DI/DO card, do the following:

1. If DI needs a power supply (active sensors), then put the SW1 jumper on 2 and 3 contacts, otherwise – on 1 and 2 contacts (passive sensors) (Figure 2.4-20).

Note. The SW2 switch is used for the RS485 interface configuration. If two DI/DO cards are in use, then the RS485 interface is disabled on the second card.

2. Make sure that the computer is turned off.
3. Connect the DI/DO card to the video capture card with the help of a loop included in the distribution kit. The loop is connected to the J1 and J2 pins (Figure 2.4-20).




Figure 2.4-20 Connection of DI/DO card to Stretch VRC7008L card

4. If it is necessary connect one more DI/DO card. Connect the loop to the J3 pin on the first and to the J2 pin on the second DI/DO card (Figure 2.4-20).
5. Install the DI/DO card into vacant motherboard slot and fix it in the casing.
6. Connect DI and DO in accordance with the pinout of external pin of the DI/DO card (Figure 2.4-20).

Connection of the DI/DO card is completed.

2.5 Connecting MO USBIO 4x4 external module

The MO USBIO 4x4 module is an interface for external sensors (DI) and external executive devices (DO) as a part of video surveillance and fire and security alarm systems (Figure 2.5-1).



Figure 2.5-1 Модуль «MO USBIO 4x4»

External module is controlled via the USB interface. Electrical and technical specifications of the module are given in *Electrical and technical specifications of MO USBIO 4x4* section.

To configure the MO USBIO 4x4 external module, do the following:

1. Connect the MO USBIO 4x4 module to the server via the USB cable included in the distribution kit.
2. To connect DI/DO, unsolder the connector included in the distribution kit. Unsoldering is made in accordance with the external connector pinout of the MO USBIO 4x4 module. Depending on module modification one of jack pinout shown in Figure 2.5-2 can be in use.




Figure 2.5-2 Jack pinouts of the MO USBIO 4x4 module

3. Fix the unsoldered connector in the casing included in the distribution kit.
4. Connect ready-for-use connector to external connector of the card in order to connect DI/DO to the Server.

The MO USBIO 4x4 external module configuration is completed.

2.6 Assembly and installation of audio subsystem hardware components

INTELLECT™ software supports synchro video and audio recording and remote audio monitoring.

To enable operation of the audio subsystem, the Operator Workstation should be equipped with auxiliary hardware, such as sound cards, microphones, loud speakers and earphones.

2.6.1 Supported sound cards and other audio input devices

The following audio input devices can be used in the audio subsystem:

1. Standard sound cards installed in a computer or motherboards integrated in a computer.
2. Multi-channel sound cards such as Comart Hera, MidiMan Delta and Olkha 9P.
3. Ekholot USB-32, an external module for multi-channel audio signal input (32 channels).
4. Audio input channels of the network devices.
5. Audio input channels of FS/WS cards. As these cards do not have audio output channels for playing back the audio signal, a sound card is to be installed.

2.6.2 Options for increasing the number of audio input channels when standard sound cards are used

INTELLECT™-based server can process as many analog audio signals as specified in the key file.

As a rule a standard sound card has only one stereo audio input channel. To increase the number of audio input channels, the following options are offered:

1. Use a stereo audio input channel of a standard sound card as two separate mono-channels.
2. Use audio input channels of video capture cards.
3. Install several standard sound cards on the server.

Note. Several sound cards of the same type installed within the system may cause conflicts in Windows OS.

4. Use multi-channel audio input cards (special sound cards support up to 16 separate audio input channels).
5. Use Ekholot USB-32, an external module for multi-channel audio signal input (32 channels).

2.6.3 Installing audio input devices

Manuals for installing sound cards of other manufacturers and the drivers for these cards, as well as any other devices are given in the documentation supplied with the hardware.

Sound channels of the network devices do not require any additional installation. The only requirement is that the device supports communication with the Server via the TCP/IP protocol.

2.6.4 Installing microphones and loud speakers

Microphones are to be installed in inaccessible places, ensuring unobstructed receipt of audio signals. Each microphone is connected to a sound card installed in a computer or to an audio plug on a videocapture card.

Loud speakers or earphones designed for audio signal receipt are installed in the Operator Workstation. Loud speakers or earphones are connected to the audio output plug of the sound card.

The layouts of pins for connecting microphones and earphones or loud speakers are given in the documentation for the sound cards.

Pins supplied with a video capture card are used to connect microphones to these video capture cards.

2.7 Connecting PTZ units and control panels

Attention! Before one starts working with a control panel or a PTZ unit it is necessary to read the list of integrated devices and protocols at [AxxonSoft's official website](#). If the connected device is not in the list, then its operation is not guaranteed.

The PTZ unit and control panel are connected to the server via a free serial port (COM) (RS-232 interface) (Figure 2.7-1).




Figure 2.7-1 Connecting PTZ units and control panels

As a rule, PTZ units use RS-422 or RS-485 interfaces. The PTZ unit is connected to a COM port of a server with RS-232 interface via RS-422 converter (RS-485) $\Rightarrow$ RS-232.

The PTZ unit uses RS-422/RS-485 based on a 4-wires diagram (2 wires for receipt and 2 wires for transmission). To control PTZ units from INTELLECT™, only 2 wires are used (transmitting data from the Server to the PTZ). The “T+” and “T-” contacts of the converter are connected to the “R+” and “R-” contacts of the PTZ.

The control panel is connected via converter RS-422 (RS-485) $\rightarrow$ RS-232. Only two wires, connected to the Server, are used to control PTZ units via control panel from INTELLECT™.

The PTZ unit and control panel controlling this PTZ unit are to be connected to one Server.

Detailed information about connecting PTZ units and control panels is given in the documentation accompanying the corresponding devices and converters. An example of controlling PTZ units with the help of control panel is described in the *Telemetry configuration* section.

2.8 Connecting and configuring network devices

Network devices allow remote video surveillance and audio monitoring using the TCP/IP telecommunication environment.

Network devices can be defined as separate hardware and software units integrated in the digital video surveillance system using the TCP/IP telecommunication environment. To work with network devices, the system requires connection to the telecommunication network using TCP/IP to interact with other components of the digital video surveillance system.

Network devices for video surveillance and audio monitoring are:

1. network cameras (IP-cameras);
2. various types of network videosevers.

Network cameras are designed for video surveillance and transmission of the digital video signal to the users via the TCP/IP telecommunication environment.

Note. If a network camera is equipped with an analog camera instead of a digital one, then a video signal is first digitized by an AD converter embedded in the camera and then transmitted to the users via the TCP/IP telecommunication environment.

Network videosevers are connected directly to the analog cameras; they digitize analog video signal and transmit it to the users via the TCP/IP telecommunication environment. The users operating analog cameras connected to the network servers can use the same functionality range for the video stream playback and transmission, as the functionality of network cameras.

Network devices are connected via a standard network pin RJ-45.

Detailed information on connecting network devices to Server is given in the documentation for corresponding network devices.

3 Configuring security system components in INTELLECT™ software

3.1 Configuring video capture cards in INTELLECT™ software

3.1.1 Video subsystem configuration

To set up a video subsystem in the INTELLECT™ software create the **Video capture card** objects under which the **Camera** objects are created.

3.1.1.1 Creating and configuring the Video capture card object

To create the **Video capture card** object, do the following:

1. Go to the **Hardware** tab in the **System settings** dialog box (Figure 3.1-1, 1).
2. Select **Create object** -> **Video capture card** in the context menu of the **Computer** object (Figure 3.1-1, 2).




Figure 3.1-1 Context menu of the Computer object

As a result the basic settings toolbar is displayed (Figure 3.1-2).

Note. Basic settings are specified automatically. It is possible to change an ID, object name and parent object.




Figure 3.1-2 Basic settings of the object

3. To create the object, click Apply.
4. Select the created object in the object tree (Figure 3.1-3, 1).






Figure 3.1-3 Configuring the Video capture card object

5. Configure the created object.
 - 5.1. From the **Type** list select type of the video capture card installed on the Server (Figure 3.1-3, 2).
 - 5.2. Specify the PCI channel by selecting value from the **PCI channel** list (Figure 3.1-3, 3). For cards based on one chip model (ADC) and one driver (see *Drivers for video capture cards integrated into the INTELLECT™ software* section) there is end-to-end distribution of PCI channels that starts with '00' (Figure 3.1-4).



PCI channels distribution for cards based on one chip model (ADC)

PCI channels distribution for cards based on different chip models (ADC)

Figure 3.1-4 Examples of PCI channels distribution

Note. Configuring FX4 or FX8 video capture cards, take into account the correlation between the color of BNC video input interface cable and PCI channel specified by INTELLECT™ software (see Features of video subsystem configuration section).

5.3. From the **Signal** list select the type of video input (PAL or NTSC) (Figure 3.1-3, 4).

Note 1. When Stretch VRC 6004, VRC 6008, VRC 6416, VRC 7008L cards are used, the video input (PAL or NTSC) is selected automatically depending on the camera connected to the card. Change of this parameter does not influence the card operation.

Note 2. When FX 116/416 cards are used, INTELLECT™ software should be restarted after changing the video input format. Otherwise the previous settings are active.

5.4. In the **Resolution** list (Figure 3.1-3, 5) select the **Standard**, **High** or **Full** resolution with which the video signal is captured. This action should be carried out when network video hubs are configured (e.g. WaveHub), otherwise this step can be skipped.

5.5. Specify allowable frame rate for the card by setting the **Speed** slider into the corresponding position (Figure 3.1-3, 6).

Table 3.1-1 Value of the Speed parameter

Value	Description
Max	Maximum allowable sum of video frame rate
Mean	Half of allowable sum of video frame rate
Min	One third of allowable sum of video frame rate

5.6. Click **Apply** to save the changes.

Setting the Video capture card object is completed.

Attention! Configuration of one physical video capture card requires creation of several Video capture card objects (see Features of video subsystem configuration section).

3.1.1.2 Creating and configuring the Camera object

To create and configure the **Camera** object, do the following:

1. Select **Create object** -> **Camera** in the context menu of the **Video capture card** object (Figure 3.1-5).




Figure 3.1-5 Context menu of the Video capture card object

As a result the basic settings toolbar is displayed (Figure 3.1-6).

Note. Basic settings are specified automatically. It is possible to change an ID, object name and parent object.




Figure 3.1-6 Basic settings of the object

2. To create the object, click Apply.
3. Select the created **Camera** object in the object tree (Figure 3.1-7, 1).




Figure 3.1-7 Configuring the Camera object

4. Configure the created object

4.1. From the **Channel number** list (Figure 3.1-7, 2) select a physical video output of the card to which the camera is connected (see *Features of video subsystem configuration* section).

Note. Channel numbers within one Video capture card must not be repeated.

4.2. In the **Resolution** list (Figure 3.1-7, 3) select the resolution: **Standard** – minimum accepted value for the card, High – mean value, Full – maximum accepted value with which a video signal is captured.

Note. Resolutions supported by video capture cards are given in Appendix 4. Technical specifications of video capture cards .

4.3. Click **Apply** to save the changes.

Configuring the **Camera** object is completed.

Repeat these actions for all cameras connected to the card.

Note 1. Number of the Camera objects that can be created under Video capture card object is specified in Features of video subsystem configuration section.

Note 2. Detailed description of all settings of the Camera object is given in INTELLECT™ software . Administrator's guide.

3.1.1.3 Configuring the analog video output

Expansion cards are used optionally and they bring out this functionality and installed directly on video capture cards. Intellect software brings out functionality of analog (decompressed and unprocessed) video output to external devices via corresponding BNC connector on video capture card (TV-out) (see *Installing the expansion card for analog video out* section).

Video outputting to analog monitor is made directly (without digitization) from one of the video cameras connected to Server.

Note. Configuring Intellect take into account that outputting of analog video to analog monitor is possible only from one camera.

For video outputting to analog monitor a video capture card must have an analog video output. An analog video output is integrated into FS-8 video capture cards. An extra analog video output card should be installed for FS-5, FS-6, FS-16 cards.

A video from any Server camera can be output to an analog monitor. By default, a video from the camera connected to the same video capture card as a monitor can be output to an analog monitor. To output a video from any camera connected to any video capture card on the Server, solder analog outputs (interface cables) on all Server video capture cards.

Note. When an analog video out card is connected to a video capture card and analog monitor connector to the corresponding BNC-connector on the video capture card, analog video outputting to analog monitor is activated automatically.

To output the video from all cameras installed on the Server and connected to different video capture cards, to one analog monitor (perhaps when analog video outputs of cards installed on the Server are soldered) in tweak.exe utility (Extended Intellect configuration) do the following:

1. Start **tweak.exe** utility in the **Tools** folder of Intellect installation directory.
2. Select the **Video subsystem** section (Figure 3.1-8, 1).




Figure 3.1-8 Extended Intellect configuration. Changing the value of the Analog video out parameter

3. In the **Analog video out** list select the **One** item to activate outputting video from cameras connected to different video capture cards to one analog monitor (Figure 3.1-8, 2).

Video commutation (switching) while outputting them to analog monitor is performed only within cameras connected to one video capture. Changing the Analog video out parameter allows to switch an extra program video commutator (switch) from all Server cameras connected to different video capture cards.

4. To save changes click **OK** (Figure 3.1-8).

If several analog cards are used, then the switch between cameras video from which is output to one analog monitor is made via macros and scripts (programs). For example for switching between two cameras one can create macros given in Table 3.1-2.

Table 3.1-2 Macros for switching between cameras video from which is output to one analog monitor

Macro	Operations			
	Type	Number	Name	Operation
Macro 1	Video capture card			Switch analog video out off 1
	Camera	1	Camera 1	Switch camera to output
Macro 2	Video capture card			Switch analog video out off 1
	Camera	2	Camera 2	Switch camera to output

Note. Detailed description of making macros is given in INTELLECT™ software . Administrator's Guide.

3.1.1.4 Configuring Stretch video capture card

To configure Stretch video capture card do the following:

1. Go to the **Hardware** tab in the **System settings** dialog box.
2. Create the **Video capture card** object under the **Localhost** object.
3. Select **Stretch (<compressor>)** in the **Type** list on the setting panel of the object. As a result the setting panel is refreshed (Figure 3.1-9, 1).

*Note. When the **Stretch(H264SVC)** type is selected:*

1. *The number of available channels and speed of data input via them decreased (see Table 7.4-6 Technical specifications of VRC6004, VRC6008, VRC6416, VRC7008L and VRC6404HD video capture cards).*
2. *Some video artifacts appear when the resolution is maximum.*
3. *It is recommended to use the 'h264ffmpegdecoder' decompressor. Preferred decompressor is selected on the setting panel of the **Camera** object (see INTELLECT™ software . Administrator's Guide).*




Figure 3.1-9 Setting panel of the Stretch video capture card. Basic settings tab

4. Set the values to the basic parameters of the card (Figure 3.1-9, 2). Detailed description of parameters is given in *Creating and configuring the Video capture card object* section (see 5.3 – 5.5 steps).
5. Go to the **Additional settings** tab (Figure 3.1-10, 1).




Figure 3.1-10 Setting panel of the Stretch video capture card. Additional settings tab

- 5.1. From the **PCI** list select number of a PCI channel (Figure 3.1-10, 2). Features of PCI channel distribution are given in *Creating and configuring the Video capture card object* section (see 5.2 step).
- 5.2. In the **Host** field enter the network name of computer (Figure 3.1-10, 3).

As a result the **Identifier** field is filled automatically on the **Basic settings** tab (Figure 3.1-11).




Figure 3.1-11 The Identifier field. Basic settings tab

6. To save changes click **Apply**.
7. Configure cameras connected to Stretch video capture card (see *Creating and configuring the Camera object*).

Configuring Stretch video capture card is completed.

Note. IP Wizard can be used to configure Stretch video capture cards in INTELLECT™ software (see IP Wizard section).

3.1.1.5 Configuring HikVision video capture card

To configure HikVision video capture card do the following:

1. Go to the **Hardware** tab in the **System settings** dialog box.
2. Create the **Video capture card** object under the **Localhost** object.
3. Select **HikVision(<compressor>)** in the **Type** list on the setting panel of the object.

Note. IP Wizard can be used to configure HikVision video capture cards in INTELLECT™ software (see IP Wizard section).

3.1.2 Audio subsystem configuration

In INTELLECT™ software the audio subsystem is configured with the help of the **Audio card** objects under which the **Microphone** objects (corresponding to connected audio devices) are created.

3.1.2.1 Creating and configuring the Audio card object

To create and configure the **Audio card** object, do the following:

1. Go to the **Hardware** tab in the **System settings** dialog box (Figure 3.1-12, 1).
2. Select **Create object -> Audio card** in the context menu of the **Computer** object (Figure 3.1-12, 2).




Figure 3.1-12 Context menu of the Computer object

As a result the basic settings toolbar is displayed (Figure 3.1-13).

Note. Basic settings are specified automatically. It is possible to change an ID, object name and parent object.




Figure 3.1-13 Basic settings of the object

3. To create the object, click **Apply**.

4. Select the created **Audio card** object in the object tree (Figure 3.1-14, 1).




Figure 3.1-14 Configuring the Audio card object

5. Configure the created object.
 - 5.1. In the **Board** list (Figure 3.1-7, 2) specify the type and PCI channel of the card (Figure 3.1-14, 2). Between the **Audio cards** objects there is end-to-end distribution of PCI channels that starts with '0'.
 - 5.2. In the **Sample rate** list select the audio sample rate (Figure 3.1-14, 3).

Note 1. Using channels from FS 5\6\16 cards set 8000, 16000 or 32000 sample rates while configuring the LinuxHub audio card. Otherwise there is no guarantee of receiving audio from FS5\6\16 cards. Set another sample rate if audio is received only from the embedded audio card.

*Note 2. Sample rate for FX HD4 (SA 7160PCI) card (specified in the **Sample rate** list) is to be the same as the sample rate on the video camera. If rate values are not the same then slow-/fast- motion is possible.*

- 5.3. Click **Apply** to save the changes.

Configuring the **Audio card** object is completed.

Attention! To configure one physical video capture card the creation of several Audio card objects is required (see *Features of audio subsystem configuration* section).

3.1.2.2 Creating and configuring the Microphone object

To create and configure the **Microphone** object, do the following:

1. Select **Create object** -> **Microphone** in the context menu of the **Audio card** object (Figure 3.1-15).




Figure 3.1-15 Context menu of the Microphone object

As a result the basic settings toolbar is displayed (Figure 3.1-16).

Note. Basic settings are specified automatically. It is possible to change an ID, object name and parent object.




Figure 3.1-16 Basic settings of the object

2. To create the object, click **Apply**.
3. Select the created **Microphone** object in the object tree (Figure 3.1-17, 1).




Figure 3.1-17 Configuring the Microphone object

4. Configure the created object.
- 4.2. In the **Channel** list (Figure 3.1-17, 2) select the channel to which the audio device is connected (see *Features of audio subsystem configuration* section).
- 4.3. In the **Line** list (Figure 3.1-17, 3) select the device type (microphone, by default).
- 4.4. Configure the level of sound volume using the **Increase** slider. Sound availability in the specific microphone and the increase value are in the **Volume level** graphic scale (Figure 3.1-17, 4).
- 4.5. Click **Apply** to save the changes.

Configuring the **Microphone** object is completed.

Note 1. Number of the Microphone objects that can be created under one Audio card object is specified in Features of audio subsystem configuration section.

Note 2. Detailed description of all settings of the Microphone object is given in INTELLECT™ software . Administrator's guide

3.1.3 Initial configuration wizard

One can configure video subsystem automatically in INTELLECT™ software using the initial configuration wizard.

Note. This opportunity is not provided for demo version of INTELLECT™ software .

Attention! If the Video capture card or Audio card has already been created in INTELLECT™ software then the initial configuration wizard does not work.

To configure the video subsystem automatically, do the following:

1. Go to the **Hardware** tab in the **System settings** dialog box (Figure 3.1-18, 1).
2. Select the **Localhost** object related to the required Server in the object tree on the **Hardware** tab (Figure 3.1-18, 2).

- Click **Initial configuration wizard** on the settings panel of selected object (Figure 3.1-18, 3).




Figure 3.1-18 Initial configuration wizard

The **Creating initial configuration of the video subsystem** window is displayed (Figure 3.1-19).




Figure 3.1-19 Initial configuration wizard

- To create initial configuration of the video subsystem, click **OK** (Figure 3.1-19). This action will add objects under Intellect software key.
As a result the created objects are displayed in the object tree (Figure 3.1-20).




Figure 3.1-20 Created objects

Note. The following objects are created as a result of initial configuration wizard working:

1. The **Video capture card** objects (specified in the key) that correspond to the physical video capture cards (for example, 4 **Video capture card** objects are created for one FS6/16 video capture card);
2. The **Camera** objects - one for each **Video capture card** object;
3. The **Audio card** object configured for working with a local audio card;
4. The **Microphone** objects under the **Audio card** object (the number of the **Microphone** objects is equal to the number of audio channels in the key).

Initial configuration wizard does not create other objects that are given in the key.

The automatic configuration of video subsystem is completed.

3.1.4 Configuring the Watchdog hardware performance tester

Hardware performance tester is for computer autoreboot in case of the Windows OS or main Intellect software modules failure.

INTELLECT™ software allows configuring the Watchdog hardware performance tester when operating with video capture cards that support this functionality (see Appendix 4. Technical specifications of video capture cards).

The Watchdog hardware performance tester on the Server with installed video capture cards is configured in 3 stages:

1. Make sure that the Watchdog hardware performance tester is connected correctly (see *Connecting the Watchdog hardware performance tester* section).
2. Activate the function of the Watchdog hardware performance tester on the setting panel of the **Video capture card** object.
3. Verify the Watchdog hardware performance tester.

To activate and verify the Watchdog hardware performance tester, do the following:

1. Go to the **Hardware** tab in the **System settings** dialog box.
2. Set the **Activate watchdog** checkbox on the setting panel of the **Video capture card** object corresponding to one ADC on the card to which the Watchdog is connected (Figure 3.1-21, 1).

*Note 1. When FX4, FX8 and FX16 video capture cards are used set the **Activate watchdog** checkbox in the settings of every **Video capture card** object created for the card to which the Watchdog is connected.*

*Note 2. The **07** PCI channel should be selected for one of the **Video capture card** objects corresponding to the ADC of FS8 card for correct operation of the Watchdog hardware performance tester on FS8 video capture card. At the same time the Watchdog hardware performance tester can be activated on the setting panel of any **Video capture card** object of FS8 card.*

3. To save changes click **Apply** (Figure 3.1-21, 2).
4. End the **video.run** process using the Windows task manager (Figure 3.1-22).




Figure 3.1-21 Activation of the Watchdog hardware performance tester on the Server with installed video capture cards




Figure 3.1-22 Ending of the video.run process using the Windows task manager

5. If the Watchdog hardware performance tester is connected and configured, then there is Windows reboot.

Note. On FS15 and FX video capture cards Windows reboots in several minutes after ending of the video.run process.

Activation and verification of the Watchdog hardware performance tester is completed.

3.2 Configuring IP devices

3.2.1 General information about IP devices

INTELLECT™ software allows receiving, digitizing, processing and playing back the audio and video with the help of IP devices. IP cameras and IP servers can be used as IP devices for receiving, digitizing, processing and playing back the video.

IP device is configured with the help of Web server or another software delivered with this device and Intellect configuration.

Process parameters (size, frame rate, frame resolution, brightness, contrast, color saturation, color format) and parameters of video compression are set with the help of Web server or another software delivered with this device.

INTELLECT™ software receives and processes video with the help of detectors, records and transmits video from IP devices to remote workplaces.

Before using IP devices in the INTELLECT™ software make sure that process and digitization parameters (codecs) of IP devices installed with the help of Web server are supported by Intellect software package. The list of IP devices compatible with the INTELLECT™ software and relevant information about the compatibility is shown on the website of Axxonsoft company in the 'Integration' section: <http://www.itv.ru/products/integration/>.

3.2.2 Configuring video acquisition from IP devices

As a rule IP devices allow processing one or more video depending on the type of device in use.

Every IP device used for video input is registered in INTELLECT™ software by creating and configuring the **Video capture card** object. The **Video capture card** objects are created on the **Hardware** tab under the **Localhost** object. When the **Video capture card** objects are created the following parameters should be set for every IP device:

1. In the **Type** list select IP device and codec used by this device.

Note. Codec is specified in brackets. If the codec is not specified then MJPEG is by default.

2. In the **IP address** field enter the specified network address of IP device. IP address assigning is described in *Assigning network addresses to IP devices* section.
3. In the **Port** field enter the port number (TCP/IP) used for video transmission.
4. Enter corresponding data into the **Name** and **Password** fields for logging into Web server of IP device.
5. If the parameters set with the help of Web server or another software of IP device should be used, then set the **Use device settings** checkbox.

*Note. If video camera settings specified with the help of IP device software are not used in INTELLECT™ software or used partially, then set the **Use device settings** checkbox unchecked and configure a video camera on the setting panel of the **Camera** object.*

After logging into INTELLECT™ software the values corresponding to numbers of connection channels of video cameras to IP device should be given to the **Chanel number** parameters of the **Camera** object.

*Note. Set the 1 value for the **Chanel number** parameter when IP camera is configured. Otherwise IP camera is nonworking.*

3.2.3 Configuring audio acquisition from IP devices

Every IP device used for audio input is registered in the INTELLECT™ software by creating and configuring the **Audio card** object. The **Audio card** objects are created on the **Hardware** tab under the **Localhost** object. When the **Audio card** objects are created the values of short names of IP devices should be set to the **Card** parameter for every IP device. Hover the cursor over the end of the **Card** line and specify the IP address of the device, username and password for access to device (if specified). Examples of configuring the **Card** parameter of the **Audio card** object for Axis video camera are given in Figure 3.2-1.



A. when there is no username or password



B. when there is a username and password

Figure 3.2-1 Examples of configuring the Card parameter for Axis IP camera

When the **Audio card** is configured restart the INTELLECT™ software. Otherwise the audio subsystem (particularly, microphones) can not be configured.

Microphones built into or connected to IP devices are registered in the INTELLECT™ software by creating the **Microphone** objects under the **Audio card** object. Under one **Audio card** object there are the **Microphone** objects in amount corresponding to the amount of audio input channels and restrictions applied by a license key. Corresponding segment of hardware branch when IP device and one microphone are registered is given in Figure 3.2-2.



Figure 3.2-2 Hardware branch when IP device and microphone are registered

When the Microphone object is created, select the channel number of connecting the microphone to audio input device from the **Channel** dropdown list (Figure 3.2-2).

3.2.4 IP Wizard

To create IP devices in the INTELLECT™ software, do the following:

1. Go to the **Hardware** tab in the **System settings** dialog box (Figure 3.2-3, 1).
2. In the object tree select the **Camera** object corresponding to the configured Server (Figure 3.2-3, 2).
3. Click **IP devices creation wizard** on the setting panel of the selected object (Figure 3.2-3, 3).




Figure 3.2-3 The IP devices creation wizard window

As a result the **IP Wizard** window is displayed. Found IP devices are displayed on the top of the window (Figure 3.2-5).

*Note. The **IP Wizard** window can also be displayed by selecting the **IP Wizard** item in the context menu of the **Localhost** object (Figure 3.2-4).*




Figure 3.2-4 The IP Wizard item in the context menu of the Localhost object




Figure 3.2-5 The IP Wizard window

4. Check up the vendor (Figure 3.2-5, 1) and model (Figure 3.2-5, 2) for для found IP device. Make changes if necessary by opening corresponding dropdown list (use button) and changing required value.
5. Check up the TCP/IP port (Figure 3.2-5, 5). Enter the required value in the field.
6. Enter login (Figure 3.2-5, 3) and password (Figure 3.2-5, 4) to connect IP device. Login and password are given in the documentation for connected network device.
7. Select the objects that should be created under IP device.

*Note. The number of objects that can be created under IP device is displayed automatically in the **Hardware available for adding** table.*

- 7.1. Open the dropdown list of supported IP device by clicking the button (Figure 3.2-6).



Figure 3.2-6 The list of objects supported by IP devices

Correspondence of object names in IP Wizard to the branches of object tree is in Table 3.2-1.

Table 3.2-1 Correspondence of object names in IP Wizard to the branches of object tree

Name of object in IP Wizard	Branch of object tree in the INTELLECT™ software
Video channel	The Video capture card object -> The Camera object
Audio input	The Audio card object -> The Microphone object
Contact	The Video capture card object -> The DI object
Executive device	The Video capture card object -> The DO object

Name of object in IP Wizard	Branch of object tree in the INTELLECT™ software
Telemetry line	The Telemetry controller object -> The PTZ device object
Audio output	The Playback card object -> The Loud speaker object

7.2. Set checkboxes for objects that should be created.

Note. To create/delete all objects set the checkboxes checked/unchecked for vendor of IP device.

8. Click **Apply** (Figure 3.2-5, 6).

The selected objects are created automatically in the **Hardware** object tree.

9. Repeat steps 4-8 for each IP device that should be created in the system.

*Note. To delete the device from the IP Wizard window right – click the corresponding line in the table and select the **Delete camera <IP address> from the list** item.*

10. If the IP device is not found, then add it manually.

- 10.1. Enter the IP address of device in the **IP address** field (Figure 3.2-5, 7).
- 10.2. Enter the number of TCP/IP port in the **Port** field (Figure 3.2-5, 8).
- 10.3. Select the vendor of IP device in the **Vendor** dropdown list (Figure 3.2-5, 9).
- 10.4. Select the model of IP device in the **Model** dropdown list (Figure 3.2-5, 10).
- 10.5. Click **Add** (Figure 3.2-5, 11).

As a result The IP device with specified parameters is displayed in on the top of the window.

11. To complete the IP device creation step 6-8.

12. Click **Exit** to close the IP Wizard window (Figure 3.2-5, 12).

IP device creation is completed.

3.2.5 Features of IP device configuration

3.2.5.1 Features of Beward IP cameras configuration

By default port 80 is set for connecting to IP devices on the settings panel of the **Video capture card** object. Enter the **5000** value in the **Port** field to connect to IP device of Beward B-9xx series and B-10xx series (B-975W, B-970, B-915, B2.920, B-1070, B-1014 models and others).

3.2.5.2 Features of Panasonic IP devices (i-Pro series) configuration

When Panasonic IP-device (i-Pro series) is configured to compress in MPEG4 format, the **Speed** slider controls videodata bitrate on the settings panel of the **Video capture card** object. When this parameter is changed, both the speed of video stream and image quality are changed.

Note. WV-NP1000\1004, WV-F284, WV-NP240\244, WV-NS202 models and others are IP-devices (i-Pro series).

Image from Panasonic IP device (i-Pro series) is displayed in the **Monitor** interface window with delay from 15 sec to 1 min, depending on the model of the camera.

3.2.5.3 Features of TrendNet IP device configuration

TrendNet IP device is restarted when one of the following settings is changed on the settings panel of the **Video capture card** object and/or **Camera** object:

1. Speed parameter (Video capture card);
2. Quality parameter (Camera);
3. Resolution parameter (Video capture card, Camera).

When the changes are saved, video disappears for about 1 min (time depends on the model of the camera) and then it is restored with new parameters.

Note. TrendNet TV-IP312W, TV-IP212W, TV-IP110, TV-IP410 IP devices are restarted.

3.2.5.4 Features of Pelco Spectra IV IP device configuration

If Pelco Spectra IV IP device is configured to compress in MPEG4 format, then the **Resolution** dropdown list on the settings panel of the **Camera** object is used for simultaneous configuration of three video signal parameters:

1. Resolution;
2. Speed;
3. Compression quality.

At the same time the Speed (**Video capture card** object) and Quality (**Camera** object) parameters do not interfere with the corresponding parameters of a video signal.

To set maximum quality, resolution and speed select the **Full** or **High** value from the **Resolution** dropdown on the settings panel of the **Camera** object. The **Standard** value should be selected to set the lowered compression quality of resolution and speed of video signal.

3.2.5.5 Features of AEBELL IP device configuration

By default port 80 is set for connecting to IP devices on the settings panel of the **Video capture card** object. Enter the **36688** value in the **Port** field to connect to AEBELL BL-E704F IP server.

3.2.5.6 Features of Dynacolor IP device configuration

Dynacolor DynaHawk ZH-801+ IP device is restarted when one of the following settings is changed on the settings panel of the **Video capture card** object and/or **Camera** object:

1. The **Type** parameter (Video capture card) – selection of Dynacolor (mjpeg) or Dynacolor (mpeg-4) video stream compression format;
2. The **Speed** parameter (Video capture card);
3. The **Quality** parameter (Camera);
4. The **Resolution** parameter (Camera);

When the changes are saved, video disappears for about 1 min and then it is restored with new parameters.

There can also be no video for about one minute when Intellect is started.

3.2.5.7 Features of Stream Labs IP device configuration

Note. Detailed description of the given devices can be found at <http://www.ipstreamlabs.ru/products-index.html>

3.2.5.7.1 Features of Wave Cam M5 camera

1. Automatic brightness control. In this mode Intellect automatically uses internal algorithm of image's brightness control. This mode is enabled when the **Brightness** slider is set to a minimum position. When there are no special requirements to the image, then this mode of brightness control is recommended.

Note. Brightness can be controlled manually, moving the Brightness slider.

2. Video stream frame rate. Wave Cam M5 camera supports two channels of video displaying. When only one video channel is engaged in Intellect, the video stream frame rate is 25 fps. When both channels are engaged, frame rate of video stream for each channel is 12fps.
3. Telemetry. Wave Cam M5 camera is not a PTZ device. One can control some area of an image with the help of video surveillance monitor. While configuring the Telemetry on a Wave Cam M5 camera, do the following:

- 3.1. Select the protocol of data exchange with a camera - IP-Camera (on the settings panel of the **Telemetry control** object).
- 3.2. Apply PTZ device to the first video input channel (is set in the **Channel number** list on the settings panel of the **Camera** object).
- 3.3. Apply telemetry control panel to the first video input channel (is set in the **Channel number** list on the settings panel of the **Camera** object).

Note. The image will move through the second video input channel.

3.2.5.7.2 Features of Wave Server Enterprise hardware internetwork

1. Video stream frame rate. When only one camera is connected to Wave Server Enterprise hardware internetwork, the video stream frame rate is 25 fps. When two or more cameras are connected, total frame rate of processed video is 16 fps.

Note. If two video input channels are used, then frame rate of processed video is $16/2=8$ fps. If there are four video input channels, then $16/4=4$ fps.

2. Telemetry. Telemetry is performed on a separate card with its own network interface. To configure it, do the following:
 - 2.1. Select the protocol of data exchange with camera with the help of which an analog camera connected to the video server is controlled on the settings panel of the **Telemetry control** object (for example, Pelco-D, Pelco-P, Panasonic-850).
 - 2.2. Create two **Video capture card** objects.

*Note. For every analog camera connected to Wave Server Enterprise, two **Camera** objects are necessary to be created on the base of different **Video capture card** objects for video viewing and telemetry configuration correspondingly.*

3.2.5.7.3 Features of Wave Server WH1501 video server

Telemetry. When telemetry for Wave Server WH1501 video server is configured, it is necessary to select protocol with the help of which the analog camera connected to the video server is controlled, on the settings panel of the **Telemetry control** object (for example, Pelco-D, Pelco-P, Panasonic-850).

3.2.5.8 Features of Cisco IP device configuration

Cisco 4500 IP-device supports the following formats of video signal compression:

1. H.264;
2. MJPEG.

While setting the resolution the H.264 format has a higher priority than MJPEG: a possibility to set the resolution for MJPEG exceeding the given for H.264, is not provided.

Priority difference leads to the following effects:

1. After changing the video capture card of the **Cisco(h264)** type for **Cisco(mjpeg)** with standard video resolution, MJPEG video resolution can not be increased;
2. When the video capture card of the **Cisco(mjpeg)** type is changed for **Cisco(h264)** with full video resolution, the resolution will be changed from 704*576 to 1280*720. Resolution 720*576 will be set after return to the **Cisco(mjpeg)** type.

*Note. The type of a video capture card is selected from the **Type** dropdown list on the settings panel of the **Video capture card** object. Video resolution is set with the use of analogous parameter on the settings panel of the **Camera** child object.*

3.2.5.9 Features of Mobotix IP device configuration

Mobotix IP camera supports the following formats of video compression in Intellect:

1. MJPEG;
2. MxPEG.

Audio subsystem of Mobotix IP devices may be used when video is encoded in MxPEG. To choose this format, select the **Mobotix MxPEG** value from the **Type** list on the settings panel of the **Video capture card** object.

*Note 1. When the **Mobotix** value is selected, video is received in MJPEG format and audio subsystem functionality of IP device is not performed.*

Note 2. Mobotix IP cameras that support sound are Q24M, D12, M22 and others. Detailed description of these devices can be found at <http://www.mobotix.ru/default.aspx>

3.3 Configuring DI/DO devices in INTELLECT™ software

3.3.1 Creating and configuring the Relay system object

The **Relay** system object is created under the **Video capture card** object.

The **Relay** object is created and main parameters are set in the following order:

1. Go to the **Hardware** tab in the setting panel of INTELLECT™ (Figure 3.3-1, 1).
2. Create the **Relay** system object under the **Video capture card** object or select the corresponding object in the object tree in the **Hardware** tab of the setting panel of INTELLECT™ (Figure 3.3-1, 2).




Figure 3.3-1 The setting panel of the Relay object

3. Specify the ID and name of the **Relay** object and select the **Video capture card** object to become the parent of the **Relay** object (Figure 3.3-1, 3).

Note. If the DI/DO card is used, then specify that video capture card with ADC to which the DI/DO card is connected.

4. Select the **Channel number** matching the number of DO pin to which the relay is connected (Figure 3.3-1, 4).
5. In the **Executor** dropdown list select the type of executive device used as the relay in the guarded area (Figure 3.3-1, 5).

The **Executor** parameter is used for selecting the icon on the interactive map. This parameter is essential for better perception of information (displayed on the map as object icons) by Operator and for real-time intercepting by Operator if required.

The types of executive devices available for the **Relay** system object are given in Table 3.3-1.

Table 3.3-1 Types of executive devices

Executive device	Description
Light	Icon of the interactive map for the device responding to changes in the illumination in the guarded area

Signal	Icon of the interactive map for the device responding to sound changes in the guarded area
Lock	Icon of the interactive map for the device responding to opening/closing of a window, door, etc.

- Click **Apply** to save the changes.

Creating and configuring the **Relay** system object is completed.

3.3.2 Creating and configuring the Sensor system object

The **Sensor** system object is created under the **Video capture card** object.

The **Sensor** object is created and main parameters are set in the following order:

- Go to the **Hardware** tab in the setting panel of INTELLECT™ (Figure 3.3-2, 1).
- Create the **Sensor** system object under the **Video capture card** object or select the corresponding object in the object tree in the **Hardware** tab of the setting panel of INTELLECT™ (Figure 3.3-2, 2).




Figure 3.3-2 The setting panel of the Sensor object

- Specify the ID and name of the **Sensor** object and select the **Video capture card** object to become the parent of the **Sensor** object (Figure 3.3-2, 3).

Note. If the DI/DO card is used, then specify that video capture card with ADC to which the DI/DO card is connected.

- Select the **Channel number** matching the number of DO pin to which the sensor is connected (Figure 3.3-2, 4).
- In the group of switches select the alarm mode: at switch on or at switch off. By default the **alarm at switch on** mode is selected (Figure 3.3-2, 5).

The executive device corresponding to the Sensor system object operates at one of modes: alarm at switch on or alarm at switch off.

Note. Sensors connected to Panasonic IP-devices (i-Pro series) trigger only at switch off.

When the **alarm at switch off** mode is selected, the normal state of the sensor is open. When the sensor closes, it triggers and the corresponding actions are carried out in INTELLECT™.

6. In the **Hardware** dropdown list select the type of executive device used as the detector in the guarded area (Figure 3.3-2, 6).

The **Detector** parameter is used for selecting the icon on the interactive map. This parameter is essential for better perception of information (displayed on the map as object icons) by Operator and for real-time intercepting by Operator if required.

Types of detectors available for the **Sensor** system object are given in Table 3.3-2.

Table 3.3-2 Types of detectors

Detector	Description
Infrared	Icon of the interactive map for the motion detectors
PIR	Icon of the interactive map for the device on the ceiling of the guarded area
Glass	Icon of the interactive map for the device on the window of the guarded area responding when the window is broken
Fire	Icon of the interactive map for the device responding to changes of heat conditions in the guarded area
Window	Icon of the interactive map for the device installed some distance away the window and responding when the window is broken
Smoke	Icon of the interactive map for the device responding to smoke in the guarded area
Reed switch	Icon of the interactive map for the device responding to opening/closing of a window, door, etc.

7. Click **Apply** to save the changes.

Creating and configuring the **Sensor** system object is completed.

3.3.3 Configuring DI/DO expansion cards

3.3.3.1 Connecting relays

If relays are connected to the DI/DO card, then up to 4 **Relay** objects can be created under the **Video capture card** parent object.

All the **Relay** objects corresponding to relays connected to one DI/DO card are to be created in the **Hardware** object tree under the **Video capture card** object corresponding to the video capture card where the DI/DO card is installed.

If the DI/DO card is installed on FS-5, FS-6 or FS-16 video capture card, then the **Relay** objects are to be created under any **Video capture card** object within the hardware card.

If the DI/DO card is installed on WS216 video capture card, then the **Relay** objects are to be created under the **Video capture card** object with **04** value of the PCI-channel.

If the DI/DO card is installed on FS-8 video capture card, then the **Relay** objects are to be created under the **Video capture card** object with **07** value of the PCI-channel (Figure 3.3-3).




Figure 3.3-3 Connecting relays on FS-8 card

One can relocate the **Relay** objects in the object tree.

To change the parent **Video capture card** object of the **Relay** objects, change the value of the **Video capture card** object on the settings panel of the **Relay** object. The value of this parameter is to correspond to the number of the **Video capture card** object (in the object tree) under which the **Relay** object is to be located. If the value of the **Video capture card** parameter is changed on the settings panel of the **Relay** object, then the object is moved to the branch of child objects of the corresponding **Video capture card** object.

*Note. All **Relay** objects related to one DI/DO card are to be located in child branches under the same **Video capture card** object for proper operation of INTELLECT™. The **Relay** objects are not to be located under different **Video capture card** objects even if these objects represent the same video capture card with the adjustable DI/DO card.*

Figure 3.3-4 shows an example of locating the **Relay** objects in the object tree when two FS-6 (FS-16) video capture cards are used, with 4 relays connected to the first 4/4 (or 16/4) DI/DO card and 2 relays connected to the second one.




Figure 3.3-4 Example of the Video capture card parameters when two FS-6 (FS-16) video capture cards with two 4/4 or 16/4 DI/DO cards with 6 relays are used

Configuring the **Relay** objects one is to specify the channel numbers of sensor connection to the DI/DO card according to the numbers of the DO pins.

To change the channel numbers, use the **Channel Number** list in the settings panel of the **Relay** object.

The 4/4 and 16/4 DI/DO cards allow connecting up to 4 relay channels according to the license key file.

Figure 3.3-5 shows an example of the channel numbers configuration of 4 relays connected to one 4/4 DI/DO card installed on FS-6 (FS-16) video capture card.




Figure 3.3-5 Example of the of the channel numbers configuration of relays connected on 4/4 DI/DO card installed on FS-6 (FS-16) video capture card (4 ADCs for 4 Video capture card objects)

The channels of the second (next) 16/4 DI/DO card are numbered from 1 to 4 according to the DI pins (Figure 3.3-6).




Figure 3.3-6 Example of the of the channel numbers configuration of relays connected on the second (next) 16/4 DI/DO card installed on FS-6 (FS-16) video capture card (4 ADCs for 4 Video capture card objects)

3.3.3.2 Connecting sensors via 4/4 DI/DO card

One can create up to 4 **Sensor** objects under the **Video capture card** object when 4/4 DI/DO card is installed.

All the **Sensor** objects corresponding to sensors connected to one 4/4 DI/DO card are to be created in the **Hardware** object tree under the **Video capture card** object corresponding to the video capture card where the DI/DO card is installed.

If the DI/DO card is installed on FS-5, FS-6 or FS-16 video capture card, then the **Sensor** objects are to be created under any **Video capture card** object within the hardware card.

If the DI/DO card is installed on WS216 video capture card, then the **Sensor** objects are to be created under the **Video capture card** object with **00** value of the PCI-channel.

If the DI/DO card is installed on FS-8 video capture card, then the **Sensor** objects are to be created under the **Video capture card** object with **07** value of the PCI-channel (Figure 3.3-7).




Figure 3.3-7 Connecting sensors on FS-8 card

One can relocate the **Sensor** objects in the object tree. To change the parent **Video capture card** object of the **Sensor** objects, change the value of the **Video capture card** object on the settings panel of the **Sensor** object. The value of this parameter is to correspond to the number of the **Video capture card** object (in the object tree) under which the **Sensor** object is to be located. If the value of the **Video capture card** parameter is changed on the settings panel of the **Sensor** object, then the object is moved to the branch of child objects of the corresponding **Video capture card** object.

*Note. All **Sensor** objects related to one DI/DO card are to be located in child branches under the same **Video capture card** object for proper operation of INTELLECT™. The **Sensor** objects are not to be located under different **Video capture card** objects even if these objects represent the same video capture card with the adjustable DI/DO card.*

Figure 3.3-8 shows an example of locating the **Sensor** objects in the object tree when two FS-6 (FS-16) video capture cards are used, with 4 sensors connected to the first 4/4 DI/DO card and 2 sensors connected to the second one.




Figure 3.3-8 Example of the Video capture card parameters when two FS-6 (FS-16) video capture cards with two 4/4 or 16/4 DI/DO cards with 6 sensors are used

Configuring the **Sensor** objects one is to specify the channel numbers of sensor connection to the DI/DO card according to the numbers of the DO pins.

To change the channel numbers, use the **Channel Number** list in the settings panel of the **Sensor** object.

4/4 DI/DO card allows connecting up to 4 sensor channels according to the license key file.

Figure 3.3-9 shows an example of the channel numbers configuration of 4 sensors connected to one 4/4 DI/DO card installed on FS-6 (FS-16) video capture card.




Figure 3.3-9 Example of the of the channel numbers configuration of sensors connected on 4/4 DI/DO card installed on FS-6 (FS-16) video capture card (4 ADCs for 4 Video capture card objects)

The channels of the second (next) 4/4 DI/DO card are numbered from 1 to 4 according to the DI pins (Figure 3.3-10).




Figure 3.3-10 Example of the of the channel numbers configuration of sensors connected on the second (next) 4/4 DI/DO card installed on FS-6 (FS-16) video capture card (4 ADCs for 4 Video capture card objects)

3.3.3.3 Connecting sensors via 16/4 DI/DO card

One can create up to 16 **Sensor** objects under the **Video capture card** object when 16/4 DI/DO card is installed.

All the **Sensor** objects corresponding to sensors connected to one 16/4 DI/DO card are to be created in the **Hardware** object tree under the **Video capture card** object corresponding to the video capture card where the DI/DO card is installed.

If the DI/DO card is installed on FS-5, FS-6 or FS-16 video capture card, then the **Sensor** objects are to be created under any **Video capture card** object within the hardware card.

If the DI/DO card is installed on FS-8 video capture card, then the **Sensor** objects are to be created under the **Video capture card** object with **07** value of the PCI-channel (Figure 3.3-11).




Figure 3.3-11 Connecting sensors on FS-8 card

One can relocate the **Sensor** objects in the object tree. To change the parent **Video capture card** object of the **Sensor** objects, change the value of the **Video capture card** object on the settings panel of the **Sensor** object. The value of this parameter is to correspond to the number of the **Video capture card** object (in the object tree) under which the **Sensor** object is to be located. If the value of the **Video capture card** parameter is changed on the settings panel of the **Sensor** object, then the object is moved to the branch of child objects of the corresponding **Video capture card** object.

Figure 3.3-12 shows an example of locating the **Sensor** objects in the object tree when two FS-6 (FS-16) video capture cards are used, with 16 sensors connected to the first 16/4 DI/DO card and 2 sensors connected to the second one.




Figure 3.3-12 Example of the Video capture card parameters when two video capture cards with two 16/4 DI/DO cards with 6 sensors are used

Configuring the **Sensor** objects one is to specify the channel numbers of sensor connection to the DI/DO card according to the numbers of the DO pins.

To change the channel numbers, use the **Channel Number** list in the settings panel of the **Sensor** object.

16/4 DI/DO card allows connecting up to 16 sensor channels according to the license key file.

Figure 3.3-13 shows an example of the channel numbers configuration of 16 sensors connected to one 16/4 DI/DO card installed on FS-6 (FS-16) video capture card.




Figure 3.3-13 Example of the of the channel numbers configuration of sensors connected on 16/4 DI/DO card installed on FS-6 (FS-16) video capture card (4 ADCs for 4 Video capture card objects)

The channels of the second (next) 16/4 DI/DO card are numbered from 1 to 16 according to the DI pins (Figure 3.3-14).




Figure 3.3-14 Example of the of the channel numbers configuration of sensors connected on the second (next) 16/4 DI/DO card installed on FS-6 (FS-16) video capture card (4 ADCs for 4 Video capture card objects)

3.3.4 Configuring DI/DO expansion cards (low profile)

3.3.4.1 Connecting relays

Depending on what video capture card is used, the **Relay** objects corresponding to relays connected to 4/4 DI/DO card (low profile) are created under the **Video capture card** objects of one of the following types: FS 115, FX 4, FX 8 and FX 16 (Figure 3.3-15).

The **Relay** objects are to be created under the **Video capture card** object that has the first PCI channel. E.g., building security video subsystem with the use of two FX4 and two DI/DO cards (low profile) the **Relay** objects are to be created under the **Video capture card** objects with **00** (for the first FX4 card) and **04** (for the second FX4 card) values of PCI channels.

*Note 1. For FX16 video capture card the **Relay** objects can be created under the **Video capture card** object with **00** or **08** value of PCI channel. Working channel is discovered experimentally.*

*Note 2. Number of PCI channels (number of the **Video capture card** objects) for all types of cards is given in Features of video subsystem configuration section.*




Figure 3.3-15 Creating the Relay objects under the Video capture card object

One can create up to 4 **Relay** objects under the **Video capture card** object. Configuring the **Relay** objects one is to specify the channel numbers of relay connection to 4/4 DI/DO card (low profile) according to external pinout of the card.

To change the channel numbers, use the **Channel Number** list in the settings panel of the **Relay** object.

4/4 DI/DO card (low profile) allows connecting up to 4 relay channels according to the license key file.

Figure 3.3-16 shows an example of the channel numbers configuration of 4 relays connected to one 4/4 DI/DO card (low profile).




Figure 3.3-16 Channel numbers configuration of 4 relays connected to one 4/4 DI/DO card (low profile)

The channels of the second (next) 4/4 DI/DO card (low profile) are numbered from 1 to 4.

3.3.4.2 Connecting sensors

Depending on what video capture card is used, the **Sensor** objects corresponding to sensors connected to 4/4 DI/DO card (low profile) are created under the **Video capture card** objects of one of the following types: FS 115, FX 4, FX 8 and FX 16 (Figure 3.3-17).

The **Sensor** objects are to be created under the **Video capture card** object that has the first PCI channel. E.g., building security video subsystem with the use of two FX4 and two DI/DO cards (low profile) the

Sensor objects are to be created under the **Video capture card** objects with **00** (for the first FX4 card) and **04** (for the second FX4 card) values of PCI channels.

*Note 1. For FX16 video capture card the **Sensor** objects can be created under the **Video capture card** object with **00** or **08** value of PCI channel. Working channel is discovered experimentally.*

*Note 2. Number of PCI channels (number of the **Video capture card** objects) for all types of cards is given in Features of video subsystem configuration section.*




Figure 3.3-17 Creating the Sensor objects under the Video capture card object

One can create up to 4 **Sensor** objects under the **Video capture card** object. Configuring the **Sensor** objects one is to specify the channel numbers of sensor connection to 4/4 DI/DO card (low profile).

4/4 DI/DO card (low profile) allows connecting up to 4 sensor channels according to the license key file.

To change the channel numbers, use the **Channel Number** list in the settings panel of the **Sensor** object.

Channels are numbered according to external pinout of the card. Figure 3.3-18 shows an example of the channel numbers configuration of 4 sensors connected to one 4/4 DI/DO card (low profile).




Figure 3.3-18 Channel numbers configuration of 4 sensors connected to one 4/4 DI/DO card (low profile)

The channels of the second (next) 4/4 DI/DO card (low profile) are numbered from 1 to 4.

3.3.5 Configuring SL USBIO card

3.3.5.1 Connecting relays

The **Relay** objects corresponding to relays connected to SL USBIO («4x4», «16x8», «24x4») card are created under the **Video capture card** objects of the **SL USBio** type (Figure 3.3-19).




Figure 3.3-19 Configuring the Video capture card object for SL USBIO («4x4», «16x8», «24x4») card

Configuring the **Relay** objects one is to specify the channel numbers of relay connection to the card. Channels are numbered according to external pinout of the card (see Appendix 6. Electrical and technical specifications of DI/DO cards).

To change the channel numbers, use the **Channel Number** list in the settings panel of the **Relay** object.

3.3.5.2 Connecting sensors

The **Sensor** objects corresponding to sensors connected to SL USBIO («4x4», «16x8», «24x4») card are created under the **Video capture card** objects of the **SL USBio** type (Figure 3.3-20).




Figure 3.3-20 Configuring the Video capture card object for SL USBIO («4x4», «16x8», «24x4») card

Configuring the **Sensor** objects one is to specify the channel numbers of sensor connection to the card. Channels are numbered according to external pinout of the card (see Appendix 6. Electrical and technical specifications of DI/DO cards).

To change the channel numbers, use the **Channel Number** list in the settings panel of the **Sensor** object.

3.3.6 Configuring MO USBIO 4x4 device

3.3.6.1 Connecting relays

The **Relay** objects corresponding to relays connected to MO USBIO 4x4 device are created under the **Video capture card** objects of the **MO USBio** type (Figure 3.3-21). One can create up to 4 **Relay** objects under the **Video capture card** object.




Figure 3.3-21 Configuring the Video capture card object for MO USBIO 4x4 device

Note. One is to specify the number of PCI channel that is not used by another object.

Configuring the **Relay** objects one is to specify the channel numbers of relay connection to MO USBIO 4x4 device. Channels are numbered according to external pinout of the device (see Connecting MO USBIO 4x4 external module or Connecting MO USBIO 4x4 cards sections).

To change the channel numbers, use the **Channel Number** list in the settings panel of the **Relay** object.

MO USBIO 4x4 device allows connecting up to 4 relay channels according to the license key file.

Figure 3.3-22 shows an example of the channel numbers configuration of 4 relays connected to one MO USBIO 4x4 device.




Figure 3.3-22 Channel numbers configuration of 4 relays connected to MO USBIO 4x4 device

The channels of the second (next) device are numbered from 1 to 4.

3.3.6.2 Connecting sensors

The **Sensor** objects corresponding to sensors connected to MO USBIO 4x4 device are created under the **Video capture card** objects of the **MO USBio** type (Figure 3.3-23). One can create up to 4 **Sensor** objects under the **Video capture card** object.




Figure 3.3-23 Configuring the Video capture card object for MO USBIO 4x4 device

Note. One is to specify the number of PCI channel that is not used by another object.

Configuring the **Sensor** objects one is to specify the channel numbers of sensor connection to MO USBIO 4x4 device. Channels are numbered according to external pinout of the device (see Connecting MO USBIO 4x4 external module or Connecting MO USBIO 4x4 cards sections).

To change the channel numbers, use the **Channel Number** list in the settings panel of the **Sensor** object.

MO USBIO 4x4 device allows connecting up to 4 sensor channels according to the license key file.

Figure 3.3-24 shows an example of the channel numbers configuration of 4 sensors connected to one MO USBIO 4x4 device.




Figure 3.3-24 Channel numbers configuration of 4 sensors connected to MO USBIO 4x4 device

The channels of the second (next) device are numbered from 1 to 4.

3.3.7 Configuring DI/DO (Stretch) cards

3.3.7.1 Connecting relays

One can connect up to 8 executive devices (relays) to one DI/DO (Stretch) card.

The **Relay** objects corresponding to relays connected to DI/DO (Stretch) card are created under the **Video capture card** objects of the **Stretch** type (Figure 3.3-25).




Figure 3.3-25 Creating the Relay objects under the Video capture card object of Stretch type

Configuring the **Relay** objects one is to specify the channel numbers of relay connection to the card. Channels are numbered according to external pinout of the card (see Connecting DI/DO (Stretch) section).

To change the channel numbers, use the **Channel Number** list in the settings panel of the **Relay** object.

3.3.7.2 Connecting sensors

One can connect up to 8 sensors to one DI/DO (Stretch) card.

The **Sensor** objects corresponding to sensors connected to DI/DO (Stretch) card are created under the **Video capture card** objects of the **Stretch** type (Figure 3.3-26).




Figure 3.3-26 Creating the Sensor objects under the Video capture card object of Stretch type

Configuring the **Sensor** objects one is to specify the channel numbers of sensor connection to the card. Channels are numbered according to external pinout of the card (see Connecting DI/DO (Stretch) section).

To change the channel numbers, use the **Channel Number** list in the settings panel of the **Sensor** object.

3.3.8 Configuring sensors and relays connected via IP devices

If relays are connected to Server via IP devices, then select the corresponding type of IP device on the setting panel of the **Video capture card** object; set IP address, name and password to connect to camera (see *Configuring IP devices* section).

*Note. If relays are connected to Server via Bosh IP device, then enter the **service** value in the **Name** field (Figure 3.3-27). With another value the functionality of the relay is not performed on Server.*




Figure 3.3-27 Configuring the Video capture card object of Bosch IP camera to connect relays

If Smartec STS-IPT-880 IP server is used, then sensors are to be connected to those channels that have the **Camera** objects. Channel with N number corresponds to 2 sensor channels with 2N-1 and 2N numbers.

Note. Smartec STS-IPT-880 IP Server supports up to 8 video channels and 16 sensors (2 sensors for each channel).

To connect each pair of sensors create the **Camera** object with N channel number, create two **Sensor** objects with 2N-1 and 2N numbers. The **Camera** and **Sensor** objects are created under one Video capture card object of the **Smartec** type. If sensors are connected via inactive video channel (no **Camera** object), then the functionality of sensors is not performed on Server.

To implement the functionality of sensors connected via AEBELL BL-E704F IP server disable the **Auto Work Plan** mode. Enabling/disabling of this mode is made via Web interface of IP server or in the dialog box of the **Network DVR Monitor System** utility (see the reference documentation on IP server).

3.4 Telemetry configuration

3.4.1 Use of PTZ devices in the digital video surveillance system

PTZ cameras in the digital video surveillance system are used to widen the video surveillance zone by mechanical rotating of the video camera.

The following interface elements of the INTELLECT™ software control the PTZ devices:

1. Surveillance monitor;
2. Telemetry control;
3. Telemetry control panel.

PTZ device control is performed with the help of the following:

1. Mouse and standard keyboard (when the **Surveillance monitor** and **Telemetry control panel** interface objects are used).
2. Specialized devices used for telemetry control, like telemetry remote control and joystick.

To manage simultaneous use of PTZ devices by different users, priorities of PTZ devices control must be set up for the following interface objects:

1. Surveillance monitor;
2. Telemetry control;
3. Telemetry control panel.

3.4.2 Priorities of PTZ control

The **PTZ control** or **Priority** parameter (depending on the type of the object) gives the privileges to control PTZ devices, when several interface objects are used or several users control the same PTZ device simultaneously.

To configure interface objects, used for PTZ control, the value of PTZ control priority should be selected from the list.

The **PTZ control** parameter is set for the following objects:

1. Surveillance monitor;
2. Telemetry control;
3. Telemetry control panel.

Note. The priority of PTZ control with joystick is equal to the priority of PTZ control with Surveillance monitor and mouse.

Priority parameter of PTZ control can be:

1. Control is forbidden (Forbidden). This item forbids PTZ control.
2. Low (Low priority). PTZ control is last in the queue after the “normal” and “high” priorities. It is the lowest in the queue in PTZ control.
3. Normal (Normal priority). PTZ is controlled after the device with “high” priority. It is higher in the queue in PTZ control than any device with “low” priority.
4. High (High priority). This item is set as first in the queue in PTZ control. It is highest in the PTZ control queue.

Contextual menu of selecting the PTZ control priority for the **Monitor** interface object is called **PTZ control** and consists of **Forbidden**, **Low priority**, **Normal priority** and **High priority** items (Figure 3.4-1):




Figure 3.4-1 The setting panel of the PTZ control parameter for the Monitor interface object

Panel of selecting the PTZ control priority for the **Telemetry control panel** interface object and **Telemetry remote control** system object is called **Priority** and consists of **Forbidden**, **Low priority**, **Normal priority** and **High priority** items (Figure 3.4-2):




Figure 3.4-2 The settings panel of the Priority parameter

If the same PTZ device is controlled from several workstations with the interface objects of the same type with the same PTZ control priority, then the following rules apply:

1. Any user can control a PTZ device, when it is not controlled by another user with the interface of the same control priority.
2. If a user with a higher priority interface object delegates control to a user with a lower priority interface object, then this procedure is delayed. The priority delay time is set with the help of the tweak.exe utility (Intellect tweaker).

To change the priority delay time using the tweak.exe utility, do the following:

1. Run the tweak.exe utility in the **Tools** folder of the INTELLECT™ software installation directory (Figure 3.4-3).
2. Select the **Telemetry** section (Figure 3.4-3, 1).




Figure 3.4-3 The Telemetry section of the tweak.exe utility

3. Enter the value of PTZ control priority delay in the **Priority delay (ms)** field (Figure 3.4-3, 2).

The delay parameter is given in milliseconds. The default value is 30000.

4. Click **OK** to save the changes (Figure 3.4-3, 3).

Note. When the objects are configured with variable PTZ priority controls it is recommended to assign different PTZ control priorities to different system objects (object types). If different system objects have the same PTZ control priority, problems may occur in operation, especially in controlling the PTZ devices.

3.4.3 PTZ device (telemetry) configuration

3.4.3.1 Sequence of PTZ device configuration

PTZ device configuration in the INTELLECT™ software consists of creation and configuration of system objects corresponding to the PTZ module, and user interface for PTZ device operation.

The user interface for PTZ device operation is represented by the following interface objects:

1. Telemetry control;
2. Operator window;
3. Surveillance monitor.

To configure PTZ devices and control panels do the following:

1. Configuration of Server ports for PTZ connection.
2. PTZ configuration.
3. Telemetry control panel configuration.
4. Telemetry control configuration.
5. Configuration of Operator window for telemetry control (PTZ devices of certain type).
6. Configuration of Surveillance monitor to control PTZ device with the help of mouse or joystick.

3.4.3.2 Configuration of Server ports and remote workplace for PTZ connection

PTZ devices are connected to the Server serial ports (COM). The INTELLECT™ software has the facility to plug in the required number of PTZ devices on demand.

Data exchange with a PTZ device is performed via the serial port (COM) in accordance with special protocol. Any type of PTZ devices has its own individual exchange protocol. Only one exchange protocol can be selected for data exchange via the serial port (COM). In this connection only one type of PTZ devices may be connected to one serial port (COM).

Configuration of several serial ports (COM) is performed in turn. Each type of serial ports (COM), used to connect the PTZ device, has the corresponding **Telemetry card** object, created and configured on the **Hardware** tab in the **System settings** dialog box.

To configure the serial port (COM) used for connecting PTZ devices of the same type, do the following:

1. Go to the **Hardware** tab in the **System settings** dialog box (Figure 3.4-4, 1).
2. Create the **Telemetry card** system object under the **Computer** object or select the corresponding object in the object tree on the **Hardware** tab in the **System settings** dialog box (Figure 3.4-4, 2).




Figure 3.4-4 The setting panel of the Telemetry card object

3. When the **Telemetry card** object is created, enter the ID, the name of the object and select Server to the COM port of which the PTZ device is connected (Figure 3.4-4, 3).
4. Select the protocol of data exchange with PTZ device from the list. The data exchange protocol names in this list correspond to the PTZ types (Figure 3.4-4, 4).
5. Select the serial port (COM) number from the **Port** list (Figure 3.4-4, 5).
6. If it is necessary change the data exchange speed (Figure 3.4-4, 6).

Note 1. Take into account that the data exchange speed via the COM port is specified by the vendor of PTZ device. The speed of data exchange with the PTZ device via the COM port must correspond to the speed specified by the vendor.

Note 2. If you need to change the COM port settings, change the relevant COM port settings in the Windows OS (for instructions on COM port configuration in the Windows OS see Appendix 4. Technical specifications of video capture cards).

7. If it is necessary change the parity check parameters for the data exchange (Figure 3.4-4, 7).
8. If PTZ devices are passive (i.e. with no independent power supply), the power supply of the PTZ devices must be activated via the DTR or RTS outputs of the COM port by setting the **DTR** or **RTS** check boxes (Figure 3.4-4, 8).
9. To save the changes click **Apply** (Figure 3.4-4, 9).

3.4.3.3 PTZ device configuration in the INTELLECT™ software

The number of PTZ devices connected to the videosever is stated in the activation key supplied with the INTELLECT™ software distribution kit.

Every PTZ device has the corresponding **Telemetry** system object in INTELLECT™ software. The **Telemetry** object is a child object relative to the **Telemetry card** object.

PTZ device configuration involves selection of the camera equipped with a PTZ device and setting of PTZ hardware addresses.

Configuration of several PTZ devices is performed in turn.

To configure PTZ devices do the following:

1. Go to the **Hardware** tab in the setting panel of INTELLECT™ (Figure 3.4-5, 1).
2. Create the **PTZ device** object under the **Telemetry controller** object or select the relevant object in the object tree on the **Hardware** tab in the **System settings** dialog box (Figure 3.4-5, 2).




Figure 3.4-5 The setting panel of the PTZ device

3. Enter the ID, the name of the **PTZ device** object and select the **Telemetry controller** object to which the PTZ device is connected (Figure 3.4-5, 3).
4. Select the ID of the camera equipped with a PTZ device (Figure 3.4-5, 4).
5. Select the name of the camera equipped with a PTZ device (Figure 3.4-5, 5).

Note. Enter either the video camera ID or its name.

6. If it is necessary to increase priority of a COM port specified in the settings of the **Telemetry controller** object, then set the **Send commands to local port** checkbox (Figure 3.4-5, 6). This parameter is used when, for ex., commands are sent not to COM port but to video capture card.
7. Enter the hardware address for the PTZ device in the **Address** field. The PTZ hardware address corresponds to the address set on the PTZ device with the help of bridges (jumpers) or configured while programming the PTZ device in the the supplied software (Figure 3.4-5, 7)
8. In the **Presets** table set checkboxes for presets names of which should be displayed on Telemetry control panel (see Telemetry panel configuration section). If it is necessary change the preset name (Figure 3.4-5, 8).

Note. In order to select all presets or cancel this operation, use the Select/Cancel checkbox.

9. To save the changes click **Apply** (Figure 3.4-5, 9).

3.4.4 Telemetry control panel configuration

The Telemetry control panel is used for PTZ device control. The **Control panel** system object is used for the **Telemetry control panel** hardware device registration in INTELLECT™ software.

To register and configure the **Control panel** object, do the following:

1. Go to the **Hardware** tab in the **System settings** dialog box (Figure 3.4-6, 1).
2. Create the **Control panel** system object under the **Telemetry card** object or select the relevant object on the **Hardware** tab in the **System settings** dialog box (Figure 3.4-6, 2).




Figure 3.4-6 The setting panel of the Control panel object

3. Enter the ID, the name of the **Telemetry** object and select the **Telemetry card** object to which the PTZ device is connected (Figure 3.4-6, 3).
4. Select the COM port number from the **Port** list in order to connect the **Control panel** device (Figure 3.4-6, 4).

*Note. The Control panel is connected to the COM port different from that to which the PTZ device is connected. Consequently on the settings panel of the parent (for the **Control panel** object) **Telemetry card** object, another COM port number must be specified.*

5. If it is necessary enter the speed of data exchange between the computer and the **Telemetry control panel** device (Figure 3.4-6, 5).
6. If it is necessary enter parity check parameters for the data exchange (Figure 3.4-6, 6).
7. If the **Telemetry control panel** device is passive (i.e. with no independent power supply), the power supply must be activated via the DTR or RTS outputs of the COM port by setting the **DTR** or **RTS** check boxes (Figure 3.4-6, 7).

*Note 1. The COM port speed and parity settings of the parent **Telemetry card** object do not relate to the similar settings of the **Control panel** object as they refer to another COM port.*

*Note 2. The **Speed** and **Parity** settings must correspond to the COM port settings in the Windows OS*

8. If it is necessary to change the PTZ device control priority for the **Telemetry control panel** device, select the relevant item from the **Priority** list (Figure 3.4-6, 8).
9. To save the changes click **Apply** (Figure 3.4-6, 9).

3.4.4.1 Features of BOSCH 12c-KBD-Digital control panel configuration and operation

3.4.4.1.1 Configuring BOSCH 12c-KBD-Digital control panel in INTELLECT™

To configure BOSCH 12c-KBD-Digital control panel in INTELLECT™ do the following:

1. Create the **Control panel** object.
2. Configure the **Control panel** object as follows (Figure 3.4-7):




Figure 3.4-7 Configuring the Control panel object for BOSCH 12c-KBD-Digital operation

- 2.1 Set the **Bosch-IntuiKey** interface protocol.
- 2.2 Select the **COM** port in the **Port** list.
- 2.3 Set **19200** value to the **Speed** parameter.
- 2.4 Set the **None** value for the **Parity** parameter.
- 2.5 Set the **DTR** and **RTS** checkboxes.
3. Create the **Control panel** system object under the **Telemetry card**.
4. Configure the **Control panel** object as the **Telemetry card**.

BOSCH 12c-KBD-Digital control panel is configured in INTELLECT™ software.

3.4.4.1.2 Features of BOSCH 12c-KBD-Digital control panel operation INTELLECT™ software

Attention! Before starting work with BOSCH 12c-KBD-Digital control panel in INTELLECT™ switch it to the Terminal mode. For this press the Prod key and select Terminal on the monitor.

Note. Detailed information on BOSCH 12c-KBD-Digital control panel is given in official reference documentation on this device.

Pressing the key on BOSCH 12c-KBD-Digital control panel in INTELLECT™ there is **Key is pressed** or **Key is released** message.

Table 3.4-1 Description of 'Key is pressed' and 'Key is released' messages

Event	Message	Parameter	Description
KEY_PRESSED	Key is pressed	param0	Code of pressed key
KEY_RELEASED	Key is released	param0	Code of released key

In the comments to these events the code (param0) of pressed and released key is specified (Table 3.4-2).

*Note. With long key pressing (more then 500 milliseconds) the **Key is pressed** event is repeated with 100 milliseconds interval. Releasing the key one **Key is released** message is received.*

Table 3.4-2 Key codes of BOSCH 12c-KBD-Digital control panel

Key	Key code	Key	Key code
SOFTKEY 1L	0x01	5	0x35
SOFTKEY 2L	0x02	6	0x36
SOFTKEY 3L	0x03	7	0x37
SOFTKEY 4L	0x04	8	0x38
SOFTKEY 5L	0x05	9	0x39
SOFTKEY 6L	0x06	MONITOR	0x20
SOFTKEY 7L	0x07	PRODUCT	0x21
SOFTKEY 1R	0x08	CLEAR	0x22
SOFTKEY 2R	0x09	IRISA	0x23
SOFTKEY 3R	0x0A	IRISB	0x24
SOFTKEY 4R	0x0B	ACK	0x25
SOFTKEY 5R	0x0C	ENTER	0x26
SOFTKEY 6R	0x0D	SHOT	0x27
SOFTKEY 7R	0x0E	FOCUSA	0x28
0	0x30	FOCUSB	0x29
1	0x31	SOFTKEY 4L + SOFTKEY 5L + SOFTKEY 5L	0x80
2	0x32	0 + 1	0x81
3	0x33	MONITOR + CLEAR	0x82
4	0x34		

The following special features are available for BOSCH 12c-KBD-Digital control panel:

1. **Paint figure** (set by **Figure**, **Type of painting**, **Paint figure**, **original Y-coordinate**, **end Y-coordinate**, **original X-coordinate**, **end X-coordinate** and **Screen**).
2. **Clear screen** (set by **Screen** parameter).
3. **Type text** (set by **X-coordinate**, **Y-coordinate**, **Coding**, **Style**, **Screen** and **Text** parameters).

Note 1. Bold text is displayed only on the status display.

Note 2. These actions are described in INTELLECT™ software . Programming Guide.

3.4.4.2 Features of Axis T8310 control panel configuration and operation

3.4.4.2.1 Configuring Axis T8310 control panel in INTELLECT™

To configure Axis T8310 control panel in INTELLECT™ do the following:

1. Create the **Control panel** object.
2. Configure the **Control panel** object as follows (Figure 3.4-7):




Figure 3.4-8 Configuring the Control panel object for Axis T8310 operation

- 2.1 Set the **Axis** interface protocol.
- 2.2 Select the **COM** port in the **Port** list.
- 2.3 Set **19200** value to the **Speed** parameter.
- 2.4 Set the **None** value for the **Parity** parameter.
- 2.5 Set the **DTR** and **RTS** checkboxes.
5. Create the **Control panel** system object under the **Telemetry card**.
6. Configure the **Control panel** object as the **Telemetry card**.

Axis T8310 control panel is configured in INTELLECT™ software.

3.4.4.2.2 Features of Axis T8310 control panel operation INTELLECT™ software

Note. Detailed information on Axis T8310 control panel is given in official reference documentation on this device.

Pressing the key on BOSCH 12c-KBD-Digital control panel in INTELLECT™ there is **Key is pressed** or **Key is released** message.

AXIS T8310 control panel is a modular system that consists of three devices:

1. AXIS T8311 joystick. This device has functionality of an ordinary joystick and it is configured as normal (see *Joystick configuration for telemetry control* section). The device also has 6 hot keys.
2. AXIS T8312 keyboard has 10 hot keys and 12 programmed keys.
3. AXIS T8313 Jog Dial has 6 hot keys and a navigation wheel.

Modules of AXIS T8310 control panel are connected to Server via the USB-interface. If complete AXIS T8310 control panel is used, then modules are connected to each other via AXIS T8312 keyboard (USB hub).

Functions of control panel related to pressing keys can be performed with the help of following:

1. scripts in JScript (see details of creating scripts in *INTELLECT™ software. Programming Guide (JScript)*);

2. programs in embedded language (see details in *INTELLECT™ software . Programming Guide*) ;
3. macros (see details in *INTELLECT™ software . Administrator's Guide, Creating and using macros* section).

Pressing the key on the keyboard of AXIS T8310 control panel in INTELLECT™ there is **Key is pressed** or **Key is released** message (Table 3.4-3).

Table 3.4-3 Description of 'Key is pressed' and 'Key is released' messages

Event	Message	Parameter	Description	Value range
KEY_PRESSED	Key is pressed	param0	Code of pressed key	0..21
		device	Device with pressed key.	0 - AXIS T8312 main keyboard, 1 - AXIS T8313 keyboard
KEY_RELEASED	Key is pressed	param0	Code of released key	0..21
		device	Device with released key	0 - AXIS T8312 main keyboard, 1 – AXIS T8313 Jog Dial

The **Cotrol panel** object (TELEMETRY_EXT) is the issuer of these events. In the comment to these events the code of pressed and released key is specified (Table 3.4-4).

Table 3.4-4 Key codes of AXIS T8312 control panel

Key	Key code	Key	Key code
0	0	Alt	11
1	1		12
2	2		13
3	3		14
4	4		15
5	5		16
6	6	F1	17
7	7	F2	18
8	8	F3	19
9	9	F4	20
	10	F5	21

When the position of AXIS T8313 joystick is changed then there is **Position is changed** message (Table 3.4-5).

Table 3.4-5 Description of Position is changed message

Event	Message	Parameter	Description	Value range
MOVED	Position is changed	param0	Offset value	JogDial -1.. 1; shuttle -7..7
		device	'AXIS T8313' type of control-gear	0 – JogDial, 1 – shuttle

The following special features are available for AXIS T8310 control panel:

1. Switch on relay (set by **Relay identifier** parameter). This command allows switching on the light on the key with light (12-16).

2. Switch off relay (set by **Relay identifier** parameter). This command allows switching off the light on the key with light (12-16).

Note. These actions are described in INTELLECT™ software . Programming Guide.

3.4.5 PTZ IP cameras configuration

Configuration of PTZ IP-cameras differs from that of other PTZ devices.

PTZ IP-cameras are connected via the local net with the TCP/IP transport protocol. Common communication protocol is used for all PTZ IP cameras.

To configure the **Telemetry card** object do the following:

1. Go to the **Hardware** tab in the **System settings** dialog box (Figure 3.4-9, 1).
2. Create the **Telemetry card** system object under the **Computer** object or select the relevant object on the **Hardware** tab in the **System settings** dialog box (Figure 3.4-9, 2).




Figure 3.4-9 The setting panel of the Telemetry card object

3. Enter the ID, the name of the **Telemetry card** object and select the Server connected via the COM port with the PTZ device (Figure 3.4-9, 3)
4. Choose the data exchange protocol from the list. To use TCP/IP protocol for the data exchange with a PTZ IP-camera, select **IP camera** as the protocol (Figure 3.4-9, 4).

*Note. When the **IP-camera** item is selected on the **Settings** panel of the **Telemetry card** object, the other settings cannot be changed.*

5. To save the changes click **Apply** (Figure 3.4-9, 5).

*Note. The **Telemetry** object configuration for PTZ IP camera control is the same as for control over PTZ devices when they are connected via the Server COM port.*

3.4.6 Telemetry panel configuration

Telemetry panel is an interface object for PTZ device control. The telemetry panel interface is the same for all PTZ devices.

To create and configure the Telemetry panel, do the following:

1. Go to the **Interfaces** tab in the **System settings** dialog box (Figure 3.4-10, 1).
2. Create the **Telemetry panel** object under the **Monitor** object or select the relevant object on the **Interfaces** tab in the **System settings** dialog box (Figure 3.4-10, 2).




Figure 3.4-10 The Telemetry panel configuration

3. Enter the ID, the name of the **Telemetry card** object and select the **Screen** object under which the **Telemetry card** object is created (Figure 3.4-10, 3).
4. Change the **X** and **Y** coordinates of the telemetry panel position on the screen in the relevant fields. The **X** and **Y** values correspond to the screen coordinates of the top left corner of the telemetry panel, and are expressed as a percentage of the horizontal and vertical screen sizes correspondingly (Figure 3.4-10, 4).
5. Enter the measures of the **Telemetry panel** interface object: the **W** (window width) and **H** (window height). Measures are expressed as a percentage of the horizontal and vertical screen sizes correspondingly (Figure 3.4-10, 5).

Note. The < button (Figure 3.4-10, 6) is used for automatic input of the current object coordinates specified by the user.

6. By default, the telemetry panel can be dragged over the screen. To fix the telemetry panel position, set the **Allow window's displacement** checkbox unchecked (Figure 3.4-10, 7).
7. By default, the telemetry panel is opaque. To display interface objects on the same screen with the telemetry panel, set the **Transparent** checkbox (Figure 3.4-10, 8).
8. If it is necessary to change the PTZ control priority via the **Telemetry panel**, select the relevant item from the **Priority** list (Figure 3.4-10, 9).
9. By default, the Operator is allowed to save the presets of PTZ device (presets of the camera position). To save presets, use the digital buttons on the **Presets** panel. To forbid the Operator to save the presets, set the **Allow set presets** checkbox unchecked (Figure 3.4-10, 10).
10. Set the **Allow hot key** checkbox if it is necessary to control PTZ device via the keyboard (Figure 3.4-10, 11).
11. Move the names of the cameras, equipped with PTZ devices, to the **Selected cameras** list. These cameras will be controlled by the **Telemetry panel** object. You can move the selected cameras

in turn, if you click the one-arrow button, or move all cameras, if you click the two-arrow button (Figure 3.4-10, 12).

12. Move the camera names from the **Selected cameras** list to the **Available cameras with telemetry control** list. These cameras will not be controlled by the **Telemetry panel** object. To move the selected cameras in turn, click the one-arrow button; to move all cameras, click the two-arrow button (Figure 3.4-10, 13).
13. To save the changes click **Apply** (Figure 3.4-10, 14).

3.4.7 Creation and configuration of the Operator dialog box for telemetry control

The INTELLECT™ software provides the PTZ control option with the help of the **Operator dialog box** interface object. The **Operator dialog box** interface object is a separate user dialog box with the relevant elements for a certain PTZ device type control.

The unique control panel is designed by the PTZ device vendor and is supplied together with the PTZ software. The files of the unique PTZ control panels are stored in the **Program** folder of the INTELLECT™ software installation directory.

To create and configure the Operator dialog box, do the following:

1. Open the **Programming** tab in the **System settings** dialog box (Figure 3.4-11, 1).
2. Create a **Macro** object under the **Macro** object on the **Programming** tab (Figure 3.4-11, 2). Enter the object ID and name.

*Note. The **Macro** object is necessary to refer to the INTELLECT™ software core and to display the Operator dialog box on the screen.*




Figure 3.4-11 The setting panel of the Macro object

3. Open the **Hardware** tab in the **System settings** dialog box (Figure 3.4-12, 3).
4. Create the **Operator dialog box** object under the **Computer** object on the **Hardware** tab (Figure 3.4-12, 4).




Figure 3.4-12 The setting panel of the Operator dialog box

5. Enter the file name (without extension) of the dialog box, used for PTZ device control, in the ID field (Figure 3.4-12, 5). The necessary files are stored in the **Program** folder of the INTELLECT™ software installation directory (Figure 3.4-13).




Figure 3.4-13 The Program folder of the INTELLECT™ software installation directory

6. To activate the moving option for the **Operator dialog box** object, set the **Allow moving** checkbox (Figure 3.4-12, 6).
7. Enter the **X** and **Y** coordinates of the **Operator dialog box** position on the screen in the relevant fields. The **X** and **Y** settings correspond to the screen coordinates of the top left corner of the **Operator dialog box** and are measured as a percentage of the horizontal and vertical screen sizes correspondingly (Figure 3.4-12, 7).
8. Select the type of the **Macro** objects from the objects and events list (Figure 3.4-12, 8).
9. Enter the ID of the **Macro** object, created to call up the **Operator dialog box** (Figure 3.4-12, 9).
10. The name of selected **Macro** object is automatically displayed in the **Name** column (Figure 3.4-12, 10).
11. Select the **Execute** item from the list of possible events (Figure 3.4-12, 11).

12. To save the changes click **Apply** (Figure 3.4-12, 12).

3.4.8 Configuration of the Monitor for telemetry control

The INTELLECT™ software has facilities to control PTZ devices via monitor windows, which correspond to the cameras with PTZ devices. In this case the PTZ device is controlled by the mouse via video surveillance windows of the PTZ cameras.

PTZ control function via the video surveillance windows, corresponding to the cameras with PTZ devices, is always activated and can't be disabled. To access PTZ control via the video surveillance window, do the following:

1. On condition that the equipment is functional, configure the **Telemetry** object related to the selected PTZ device.
2. Select the PTZ control priority for the video surveillance window in the settings of the **Monitor** object.

Additional configuration of telemetry control is not necessary.

3.4.9 Joystick configuration for telemetry control

3.4.9.1 Joystick configuration procedure

If the joystick is connected to the Server and is configured in Windows OS, then the INTELLECT™ software automatically activates the joystick telemetry control option. The option is valid for all PTZ devices, connected to the Server and configured in INTELLECT™ software.

Generally the joystick configuration includes the following stages:

1. Testing joystick handle performance in INTELLECT™ software. This procedure is described in the *Testing joystick performance* section.
2. Configuration of issuing the command to PTZ devices with joystick keys. For configuration instructions see the *Assignment of the commands to joystick keys for telemetry control* section.
3. Testing joystick keys performance in INTELLECT™ software. The procedure is similar to testing joystick handle performance. For a detailed description see the *Testing joystick performance* section.

The following functions are available by default and do not require additional configuration:

1. Rotation of cameras equipped with PTZ devices is performed by inclination of a joystick handle;

*Note. Joystick threshold corresponds to the **Joystic Threshold** line parameter and is set at the HKLM\SOFTWARE\ITV\Intellect\Telemetry register of the Windows OS. By default Joystic Threshold=1, this parameter possesses the value from 0 and more. The more the value, the less sensitive the joystick is, best value is selected empirically.*

2. The image shrinkage function from cameras is performed by turning a joystick handle around its vertical axis.

The image shrinkage function is available only for joysticks with Z axis, as for example Axis 295. This axis is formed by joystick handle's angles of rotation.

Z axis is activated by default and corresponds to value of the **Zenable=1** line parameter at the HKLM\SOFTWARE\ITV\INTELLECT\Telemetry register of the Windows OS.

Attention! Coordinate of joystick Z axis should be automatically zeroized after every image shrinkage operation for correct telemetry control. Otherwise Z axis should be disconnected by setting the *Zenable=0* parameter in the *HKLM\SOFTWARE\ITV\INTELLECT\Telemetry* section.

Note. Z axis should be disconnected when the Logitech USB joystick is used.

3.4.9.2 Testing joystick performance

Before you configure and use a joystick to control PTZ devices, test its performance in INTELLECT™ software.

To test the joystick performance in INTELLECT™ software, do the following:

1. Make sure that PTZ devices are connected, configured and operate properly in INTELLECT™ software.
2. Display the video surveillance monitor on the screen.
3. Check if cameras equipped with PTZ devices are displayed on the video surveillance monitor. If not, change the video surveillance windows layout .
4. Activate the selected camera surveillance window by left clicking it.
5. Display the telemetry module debug window. To display the telemetry module debug window, left double click the window icon in the notification zone of the Windows OS menu (Figure 3.4-14).



Figure 3.4-14 Telemetry module debug window icon

6. As a result the telemetry module debug window is displayed (Figure 3.4-15).




Figure 3.4-15 Telemetry module debug window

7. To test the joystick handle, rotate it in different directions.
8. To check the joystick push-buttons performance, click them in turn.

9. If the joystick operates properly, the relevant commands are displayed in the debug window (Figure 3.4-16).




Figure 3.4-16 Telemetry module debug window after the performance of joystick commands

10. If there are no commands in the debug windows, then the joystick does not operate in INTELLECT™ software. Check its connection to the computer and its data exchange driver settings in the Windows OS.

The joystick performance test is completed.

3.4.9.3 Assignment of the commands to joystick keys for telemetry control

Certain commands are assigned to the joystick push-buttons in order to issue default commands to PTZ devices.

To assign the commands to joystick push-buttons, the Windows OS registry is edited.

Below there is a short list of actions to be carried out for configuring the joystick push-buttons. For detailed information on operation of the Windows OS registry see Appendix 4.

To assign the commands to the joystick push-buttons in the Windows OS registry, do the following:

1. Open the **TELEMETRY** folder of the registry **HKEY_LOCAL_MACHINE** ⇒ **SOFTWARE** ⇒ **ITV** ⇒ **Intellect** branch.
2. Add a line parameter to the **TELEMETRY** folder.
3. Assign the name to the line parameter, identical to the number of the joystick push-button in the Windows OS (Figure 3.4-17).




Figure 3.4-17 An example of editing the Windows OS registry for assigning the commands to joystick push-buttons

Note. To define the numbers of the joystick push-buttons in the Windows OS, use the **Game devices** application. For more information see the **Joystick connection and test** section.

4. Assign the value to the line parameter, identical to the name of the command executed by the PTZ device in the INTELLECT™ software (the value is to be entered in the uppercase). Available commands in the INTELLECT™ software are listed in Table 3.4-6:

Table 3.4-6 Command symbols

Symbol	Command
AUTOFOCUS_ON	Activate the autofocusing option.
AUTOPAN_END_P	Set the autopan endpoint.
AUTOPAN_START	Start the autopan.
AUTOPAN_START_P	Set the autopan start point.
AUTOPAN_STOP	Stop the autopan.
CLEAR_PRESET	Clear the selected preset.
D2OFF	Disable additional dynamic settings for Panasonic PTZ cameras for improving an analog video signal.
D2ON	Enable additional dynamic settings for Panasonic PTZ cameras for improving an analog video signal.
DOWN	Rotate the camera lens down.
FOCUS_IN	Focusing the image in.
FOCUS_OUT	Focusing the image out.
FOCUS_STOP	Stop focusing the image in/out.

Symbol	Command
GO_PRESET.N	Rotate the video camera to the position set in N preset.
HOME	Rotate the video camera to the initial (home) position.
IRIS_CLOSE	Close the iris diaphragm.
IRIS_OPEN	Open the iris diaphragm.
IRIS_STOP	Stop the iris diaphragm.
LEFT	Rotate the camera lens left.
LEFT_DOWN	Rotate the camera lens left and down.
LEFT_UP	Rotate the camera lens left and up.
PATROL_LEARN	Start the programming procedure of patrolling by learning the video camera behavior.
PATROL_PLAY	Start patrolling.
PATROL_STOP	Stop patrolling.
RIGHT	Rotate the camera lens right.
RIGHT_DOWN	Rotate the camera lens right and down.
RIGHT_UP	Rotate the camera lens right and up.
SET_PRESET	Save the current position of the video camera in the selected preset.
STOP	Stop the the camera lens rotation.
UP	Rotate the camera lens up.

Repeat steps 2-4 for each joystick push-button to which the command is assigned.

Note. Some PTZ devices do not react to commands by the joystick push-buttons used for video camera rotation. In this case you can rotate a video camera with a joystick handle.

Configuration of the joystick push-buttons is completed.

4 Conclusion

Please send your comments or requests concerning this Guide to the AxxonSoft Training and documentation development division at (documentation@itv.ru).

Axxon Soft Inc., Beryozovaya alleya, building 5, section 5a, Moscow, Russia, 127273

Tel/fax: (495) 775-29-29

www.axxonsoft.com

5 Appendix 1. Features of video capture card configuration

5.1 Drivers for video capture cards integrated into the INTELLECT™ software

Drivers for video capture cards integrated into the INTELLECT™ software are in the **Drivers** folder of the INTELLECT™ installation directory (e.g., C:\Program Files\Intellect\Drivers). Structure of the **Drivers** folder is given in Table 5.1-1.

Table 5.1-1 Structure of the Drivers folder

Directory	Drivers for video capture cards
ITV\Fs5_6_8_16	FS5, FS6, FS8, FS16, FX2
ITV\FX116_416	FX116, FX416
ITV\Ws6	WS6
ITV\Ws7	WS7, WS17
TUAN\TW6802	FS15, FS115, FX4, FX8
TUAN\CX2581	FX16
TUAN\AH8400	WS16
TUAN\TW5864	WS216
TUAN\SA7160	FX HD4

Note 1. Drivers for Stretch (VRC6004, VRC6008, VRC6416, VRC7008L and VRC6404HD) video capture cards are in the **C:\Program Files\Common Files\AxxonSoft\Drivers\Stretch\x86** directory.

Note 2. Drivers for HikVision DS-4016HCI(R) video capture card are in the **c:\Program Files\Common Files\AxxonSoft\Drivers\HikvisionBoard\x86** directory (**c:\Program Files (x86)\Common Files\AxxonSoft\Drivers\HikvisionBoard\x64** for 64-bit system).

5.2 Features of video subsystem configuration

Features of video subsystem configuration are given in Table 5.2-1.

Table 5.2-1 Features of video subsystem configuration

Video capture card	Number of the Video capture card objects for one physical card	Maximum number of the Camera objects for one Video capture card object	Distribution of channel numbers between the Camera objects	Number of the Camera objects (in live mode) for the Video capture card object
FS5	1	16	1-16 (for each physical card)	1
FS6	4	4	1-16 (for each physical card)	1
FS16	4	4	1-16 (for each physical card)	1
FS8	8	2	1-16 (for each physical card)	1
FX2	2	4	1-8 (for each physical card)	1

Video capture card	Number of the Video capture card objects for one physical card	Maximum number of the Camera objects for one Video capture card object	Distribution of channel numbers between the Camera objects	Number of the Camera objects (in live mode) for the Video capture card object
			card)	
FS15	1	4	1-4 (for each physical card)	1
FS115	1	4	1-4(for each physical card)	1
FX4**	4	4	1-4 (for each Video capture card object)	1
FX8**	8	2	1-2 (for each Video capture card object)	1
FX16	16	1	randomly	1
WS6	4	1	randomly	1
WS7	4	1	randomly	1
WS16	16	1	randomly	1
WS17	4	1	randomly	1
WS216	16	1	randomly	1
FX116	1	16	1-16 (for each physical card)	8
FX416	1	16	1-16 (for each physical card)	16
Stretch (VRC6004)	1	4	1-4 (for each physical card)	4
Stretch (VRC6008)	1	8	1-8 (for each physical card)	8
Stretch (VRC6416)	1	16	1-16 (for each physical card)	16
Stretch (VRC7008L)	1	8	1-8 (for each physical card)	8
Stretch (VRC6404HD)	1	4	1-4 (for each physical card)	4
DS4016HCI(R)	1	16	1-16 (for each physical card)	16
FX HD4*	4	1	randomly	1

*PCI channels are to be distributed between the **Video capture card** objects created for FX HD4 video capture card, taking into account the numbers of external HDMI connectors indicated on the card.

** When a video subsystem is built using FX4 or FX8 video capture card, be aware that each color of BNC video input of interface cable conforms with a certain PCI channel specified in the settings of the Video capture card object (Table 5.2-2).

Table 5.2-2 Conformity of a colour of BNC video input with a PCI channel

Value of PCI channel	Colour of BNC video input
00	Blue
01	Green
02	Yellow
03	Black
2nd interface cable	
04	Blue
05	Green
06	Yellow
07	Black

For example, if one FX4 video capture card is used and video cameras are connected to blue BNC video inputs, then the **Camera** objects based on the **Video capture card** object correspond to these video cameras (with 00 value for PCI channel) in the INTELLECT™ system.

5.3 Features of audio subsystem configuration

Features of audio subsystem configuration are given in Table 5.3-1.

Table 5.3-1 Features of audio subsystem configuration

Video capture card	Number of the Audio card objects for one physical card	Maximum number of the Microphone objects for one Audio card object	Distribution of channel numbers between the Microphone objects based on one Audio card object
FS5 (FS 6)	1	2	#0 - #1
FS6 (FS 6)	4	2	#0 - #1
FS16 (FS 6)	4	2	#0 - #1
FS8 (FS 8)	8	2	#0 - #1
FX2 (FS 6)	2	2	#0 - #1
FS15 (TW6802 PCI, Analog WaveIn)	1	1	only #0
FS115	1	1	only #0
FX4 (TW6802 PCI, Analog WaveIn)	4	1	only #0
FX8 (TW6802 PCI, Analog WaveIn)**	8	1	only #0
FX16 (CX2581 PCI, Analog WaveIn)	16	1	only #0
WS6 (WS 6)	4	2	#0 - #1
WS7 (WS 7)	4	2	#0 - #1
WS16 (AH8400 PCI, Analog WaveIn)	16	1	only #0
WS17 (WS 7)	4	2	#0 - #1
WS216 (TW5864 PCI, Analog WaveIn)	16	1	only #0
FX116 (SLFXR)	1	16	#0 - #15

Video capture card	Number of the Audio card objects for one physical card	Maximum number of the Microphone objects for one Audio card object	Distribution of channel numbers between the Microphone objects based on one Audio card object
FX416 (SLFXR)	1	16	#0 - #15
Stretch (VRC6008)	1	8	#0 - #7
Stretch (VRC6416)	1	16	#0 - #15
Stretch (VRC7008L)	1	8	#0 - #7
FX HD4 (SA7160 PCI, Analog WaveIn)*	4	1	only #0

* PCI channels are to be distributed between the **Audio card** objects created for FX HD4 video capture card, taking into account the numbers of external HDMI connectors indicated on the card.

** FS8 video capture card allows capturing 16 audio channels with digitization quality up to 32 kHz. Eight right (#1) channels are used to connect to external DB9-M slot (Figure 5.3-1).




Figure 5.3-1 Pinout of a sound port of FS8 card

Eight left (#0) channels are used to connect to internal 6-pin connector (Figure 5.3-2) using 8-channel audio cable (Figure 5.3-3).




Figure 5.3-2 FS8 card with audio cable




Figure 5.3-3 Pinout of a sound port of an audio cable

Optionally there is an adapter for DB9-M connector (audio input port on FS8 card) with 8 RCA-F connectors that make audio source connection easier.

Attention! Signs in audio cable connectors do not conform with numbers of card channels. Right channels are performed in DB9 connector (Figure 5.3-2), left channels are performed in DB9 cable (Figure 5.3-3).

Table 5.3-2 Channels in DB9 connector

Sign in audio cable connector	Number of a card channel
1R	1R
2R	3R
3R	5R
4R	7R
1L	2R
2L	4R
3L	6R
4L	8R

Table 5.3-3 Channels in DB9 cable

Sign in audio cable connector	Number of a card channel
1R	1L
2R	3L
3R	5L
4R	7L
1L	2L
2L	4L
3L	6L
4L	8L

6 Appendix 2. IP-device configuration in the Windows OS

6.1 Configuration of IP-devices by the example of Axis camera

IP-devices in Windows OS are configured with the software supplied with the network module.

To configure the IP-device in Windows OS, the following software supplied with the device is used:

1. software included into the package supplied with the network device. This software allows:
 - 1.1. searching for the network devices connected to the local network computers.
 - 1.2. assigning initial IP-addresses (without routing).

Note. An initial IP-address is required to enable access to the home pages of the devices installed in the embedded Web-servers.

2. The Web-server module of the network device. This module contains home pages of all connected network devices. The Web-server module allows the following:
 - 2.1. configuring network devices including routing.
 - 2.2. configuring modes of operation of the network devices with video and audio signals.
 - 2.3. playback of the video image from the network devices in the standard Web-browser mode.

6.1.1 Search for IP-devices

The delivery set of the network devices consists of various software including different utilities designed to search for the network devices of the same type connected to the local network computers.

IPUtility.exe utility is used when Axis cameras are used to search for connected network cameras. IPUtility.exe is a part of delivery set of Axis cameras and is stored in the Axis installation software directory.

To search for Axis IP-cameras connected to the local network computers, using the IPUtility.exe utility, do the following:

1. Select **Search** in the IPUtility.exe tools panel (Figure 6.1-1).




Figure 6.1-1 The IPUtility.exe interface window. The Search button

The search for Axis IP-cameras starts as soon as the Search button is clicked.

2. The IPUtility.exe window displays a list of Axis IP-cameras available in the local network (Figure 6.1-2).




Figure 6.1-2 Example of search result for the network Axis cameras

6.1.2 Assigning network addresses to IP devices

To ensure correct operation of the network devices within the local video surveillance system, their IP-addresses are to be configured correctly. IP-addresses are configured using the utilities included into the software distribution kit.

Before assigning an IP-address to the Axis network surveillance camera, do the following:

1. Make sure that the Axis network camera is connected to the mains and correctly connected to the telecommunication network.
2. Get a unique IP-address from the Network administrator.
3. Make sure that the device displays its own MAC-address correctly. The MAC-address of Axis cameras corresponds to the serial number of the camera.

Note 1. The following examples use a computer with 192.168.0.1 IP-address, whereas an Axis camera is installed to 192.168.0.90 IP-address. The MAC-address for an Axis camera is 00408C70D7DE. The addresses given as an example are not to be used; always consult your network administrator before assigning an IP-address.

Note 2. Selecting an IP-address to be assigned to an IP-camera, keep in mind that the initial IP-address of the camera connected for the first time is to correspond to the same subnetwork as the IP-address of computer. Later on, if required, the IP-address can be modified using the Web-server of the device.

To assign an IP-address to the Axis network camera, do the following:

1. Check that the IP-address to be assigned to the Axis network camera is not used by any other devices.

The IP-address in Windows OS is checked using the command line. To display the command line on the monitor select the **Run** command in the **Start** menu (Figure 6.1-3).



Figure 6.1-3 The Run command selected from the Start menu

Now enter the **cmd** command in the **Open** field of the **Run** dialog box and click **OK** to confirm the entry (Figure 6.1-4).




Figure 6.1-4 Command line window

As a result the command line is displayed on the monitor (Figure 6.1-5).




Figure 6.1-5 Command line

To check the selected IP-address enter the **ping 192.168.0.90** command in the command line window. If the given IP-address does not belong to any other device, then the monitor displays the following message: "Request timed out" (Figure 6.1-6).




Figure 6.1-6 The message: "Request timed out"

2. Assign the required IP-address to the Axis camera. To assign the selected IP-address, do the following:
 - 2.1. Start the **IPUtility.exe** utility.
 - 2.2. Start searching for all Axis IP-cameras (see *Search for IP-devices* section).
 - 2.3. Highlight the line containing the required IP-camera in the list of Axis IP- cameras connected to the local network.
 - 2.4. Select **Set IP Address** in the **Server** dropdown list in the main menu of the **IPUtility.exe** utility (Figure 6.1-7).




Figure 6.1-7 Set IP Address in the Server dropdown list in the main menu of the IPUtility.exe utility

2.5. Enter the required IP-address in the **Set IP Address** panel (Figure 6.1-8).




Figure 6.1-8 Entering the required IP-address in the Set IP Address dialog box

2.6. Confirm the IP-address assigned to the Axis network camera by clicking **Set IP** (Figure 6.1-8).

As soon as the above operations are done, IP-address settings of the network device are enabled.

Note. To prevent possible failures of the camera, check the assigned IP-address again.

3. Check the IP-address assigned to the Axis network camera.

*Note. The IP-address is checked with the use of the command line (see 1st item of this instruction). If the IP-address is set correctly, then following message should be displayed in the command line window in reply to the **ping 192.168.0.90** command (Figure 6.1-9).*




Figure 6.1-9 Reply to the ping 192.168.0.90 command

Now the process of assigning an IP-address to the Axis camera is complete. If assignment of the IP-address to the Axis camera is successful, then proceed to the network configuration of the device using the embedded Web-server.

6.1.3 How to call the Web-server home page of IP device

The home page of a network device is automatically created on the Web-server of the network device, as soon as an IP-address is assigned to the device by the IPUtility.exe utility (see *Assigning network addresses to IP devices* section).

To load a home page of a network device, do the following:

1. Start Internet Explorer.

Enter the address in the **Address** line: `http://assigned IP-address` (for instance, `http://192.168.0.90`) and click **Enter** (Figure 6.1-10).




Figure 6.1-10 Entering the IP-address of the network camera

2. Enter a user name and password to access a home page of a network device. The data entered in the **User name** and **Password** fields can be found in the documentation to the add-on network device (Figure 6.1-11).




Figure 6.1-11 User name and password dialog box for access a home page of a network device

Click **OK** after entering a user name and password.

3. The monitor displays the surveillance window of the IP-camera, if a network camera is used, or one of the analog cameras connected to the network server, if a network server is used (Figure 6.1-12).




Figure 6.1-12 Surveillance windows displaying an image of an IP camera or one of analog cameras connected to the network server

Note. If an IP-camera gives no image, check if the IP-address is assigned correctly (see Assigning network addresses to IP devices section).

6.1.4 Configuration of network parameters for IP-devices using the Web-server

Network parameters of the IP-devices are configured via the embedded Web-server of the network device.

Note. Configuration of the network parameters for IP-devices using the Web-server is a compulsory procedure.

To configure IP-devices for operations in the local network that is either equipped or non-equipped with the routers, do the following:

1. Start Internet Explorer.
2. Open a home page of the network device (see *How to call the Web-server home page of IP device* section).
3. Open the **Setup** section in the Web-server feature menu of the Web browser home page (Figure 6.1-13).




Figure 6.1-13 The Setup section in the Web-server feature menu of a network device

4. Select the **TCP/IP** tab in the **Setup** section.

Enter the **IP-address**, **Subnet mask** and **Default router** in the given tab. To confirm the settings click **Save** (Figure 6.1-14).




Figure 6.1-14 Network settings for IP devices

In the **IP address** field enter the assigned IP-address of the network device (see *Assigning network addresses to IP devices* section).

In the **Subnet mask** field enter the mask of the subnet to which the network device is connected.

Entering data in the **Default router** field, the following should be taken into consideration:

- 4.1. If the Server and IP-camera are installed in the same subnetwork, then the **Default router** parameter is not to be specified (Figure 6.1-15).




Figure 6.1-15 Server and IP-camera are in the same subnetwork

4.2. If the Server and IP-camera are installed in different subnetworks, then the **Default router** parameter is to be specified (Figure 6.1-16).




Figure 6.1-16 Server and IP-camera are in different subnetworks

4.3. The IP-address of the default router is to match the subnetwork that the IP-address of the camera belongs to.

Note. The camera is inoperative if the IP-address of the router is wrong or not specified at all (Figure 6.1-17).




Figure 6.1-17 The IP-address of the router is not specified (no connection)

5. Select **System Options / Ports & Devices / RS232** tab in the **Setup** section.

Select **Pan Tilt Zoom** in the **Port 1 Usage** field to show that the given interface is used for telemetry. To confirm the settings click **Save** (Figure 6.1-18).




Figure 6.1-18 Configuration of telemetry parameters for IP-devices

Configuration of the network parameters for the IP-devices is completed.

Now proceed to the configuration of IP-devices in the INTELLECT™ software.

6.2 Features of configuring Axis IP-device

It is strongly recommended to keep the value by default of the **Friendly name** parameter unchanged for Axis IP-device with enabled and supported *Bonjour* function. If there is an arbitrary value of the **Friendly name** parameter for Axis IP-device, then search for a connected device in the INTELLECT™ software will give incorrect results concerning this IP-device.

*Note1. The **Friendly name** parameter is configured via the Web-interface of IP-device: Setup -> System options -> Network -> Bonjour.*

*Note2. The **Friendly name** parameter has the following value by default: AXIS <model name> - <mac address>, where <model name> is model of Axis IP-device and <mac address> is its MAC-address (for example, AXIS 214 - 00408C7D2610).*

6.3 Features of configuring IP-devices using the Web-interface

Note. Features of configuring IP-devices using the Web-interface are given in reference manual to corresponding devices.

6.3.1 Features of configuring Panasonic IP-devices (i-Pro series) using the Web-interface

If a Panasonic IP device (i-Pro series) is configured to simultaneous transmission of video streams in MJPEG and MPEG-4 formats, then video stream rate in MJPEG format is limited by 5(10) fps.

Note. WV-NP1000\1004, WV-F284, WV-NP240\244, WV-NS202 and other models belong to IP devices of i-Pro series.

6.3.2 Features of configuring Samsung IP-devices using the Web-interface

An audio input gain for Samsung SNC-B2315 IP device is configured using **Setup ⇒ Video & Audio Configuration ⇒ Input Gain**. By default the **Input Gain** parameter equals 0 and audio signals are not played back by IP-device. To play back audio signals select the value of the **Input Gain** parameter from 1 to 10 depending on the required audio input gain.

Samsung SNC-M300P IP –device supports two-stream mode of video compression in MJPEG and MPEG-4 formats. If the value 25fps is selected for the frame rate of MJPEG-video stream (the **Frame Rate** parameter) then the range of values of analog parameter for MPEG-4 format is restricted by 3fps. To extend the given rate the value less than 25fps for the **Frame Rate** parameter of MJPEG-video stream is to be selected.

6.3.3 Features of configuring Mobotix IP-devices using the Web-interface

Resolution of Mobotix MX-Q22M-Sec-D11 panoramic camera is determined by selected mode of video displaying (**Display Mode**) on the **Setup Menu** tab (Table 6.3-1).

Table 6.3-1 Dependence of resolution from the video display mode

Display Mode	Resolution
Full Image	2048*1536
Normal	1456*1088
Surround	1456*1088
Panorama	2048*768
Double Panorama	1456*1088
Focus Panorama	1456*1088

*Note. In the **Double Panorama** mode the screen is divided by horizontal line into equal areas, each of which displays a panoramic video.*

As a Mobotix MX-Q22M-Sec-D11 camera is panoramic, proportions are distorted in the INTELLECT™ software. The **Normal** mode is recommended to be installed for correct video displaying.

6.3.4 Features of configuring Sony IP-devices using the Web-interface

The **Light Funnel** function is used for sensitivity enhancement of Sony SNC-CM120 IP-device. Access to settings of this function is on the **Setting -> Camera -> Sense up** tab.

Enabling the **Light Funnel** option leads to changing the range of values of the following settings in the INTELLECT™ software (Table 6.3-2):

1. Videostream rate;
2. Video resolution (in MJPEG format).

Table 6.3-2 Configuring INTELLECT using the 'Light Funnel' option

Setting in the INTELLECT™ software	Implementation of a setting in the INTELLECT™ software	Range of values	
		The Light Funnel is disabled	The Light Funnel is enabled
Videostream rate	The Speed slider on the setting panel of the Video capture card object	No more than 10fps	Up to 30 fps
Video resolution (in MJPEG	The Resolution	Full (1280*960)	Standard (640*480)

Setting in the INTELLECT™	Implementation of a	Range of values	
format)	dropdown list on the setting panel of the Camera object	High (960*720) Standard (640*480)	

Example. If a full resolution is set with enabled **Light Funnel** function, then the video is displayed in a standard resolution.

7 Appendix 3. Installing the Matrix Linux Server and LinuxHub

7.1 Introduction

Matrix is a specialized hardware/software platform for building the integrated security systems based on digital surveillance systems.

Matrix Linux Server (LS) and Matrix LinuxHub (LH) are the hardware/software video commutators used for receiving, processing (analog-to-digital conversion) and transferring video images via IP-networks. LS and LH work under the Linux OS (kernel 2.6). A LH is shown in Figure 7.1-1.



Figure 7.1-1 Matrix LinuxHub

There are two basic configurations of LS (LH):

1. Based on FS5 video capture card;
2. Based on FS6 or FS16 video capture cards;
3. Based on FX4 video capture card;
4. Based on FX8 video capture card;
5. Based on FX16 video capture card.

The main technical specifications of LS (LH) depend on the specifications of video capture cards. LS (LH) is used in conjunction with Intellect-based systems. Remote access to LS (LH) is available through the Web interface.

LH/LS functionality:

1. Enclosed in desktop casing of microATX type (FS6 card) and Mini-ITX type (FS5 card) or 1u type that can be fixed or installed in the computer cabinet (FX4, FX8 and FX16 cards).
2. Watchdog hardware system for system failure prevention.
3. Flash memory used for holding the operating system.
4. Telemetry devices connection.
5. External storage connection for storing video recordings from surveillance cameras (LS only).
6. External devices connection to the embedded sensor-relay module – 4/4 for FS5, FX4, FX8 and FX16 and 4/16 for FS6/16 (optional).
7. Possibility for remote firmware update.
8. No local videostream display (monitor connected directly to LS (LH) for viewing the video received from the cameras).

Figure 7.1-2 shows a general structural diagram of the digital video surveillance system based on the Matrix hardware/software platform.




Figure 7.1-2 General structural diagram of the digital video surveillance system based on the Matrix hardware/software platform

7.2 Installing the Linux Server (LinuxHub)

7.2.1 Introduction

The LS/LH installation and configuration include the following stages:

1. Connecting and running the LS (LH). This stage is common to LS and LH.
2. Network identification of the LS (LH). This stage is common to LS and LH.
3. Configuration of the LS (LH) for the INTELLECT™ operation. This stage is different for LS and LH.

7.2.2 Connecting and running the Linux Server (LinuxHub)

This stage includes the following:

1. To connect the LS (LH) to the local network, plug the network cable into the network socket and the corresponding LAN socket in the LS (LH).
2. To connect the LS (LH) to the power supply, plug the power cable into the 220 V mains and the corresponding power plug on the back panel of the LS (LH).
3. To turn the LS (LH) on, press the power button on the front panel of the LS (LH).
4. Wait for the LS (LH) system to load. It usually takes no more than one minute.

Note. Running the LS after incorrect unloading there is a check of hard disks for errors that can take much time (depends on archive size).

7.2.3 Network identification of the Linux Server (LinuxHub)

This stage includes the following steps:

1. Run the **Search for IP devices** utility included in the INTELLECT™ installation kit. To run the utility from Windows click **Start => All Programs => Intellect => Tools => Search for IP devices**.
2. Select the network adapter through which your computer is connected to the LAN to which the LS (LH) is connected (the **Select NetAdapter** drop-down list) and click **Search** (Figure 7.2-1).

HubSearch

NetAdapter Info

Select NetAdapter: Realtek RTL8168/8111 PCI-E

IP: 192.168.247.1

Mask: 255.255.255.0

MAC: 00:1B:FC:88:86:E1

VideoHub Addresses

No VideoHub Devices

VideoHub Properties

☒ Use DHCP

☐ Use the following IP address

IP address: . . .

Subnet mask: . . .

Default gateway: . . .

Device description

Apply

Net BIOS Name

Apply

Search status: No search

Search Close

Figure 7.2-1 Selecting the network adapter

3. The system will search for all LSs and LHs connected to this local network (Figure 7.2-2). The **Search status** field will read **Search. Please, wait** during the search process.

The HubSearch application window is divided into several sections:

- NetAdapter Info:** Contains a dropdown menu for "Select NetAdapter:" set to "Realtek RTL8168/8111 PCI-E", and three text fields for "IP:" (192.168.247.1), "Mask:" (255.255.255.0), and "MAC:" (00:1B:FC:88:86:E1).
- VideoHub Addresses:** A list box currently displaying "No VideoHub Devices".
- VideoHub Properties:** Contains two radio buttons: "Use DHCP" (selected) and "Use the following IP address". Below these are three text fields for "IP address:", "Subnet mask:", and "Default gateway:", each with a dotted placeholder. To the right is a "Device description" label and two empty text fields. An "Apply" button is at the bottom right of this section.
- Net BIOS Name:** A single text field with an empty space and an "Apply" button to its right.
- Search status:** A text field displaying "Search. Please, wait.".
- Buttons:** "Search" and "Close" buttons are located at the bottom of the window.

Figure 7.2-2 Searching for LS and LH

- After the search is completed, the **Search status** field will read **Stop search. Find...**. The found devices will be added to the **VideoHub Addresses** list. Select the required LS (LH) from the list. The **VideoHub Properties** field will display the information on the selected device (Figure 7.2-3).





Figure 7.2-3 Search results for LS and LH

5. Some of the parameters of the selected device can be edited (IP-address, subnet mask, default gateway and NET BIOS name). To edit the NETBIOS name, change the value in the Net BIOS Name field and click the button next to this field. To specify the IP-address, subnet mask and default gateway manually, set the **Use the Following IP-address** checkbox, enter the values in the fields and click **Apply** next to these fields. The default values are set by the **Dynamic Host Configuration Protocol** service when the DHCP checkbox is set.
6. To test the LS (LH) connection, send a query to the specified IP-address using the **Ping** utility included in the Windows software package (Figure 7.2-4).



```
C:\WINDOWS\system32\cmd.exe
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\user>ping 192.168.254.1

Pinging 192.168.254.1 with 32 bytes of data:

Reply from 192.168.254.1: bytes=32 time=10ms TTL=128
Reply from 192.168.254.1: bytes=32 time<1ms TTL=128
Reply from 192.168.254.1: bytes=32 time<1ms TTL=128
Reply from 192.168.254.1: bytes=32 time<1ms TTL=128

Ping statistics for 192.168.254.1:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 10ms, Average = 2ms

C:\Documents and Settings\user>_
```

Figure 7.2-4 Using the Ping utility

7.2.4 Configuring the Linux Server for the INTELLECT™ operation

This stage includes the following steps:

1. Run the INTELLECT™ system. To run the system from the main Windows menu click Start ⇒ All Programs ⇒ Intellect ⇒ Intellect.
2. Create a new **Computer** object in the **Hardware** tab (Figure 7.2-5) and enter the NetBIOS name (see *Network identification of the Linux Server (LinuxHub)* section) into the **Computer name** field.



Figure 7.2-5 Creating a Computer object

Specify the IP-addresses of your computer and LS in the **Architecture** tab then restart the INTELLECT™ system (Figure 7.2-6, Figure 7.2-7).

Architecture Hardware Interfaces Users Programming					
Computer	Name	Connection	With computer	IP-address	Send events
LS44	VideoServer LS44	☒	Y-GAVRILYCHEV	10.0.0.152	☒
Y-GAVRILYCH..	Computer				

Figure 7.2-6 Entering an LS IP-address

Architecture Hardware Interfaces Users Programming					
Computer	Name	Connection	With computer	IP-address	Send events
LS44	VideoServer LS44	☒	LS44	192.168.0.53	☒
Y-GAVRILYCH..	Computer				

Figure 7.2-7 Entering a computer IP-address

3. In the **Hardware** tab click **Reconnect** in the contextual menu of the created computer object. If the settings are correct, the created computer is displayed in the hardware list (Figure 7.2-8).




Figure 7.2-8 The connected computer is displayed in the list

Make other settings in the INTELLECT™ system. For example, to display video received from a camera connected to the LS, create a **Video Capture Card** object under the **Computer <NetBIOS name>** object in the tree, and configure the created camera (Figure 7.2-9, Figure 7.2-10).




Figure 7.2-9 Creating a Camera object




Figure 7.2-10 Example of the LS configuration

Note. The details on the INTELLECT™ system configuration are described in another section of this manual. Some LS settings can be made through the Web interface (see The Linux Server (LinuxHub) Web interface section).

The **Relay** and **Sensor** objects are created under the **Video capture card** object with the first PCI channel used by the card. For ex., building security video subsystem with the use of two FX4 video capture cards and two DI/DO cards (low profile), the **Relay** and **Sensor** objects are to be created under the **Video capture card** object with **00** (1st FX4 video capture card) and **04** (2nd FX4 video capture card) values of the PCI channel.

Configuring the **Audio card** object bear in mind that list of available digitization rate can not agree with those stated in the specification. This list depends on ALSA driver for LS.

7.2.5 Configuring the LinuxHub for the INTELLECT™ operation

This stage includes the following steps:

1. Run the INTELLECT™ system. To run the system from the main Windows menu click Start ⇒ All Programs ⇒ Intellect ⇒ Intellect.
2. Create a new **Video Capture Card** under the **Computer** object (in the **Hardware** tab) (Figure 7.2-11), by specifying the **LinuxHub** type and the IP-address of the required LH (see *Network identification of the Linux Server (LinuxHub)* section).




Figure 7.2-11 Creating a Video Capture Card object

3. Make other settings in the INTELLECT™ system. For example, to display video received from a camera connected to the LH, create the **Camera** object under the **Video Capture Card <card id>** object in the object tree, and configure the created camera (Figure 7.2-12, Figure 7.2-13).




Figure 7.2-12 Creating a Camera object



Figure 7.2-13 Example of the LH configuration

4. Restart the INTELLECT™ system.

Note. The details on the INTELLECT™ system configuration are described in another section of this manual. Some LH settings can be made through the Web interface (see The Linux Server (LinuxHub) Web interface section).

LH enables working with audio received both from the cards and from the embedded audio card. To configure the LH audio subsystem, do the following:

1. Create the **Audio card** system object under the **Computer** object in the **Hardware** tab, set the **LH** type of the video capture card (Figure 7.2-14, 1).




Figure 7.2-14 Configuring the audio card

2. Set the sample rate for audio signal processed in the **LH** (Figure 7.2-14, 2).
3. Create and configure the required number of the **Microphone** objects under the **Audio card** object.
4. Restart the INTELLECT™ system.

Note. To enable audio stream recording from the microphone set the environment variable before starting the VideoServerCore:

export WRITE_AUDIO_INPUT= audio_device_number.

Number of the audio device can be found in VideoServerCore logs:

CBoard(audio_device_number, HDA Intel PCH:VT1708S Analog (hw:0,0)).

Configuring the LH for the INTELLECT™ operation is completed.

7.3 The Linux Server (LinuxHub) Web interface

7.3.1 Introduction

The Web interface is designed for remote access to the LS (LH) and has the following functionality:

1. Viewing video received from the cameras connected to the LS (LH);
2. Monitoring the LS (LH) operability;
3. Configuration of the LS (LH) network parameters;

4. Resetting the LS (LH) configuration;
5. Updating the LS (LH) firmware;
6. Downloading the activation key to the LS (LH).

7.3.2 Access to the Web interface

To open the LS (LH) Web interface, enter the IP-address of the required LS (LH) into the address line of the browser. The Web interface home page will load (Figure 7.3-1).




Figure 7.3-1 The LS (LH) Web interface home page (Info tab)

The following information is displayed in the **Info** tab:

1. The LS (LH) name;
2. The LS (LH) firmware version;
3. Operation time since last LS (LH) reboot;
4. NetBIOS name of the LS (LH);
5. IP-address of the remote computer from which the LS (LH) was last rebooted;
6. IP-address, subnet mask and default gateway of the LS (LH).
7. Status of the LS (LH) connection with INTELLECT™.

The **Reboot** button is located below used for the LS (LH) reboot. The **The Matrix is restarting now** message is displayed during the reboot.

Note. The browser must support Java to work correctly with the Web interface.

7.3.3 Viewing the video

The **Video** tab allows viewing the video signal received from the LS (LH) cameras (Figure 7.3-2).




Figure 7.3-2 Viewing the video (Video tab)

Viewing the video received from the LS (LH) cameras in the Web interface is similar to viewing the video through a web browser (see this manual).

7.3.4 Monitoring rays and relays status

Monitoring the status of connected rays and relays is made in the **Rays and Relays** tab (Figure 7.3-3).




Figure 7.3-3 Monitoring rays and relays status

This tab displays the list of rays and relays connected to LS (LH) and their status.

7.3.5 Monitoring the Linux Server (LinuxHub) operability

The **Sensors** tab allows monitoring the operability of the LS (LH) (Figure 7.3-4).

Sensors allow monitoring computer hardware: CPU temperature, fan speed, memory usage, etc. The **LmSensors** library is used to obtain this information. Data received with its help are displayed in the **LmSensors** group. Some data can be obtained without this library; these data are displayed in the **Basic** group. In general these are 'general monitoring data' and extended data.

For basic sensors the name and current value are given, limit of accepted values is specified in parenthesis.




Figure 7.3-4 Monitoring the system operability (Sensors tab)

7.3.6 Configuring the Linux Server (LinuxHub) network parameters

The **Setting** tab allows configuring the network parameters of the LS (LH) (Figure 7.3-5):

1. The password for accessing the LS (LH) Web interface (the **Password** and **Confirmation** fields);
2. NetBIOS name of the LS (LH);
3. IP-address, subnet mask and default gateway of the LS (LH);




Figure 7.3-5 Network parameters configuration (Setting tab)

*NOTE. To enter an IP-address, subnet mask and default gateway manually, set the **DHCP Off** checkbox and enter the values. To set the parameters automatically using the Dynamic Host Configuration Protocol service, set the **DHCP On** checkbox.*

When all values are set click **Submit** to save the changes or **Reset** to restore the previous values.

7.3.7 Configuring the Linux Server (LinuxHub) logging

To start storing logs on HDD or portable data medium set the **Store logs on HDD/Flash** checkbox (Figure 7.3-6).




Figure 7.3-6 Logging

After setting all necessary parameters click **Submit** to save all the changes or **Reset** to restore the previous parameters.

7.3.8 Configuring parameters of video stream displaying

Parameters of video stream displaying in the LS (LH) Web interface are configured in the **Settings** tab of the **Extra** group (Figure 7.3-7):

5. Select the period (in seconds) in the **Period (sec)** dropdown list.
6. Select the number of frames that are to be displayed for the selected period in the **Frames in period** dropdown list.

7. Select the videostream compression rate in the **Compression** dropdown list.




Figure 7.3-7 Configuring parameters of video stream displaying

After setting all necessary parameters click **Submit** to save all the changes or **Reset** to restore the previous parameters.

7.3.9 Setting the the Linux Server (LinuxHub) security

The following operations are performed in the **Key** tab (Figure 7.3-8):

1. Viewing the dallas codes of video capture cards' cryptochips installed on the LS (LH);
2. Viewing the information about the compliance of video capture card's dallas-codes with the LS (LH)'s key file;

Note. intellect.sec is used for the LS security, video.sec is used for the LH security.

3. Downloading the activation key to the LS (LH).




Figure 7.3-8 Downloading the activation key to the LS (LH)

To download the activation key to the LS (LH) do the following (Figure 7.3-8):

1. Click **Browse** to select the activation key;
2. Select the required file and click **Open** in the appeared standard dialog window of the Windows OS;
3. Click **Load**;
4. As a result the intellect.sec (video.sec) activation key is saved on the LS (LH) in the \etc\itv\ directory;
5. Restart the LS (LH).

Attention! Mozilla Firefox does not download the activation key to the LS (LH).

Downloading the activation key to LS (LH) is completed.

7.3.10 Resetting the Linux Server (LinuxHub) configuration

The **Setup** tab (Figure 7.3-9) allows resetting some configuration parameters of the LS (LH).

*Note. Online updating of the firmware is performed in the **Setup** tab (see Updating the Linux Server (LinuxHub) firmware section).*




Figure 7.3-9 Resetting some of the configuration parameters (Setup tab)

To reset the current LS (LH) configuration click **Reset** next to **Configuration**. The LS (LH) will reset the selected configuration parameters after restart. Click **Reboot** to restart the LS (LH).

Configuration means hardware configuration received from the INTELLECT™ system. Default configuration (under available and licensed hardware) is created after reset and reboot; hardware configuration created on Server is applied after connecting the INTELLECT™ system.

To reset the LS(LH) database settings click **Reset** next to **Video archive index**. Settings will be reset after restart. To restart the LS (LH) click **Reboot**.

The **Reset** button does not make any changes to LS (LH) configuration.

7.3.11 Viewing the Linux Server (LinuxHub) logs

Logs of the LS (LH) are viewed in the **Logs** tab (Figure 7.3-10).




Figure 7.3-10 Viewing the LS (LH) logs

Select the file with necessary log in the **Select module log file** dropdown list.

Only part of .log file is displayed in the Web interface. To get full file click **Download full logs**.

7.3.12 Working with memory dumps

Work with memory dumps is performed in the **Dumps** tab (Figure 7.3-11).




Figure 7.3-11 The Dumps tab

The available dumps are displayed in the **Dumps** tab.

To save the dump click **Download**.

7.4 Updating the Linux Server (LinuxHub) firmware

The LS (LH) firmware is updated via the Web interface.

Attention! Installing the LS firmware on the LH results in incorrect LH operation.

Note. The firmware update can be carried out locally from .iso image.

To update the LS (LH) firmware via the Web interface, do the following:

1. Go to the **Setup** tab (Figure 7.4-1).




Figure 7.4-1 Updating the Linux Server (LinuxHub) firmware via the web interface

2. Click **Browse** to select the firmware file (Figure 7.4-1).

Note. To get the firmware file, please, contact AxxonSoft's Help desk.

The firmware file has .iso extension.

3. Select the required firmware file and click **Open** in the standard dialog box.
4. Click **Load** (Figure 7.4-1).
5. As the result the firmware is loaded and installed on the LS (LH).
6. Wait till the process ends and then restart the LS (LH).

Updating the LS (LH) firmware via the Web interface is completed.

Note. There is no need to restore network settings and the LS(LH) activation key while updating the LS (LH) firmware via the Web interface.

8 Appendix 4. Technical specifications of video capture cards

Technical specifications of FS-5, FS-6, FS-16 and FS-8 video capture cards are given in Table 7.4-1.

Table 7.4-1 Technical specifications of FS-5, FS-6, FS-16 and FS-8 video capture cards

Parameters	FS-5		FS-6		FS-16		FS-8	
PCI bus, bit / MHz	32 / 33, using PCI-66/X		32 / 33, using PCI-66/X		PCI E 1x		32 / 33, using PCI-66/X	
Supply voltage, V	3.3 and 5		3.3 and 5		3.3		3.3 and 5	
Power consumption, W	2		5		5		9	
Video inputs, V / Ohm	1 / 75		1 / 75		1 / 75		1 / 75	
Video output, V / Ohm	1 / 75		1 / 75		1 / 75		1 / 75	
Number of video inputs	16		16		16		16	
Hardware compression	no		no		no		no	
Analog video out	1 (optional)		1 (optional)		1 (optional)		1 (built-in)	
Signal type	CCIR PAL, NTSC		CCIR PAL, NTSC		CCIR PAL, NTSC		CCIR PAL, NTSC	
Resolution, pixels	PAL	NTSC	PAL	NTSC	PAL	NTSC	PAL	NTSC
	352*288	320*240	352*288	320*240	352*288	320*240	352*288	320*240
	704*288	640*240	704*288	640*240	704*288	640*240	704*288	640*240
	704*576	640*480	704*576	640*480	704*576	640*480	704*576	640*480
Resolution, TV lines (b/w, color)	500 (500)		500 (500)		500 (500)		500 (500)	
Color palette	16 mln colors, 256 shades of gray		16 mln colors, 256 shades of gray		16 mln colors, 256 shades of gray		16 mln colors, 256 shades of gray	
Number of multiplexed video inputs	16		16		16		16	
Number of non-multiplexed (live) video inputs	1		4		4		8	
Video input rate for each non-multiplexed channel, fps, PAL (NTSC)	25 (30)		25 (30)		25 (30)		25 (30)	
Total video input rate for all multiplexed channels, fps, PAL	16 (704x288, 352x288) 12 (704x576)		64 (704x288, 352x288) 48 (704x576)		64 (704x288, 352x288) 48 (704x576)		128 (704x288, 352x288) 96 (704x576)	
Total video input rate for all multiplexed channels, fps, NTSC	20 (640x240, 320x240) 15 (640x480)		80 (640x240, 320x240) 60 (640x480)		80 (640x240, 320x240) 60 (640x480)		160 (640x240, 320x240) 120 (640x480)	
Total video input rate for all non-multiplexed channels, fps, PAL (NTSC)	25 (30)		100 (120)		100 (120)		200 (240)	
Galvanic isolation of sensor lines	4(16), 2000 V		4 (16), 2000 V		4 (16), 2000 V		4 (16), 2000 V	
Galvanic isolation of control outputs	4, 24 V, 30 mA		4, 24 V, 30 mA		4, 24 V, 30 mA		4, 24 V, 30 mA	
Number of audio input/output channels	2 x RCA/ -		8 x RCA/ -		8 x RCA/ -		16 x RCA/ -	
Audio digitizing frequency, kHz	8, 16, 32		8, 16, 32		8, 16, 32		8, 16, 32	

Parameters	FS-5	FS-6	FS-16	FS-8
Watchdog, hardware control of OS hanging-up	yes	yes	yes	yes
Digital-analog conversion, bit	9	9	9	9

Technical specifications of WS-6, WS-7, WS16 and WS-17 video capture cards are given in Table 7.4-2.

Table 7.4-2 Technical specifications of WS-6, WS-7, WS16 and WS-17 video capture cards

Parameters	WS-6		WS-7		WS16*		WS-17	
PCI bus, bit / MHz	32 / 33, using PCI-66/X		32 / 66(33)		1x		1x	
Supply voltage, V	3,3 and 5		3,3		-		3,3	
Power consumption, W	4		8		3,3		8	
Video inputs, V / Ohm	1 / 75		1 / 75		1 / 75		1 / 75	
Video output, V / Ohm	no		no		no		no	
Number of video inputs	4		4		16		4	
Hardware compression	yes		yes		yes		yes	
Analog video out	no		no		no		no	
Signal type	PAL, NTSC		PAL, NTSC		PAL, NTSC		PAL, NTSC	
Resolution, pixels	PAL	NTSC	PAL	NTSC	PAL	NTSC	PAL	NTSC
	704*544	640*480	704*288 704*544	640*240 640*480	352*288 704*288 704*576	352*240 704*240 704*480	352*288 704*288 704*544	320*240 640*240 640*480
Resolution, TV lines (b/w, color)	500 (500)		500 (500)		625 (PAL)/525(NTSC)		500 (500)	
Color palette	16 mln colors, 256 shades of gray		16 mln colors, 256 shades of gray		16 mln colors, 256 shades of gray		16 mln colors, 256 shades of gray	
Number of multiplexed video inputs	-		-		-		-	
Number of non-multiplexed (live) video inputs	4		4		16		4	
Video input rate for each non-multiplexed channel, fps, PAL (NTSC)	25 (30)		25 (30)		25 (30)		25 (30)	
Total video input rate for all multiplexed channels, fps, PAL	-		-		-		-	
Total video input rate for all multiplexed channels, fps, NTSC	-		-		-		-	
Total video input rate for all non-multiplexed channels, fps, PAL (NTSC)	100 (120)		100 (120)		400(480)		100 (120)	
Galvanic isolation of sensor lines	no		no		no		no	
Galvanic isolation of control outputs	no		no		no		no	

Parameters	WS-6	WS-7	WS16*	WS-17
Number of audio input/output channels	8 x RCA/ -	8 x RCA/ -	16 x RCA/ -	8 x RCA/ -
Audio digitizing frequency, kHz	16	8, 16	8	8,16
Watchdog, hardware control of OS hanging-up	no	no	no	no
Digital-analog conversion, bit	9	9	10	9

* Resolutions supported by WS16 video capture card are given in the table. Video is displayed only with 352x288 (PAL) / 352x240 (NTSC) resolution.

Technical specifications of FX8, FS15, FX4 and FX16 video capture cards are given in Table 7.4-3.

Table 7.4-3 Technical specifications of FX8, FS15, FX4 and FX16 video capture cards

Parameters	FX8		FS15		FX4		FX16	
Size (mm x mm)	132,22 x 80		120.55 × 85		132,22 x 80		179.97 × 106.65	
Minimal requirements to the input/output bus, standard	PCI-E x 1		PCI (33MHZ)		PCI-E x 1		PCI-E×4 (33MHZ)	
ADC (bit)	10		10		10		10	
Number of video inputs	16 x BNC		4 × BNC		16 x BNC		16 x BNC	
Hardware compression	no		no		no		no	
Analog video out	no		no		no		no	
Power consumption, W	4		0,5		4		5,5	
Video inputs, V / Ohm	1/75		1/75		1/75		1/75	
Video output, V / Ohm	1/75		1/75		1/75		1/75	
Audio input, V/ kOhm	1/40		1/40		1/40		3,5/10	
Signal type	PAL, NTSC		PAL, NTSC		PAL, NTSC		PAL, NTSC	
Resolution, pixels	PAL	NTSC	PAL	NTSC	PAL	NTSC	PAL	NTSC
	352*288	320*240	352*288	320*240	352*288	320*240	352*288	320*240
	704*288	640*240	704*288	640*240	704*288	640*240	704*288	640*240
	704*576	640*480	704*576	640*480	704*576	640*480	704*576	640*480
Maximum resolution, TV lines (b/w, color)	576 (PAL) / 480 (NTSC)		576 (PAL) / 480 (NTSC)		576 (PAL) / 480 (NTSC)		625 (PAL) / 525 (NTSC)	
Color palette	16 mln colors, 256 shades of gray		16 mln colors, 256 shades of gray		16 mln colors, 256 shades of gray		16 mln colors, 256 shades of gray	
Number of multiplexed video inputs	16		4		16		-	
Number of non-multiplexed (live) video inputs	8		1		4		16	
Video input rate for each non-multiplexed channel, fps, PAL (NTSC)	25 (30)		25 (30)		25 (30)		25 (30)	
Total video input rate for all multiplexed channels, fps, PAL	128 (704x288, 352x288) 128 (704x576)		16 (704x288, 352x288) 16 (704x576)		64 (704x288, 352x288) 64 (704x576)		-	

Parameters	FX8	FS15	FX4	FX16
Total video input rate for all multiplexed channels, fps, NTSC	160(640x240, 320x240) 160(640x480)	20(640x240, 320x240) 20(640x480)	80(640x240,320x240) 80(640x480)	-
Total video input rate for all non-multiplexed channels, fps, PAL (NTSC)	200 (240)	25 (30)	100 (120)	400(480)
Number of audio input/output channels	8 x RCA/ -	1 x TRS/ -	4 x RCA/ -	16 x RCA/ -
Audio digitizing frequency, kHz	8, 16, 24, 32, 40, 48	8, 16, 24, 32, 40, 48	8, 16, 24, 32, 40, 48	8, 16, 24, 40, 48
Galvanic isolation of sensor lines	4	not integrated	4	4
Control outputs, open collector	4	not integrated	4	4
Watchdog, hardware control of OS hanging-up	yes	yes	yes	yes
Peak temperature of card	50 ⁰ C	40 ⁰ C	40 ⁰ C	65 ⁰ C
Supported OS	All OS supported by the INTELLECT™ system	All OS supported by the INTELLECT™ system	All OS supported by the INTELLECT™ system	All OS supported by the INTELLECT™ system

Technical specifications of FS115, FX2, FX116 and FX416 video capture cards are given in Table 7.4-4.

Table 7.4-4 Technical specifications of FS115, FX2, FX116 and FX416 video capture cards

Parameters	FS115		FX2		FX116		FX416	
Minimal requirements to the input/output bus, standard	PCI		PCI-E x 1		PCI-E x 1		PCI-Ex4	
ADC (bit)	10		9		10		10	
Number of video inputs	4 x BNC		8 x BNC		16 x BNC		16 x BNC	
Hardware compression	no		no		no		no	
Analog video out	no		1 (optionally)		no		no	
Power consumption, W	0,5		3		1,5		1,8	
Video inputs, V / Ohm	1/75		1/75		1/75		1/75	
Video outputs, V / Ohm	1/75		1/75		1/75		1/75	
Audio input, V/ kOhm	1/40		1,4 / 5		1/10		1/10	
Signal type	PAL, NTSC		PAL, NTSC		PAL, NTSC		PAL, NTSC	
Resolution, pixels	PAL	NTSC	PAL	NTSC	PAL	NTSC	PAL	NTSC
	352*288	320*240	352*288	320*240	352*288	320*240	352*288	320*240
	704*288	640*240	704*288	640*240	704*288	640*240	704*288	640*240
	704*576	640*480	704*576	640*480	704*576	640*480	704*576	640*480
Maximum resolution, TV lines (b/w, color)	576 (PAL) / 480 (NTSC)		480		625 (PAL) / 525 (NTSC)		625 (PAL) / 525 (NTSC)	
Color palette	16 mln colors, 256 shades of gray		16 mln colors, 256 shades of gray		16 mln colors, 256 shades of gray		16 mln colors, 256 shades of gray	

Parameters	FS115	FX2	FX116	FX416
Number of multiplexed video inputs	4	8	16	-
Number of non-multiplexed (live) video inputs	1	2	8	16
Video input rate for each non-multiplexed channel, fps, PAL (NTSC)	25 (30)	25 (30)	25 (30)	25 (30)
Total video input rate for all multiplexed channels, fps, PAL	16 (704x288, 352x288) 16 (704x576)	32 (704x288, 352x288) 24 (704x576)	128 (704x576)	-
Total video input rate for all multiplexed channels, fps, NTSC	20(640x240, 320x240) 20(640x480)	40(640x240,320x240) 30(640x480)	160(640x480)	-
Total video input rate for all non-multiplexed channels, fps, PAL (NTSC)	25 (30)	50 (60)	200 (240)	400 (480)
Number of audio inputs/outputs channels	1 x RCA/ -	4 x RCA/ -	16 x RCA/ -	16 x RCA/ -
Audio digitizing frequency, kHz	8, 16, 24, 32, 40, 48	8, 16, 32	8, 16	8, 16
Galvanic isolation of sensor lines	4	4 (16), 2000 V	not integrated	not integrated
Control outputs, open collector	4	4, 24 B, 30 mA	not integrated	not integrated
Watchdog, hardware control of OS hanging-up	yes	yes	yes	yes
Supported OS	All OS supported by the INTELLECT™ system	All OS supported by the INTELLECT™ system	All OS supported by the INTELLECT™ system	All OS supported by the INTELLECT™ system

Technical specifications of WS216 and FX HD4 video capture cards are given in Table 7.4-5.

Table 7.4-5 Technical specifications of WS216 and FX HD4 video capture cards

Parameters	WS216		FX HD4	
Minimal requirements to the input/output bus, standard	PCI-E x 1		PCI-Ex4	
ADC (bit)	10		-	
Number of video inputs	16		4	
Hardware compression	yes		no	
Analog video out	no		no	
Power consumption, W	3,3		3,3	
Video inputs, V / Ohm	1/75		-	
Video outputs, V / Ohm	-		-	
Signal type	PAL, NTSC		-	
Resolution, pixels	PAL	NTSC	Progressive scanning in PAL system (NTSC)	Interlase scanning in PAL system (NTSC)

Parameters	WS216		FX HD4	
	352*288 704*288 704*576	352*240 704*240 704*480	1920*1080 1280*720	1280*720
Maximum resolution, TV lines (b/w, color)	576 (PAL) / 480 (NTSC)		-	
Color palette	16 mln colors, 256 shades of gray		16 mln colors, 256 shades of gray	
Number of multiplexed video inputs	-		-	
Number of non-multiplexed (live) video inputs	16		4	
Total video input rate for all non-multiplexed channels, fps, PAL (NTSC)	25 (30)		25 (1920x1080 resolution) 50 (1270x720 resolution)	
Total video input rate for all multiplexed channels, fps, PAL	-		200 (1280x720 resolution) 100 (1920x1080 resolution)	
Total video input rate for all multiplexed channels, fps, NTSC	-		-	
Total video input rate for all non-multiplexed channels, fps, PAL (NTSC)	400 (480)		100 (120)	
Number of audio inputs/outputs channels	16 x RCA/ -		4 x HDMI/ 4 x HD SDI	
Audio digitizing frequency, kHz	8		32 - 48	
Galvanic isolation of sensor lines	4		not integrated	
Control outputs, open collector	4		not integrated	
Watchdog, hardware control of OS hanging-up	yes		yes	
Supported OS	All OS supported by the INTELLECT™ system		All OS supported by the INTELLECT™ system	

Note. When WS216 video capture card with h.264 compression is in use, recording to the archive is in the colour mode. Black-and-white mode is not supported.

Technical specifications of VRC6004, VRC6008, VRC6416 and VRC7008L video capture cards are given in Table 7.4-6.

Table 7.4-6 Technical specifications of VRC6004, VRC6008, VRC6416, VRC7008L and VRC6404HD video capture cards

Parameters	Stretch VRC6004		Stretch VRC6008		Stretch VRC6416		Stretch VRC7008L		Stretch VRC6404HD
Interface	PCI-E 1x		PCI-E 1x		PCI-E 4x		PCI-E 1x		PCI-E 4x
Number of video inputs	4		8		16		8		4
Number of video channels for H264 Svc format	3 (channel 4 is disabled)		6 (channels 4 and 8 are disabled)		12 (channels 4, 8, 12 and 16 are disabled)		8		4
Signal type	PAL, NTSC		PAL, NTSC		PAL, NTSC		PAL, NTSC		PAL, NTSC
Resolution, pixels	PAL	NTSC	PAL	NTSC	1920*1072 960*528 480*256	NTSC	PAL	NTSC	1920*1072 960*528 480*256
	720*576	720*480	720*576	720*480		720*480	720*576	720*480	
	704*576	704*480	704*576	704*480		704*480	704*576	704*480	
	528*384	528*320	528*384	528*320		528*320	528*384	528*320	
	360*288	360*240	360*288	360*240		360*240	352*288	352*240	

Parameters	Stretch VRC6004		Stretch VRC6008		Stretch VRC6416		Stretch VRC7008L		Stretch VRC6404HD
	180*144	180*120	180*144	180*120		180*120	176*144	176*120	
Recording rate for each channel	25fps PAL / 30fps NTSC		25fps PAL / 30fps NTSC		25fps PAL / 30fps NTSC		25fps PAL / 30fps NTSC		25fps PAL / 30fps NTSC
Video compression format	H.264 / MJPEG / MPEG		H.264 / MJPEG / MPEG		H.264 / MJPEG / MPEG		H.264 / MJPEG / MPEG		H.264 AVC / H.264 SVC / MPEG4 / MJPEG
Recording rate for each channel for H264 Svc format	12fps PAL / 15fps NTSC		12fps PAL / 15fps NTSC		12fps PAL / 15fps NTSC		25fps PAL / 30fps NTSC		25fps PAL / 30fps NTSC
Number of audio in/out channels	-		8 x RCA/ -		16 x RCA/ -		8 x RCA/ -		4 x BNC/-
Number of audio channels (input) for H264 Svc format	-		6 (channels 4 and 8 are disabled)		12 (channels 4, 8, 12 and 16 are disabled)		8		4
Audio compression format	-		G.711		G.711		G.711		G.711
Analog video out modes	-		NTSC / PAL Analog "Rolling" SMO		-		1CVBS		-
Video out pin	-		BNC		-		DVI		BNC
Video pre-preprocessing	De-interlacing; Titling by user; Stretch Bilateral Filter (additionally)		De-interlacing; Titling by user; Stretch Bilateral Filter (additionally)		De-interlacing; Titling by user; Stretch Bilateral Filter (additionally)		De-interlacing; Titling by user; Stretch Bilateral Filter (additionally)		De-interlacing; Titling by user; Stretch Bilateral Filter (additionally)
Analytics	Motion detector; Flash and break-in detector; Night mode detector		Motion detector; Flash and break-in detector; Night mode detector		Motion detector; Flash and break-in detector; Night mode detector		Motion detector; Flash and break-in detector; Night mode detector		Motion detector; Flash and break-in detector; Night mode detector
Alarm system and triggers support (available in additional daughter cards)	8 optically isolated inputs; 8 relay outputs		8 optically isolated inputs; 8 relay outputs		8 optically isolated inputs; 8 relay outputs		8 optically isolated inputs; 8 relay outputs		16 optically isolated inputs; 16 relay outputs
Sertificates	FCC, CE		FCC, CE		FCC, CE		-		FCC, CE
Minimal requirements to processor	Dual Core 2.4 GHz or equivalent		Dual Core 2.4 GHz or equivalent		Dual Core 2.4 GHz or equivalent		Dual Core 2.4 GHz or equivalent		Dual Core 2.4 GHz or equivalent
Minimal requirements to RAM(Gb)	1		1		1		1		1
Supported OS	All OS supported by the INTELLECT™		All OS supported by the INTELLECT™		All OS supported by the INTELLECT™		All OS supported by the INTELLECT™		All OS supported by

Parameters	Stretch VRC6004	Stretch VRC6008	Stretch VRC6416	Stretch VRC7008L	Stretch VRC6404HD
	system	system	system	system	the INTELLECT™ system

Technical specifications of DS-4016HCI(R) video capture card are given in Table 7.4-7.

Table 7.4-7 Technical specifications of DS-4016HCI(R) video capture card

Parameters	DS-4016HCI(R)	
Minimal requirements to the input/output bus, standard	PCI	
Size (mm x mm)	198 x 100	
Number of video channels	16	
Video input interface	BNC (1.0Vp-p, 75Ω)	
Maximum fps for a channel	25fps (PAL)/30 fps (NTSC)	
Resolution at recording, pixels	PAL	NTSC
	704 * 576	704 * 480
	704*288	704*240
Resolution under compression, pixels	352 * 288	352 * 240
	PAL	NTSC
	704 * 576	704 * 480
	704*288	704*240
	352 * 288	352 * 240
Data rate for one video channel	32Kbps ~ 2Mbps	
Video compression format	H.264 or I420	
Number of audio channels	16	
Audio compression format	OggV or bis, 16Kbps	
Audio input interface	BNC(2Vp-p, 1kΩ)	
Video/audio output	yes	
Resolution of preview, pixels	PAL	NTSC
	704 * 576	704 * 480
Type of stream	Video/video+audio	
Dual stream	yes	
Dual coding support	yes	
Power consumption	Less then 9W	
Peak temperature	from -10°C to +50°C	

Parameters	DS-4016HCI(R)
Humidity	10%~90%
Supported OS	All OS supported by the INTELLECT™ system

Note 1. DS-4016HCI(R) video capture card has an embedded motion detector that is not integrated at the time of writing this manual.

Note 2. At the time of writing this manual audio is not integrated for DS-4016HCI(R) video capture card.

9 Appendix 5. Video capture cards pins

9.1 FS-5 video capture card pins

FS-5 video capture card has 3 external pins— two RCA pins and a D-SUB-25 pin (Figure 9.1-1). Video connection is performed to the D-SUB-25 pin with the help of D-SUB-25/BNC stub. Simultaneous connection of up to 16 cameras is possible. Sound connection is performed with the help of RCA pins (two sound sources are maximum possible). Analog output card is connected to J2, J7, J8 pins. The Watchdog cable is connected to the J1 pin.




Figure 9.1-1 FS-5 video capture card pins

9.2 FS-6 video capture card pins

FS-6 video capture card has 2 external pins - D-SUB-9 and D-SUB-25 (Figure 9.2-1). Video connection is performed with the help of D-SUB-25/BNC stub. Simultaneous connection of up to 16 cameras is possible. D-SUB-9/RCA-8 interface cable is used for connecting the audio channels (up to 8 sound sources simultaneously) to the external D-SUB-9 pin of FS-6 video capture card. Analog output card is connected to J2, J7, J8 pins. The Watchdog cable is connected to the J1 pin.




Figure 9.2-1 FS-6 video capture card pins

9.3 FS-16(Exp) video capture card pins

FS16 (Exp) video capture card has 2 external pins - D-SUB-9 and D-SUB-25 (Figure 9.3-1). Video connection is performed with the help of D-SUB-25/BNC stub. Simultaneous reception of up to 16 video images is possible. D-SUB-9/RCA-8 interface cable is used for connecting the audio channels to the external D-SUB-9 pin of FS16 (Exp) video capture card (up to 8 sound sources simultaneously). Analog output card is connected to J2, J7, J8 pins. The Watchdog cable is connected to the J1 pin.




Figure 9.3-1 FS-16(Exp) video capture card pins

9.4 FS-8 video capture card pins

FS-8 video capture card has two external pins - D-SUB-9 and D-SUB-25 and one internal pin - IDC-16 (Figure 9.4-1). Video connection is performed with the help of D-SUB-25/BNC stub via D-SUB-25 pin. Simultaneous reception of up to 16 video images is possible. D-SUB-9/RCA-8 interface cable is used for connecting the audio channels to the external D-SUB-9 pin of FS-8 video capture card (up to 8 sound sources simultaneously). IDC-16/D-SUB-9 bracket of sound extension is used (up to 8 sound sources simultaneously) to connect additional audio channels. It is connected to the internal IDC-16 pin of FS-8 video capture card. The Watchdog cable is connected to the J1 pin.




Figure 9.4-1 FS-8 video capture card pins

9.5 WS-7 video capture card pins

WS-7 video capture card has two external pins - D-SUB-9 and D-SUB-25 (Figure 9.5-1). D-SUB-25/BNC interface cable is used for simultaneous connection of 4 cameras to the external D-SUB-25 pin of WS-7 video capture card. D-SUB-9/RCA interface cable is used for simultaneous connection of 4 audio channels to the external D-SUB-9 pin of WS-7 video capture card.




Figure 9.5-1 WS-7 video capture card pins

9.6 WS-16 video capture card pins

WS-16 video capture card has two external DVI-I pins (Figure 9.6-1). Video and audio connection is performed with the help of DVI-I/BNC and DVI-I/RCA stubs correspondingly. Simultaneous connection of up to 8 cameras and up to 8 sound sources to one external pin of WS-16 video capture card is possible. The Watchdog cable is connected to the J1 pin.




Figure 9.6-1 WS-16 video capture card pins

9.7 WS-17 video capture card pins

WS-17 video capture card has two external pins - D-SUB-9 and D-SUB-25 (Figure 9.7-1). D-SUB-25/BNC interface cable is used for simultaneous connection up to 4 cameras to the external D-SUB-25 pin of WS-17 video capture card. D-SUB-9/RCA interface cable is used for simultaneous connection up to 4 audio channels to the external D-SUB-9 pin of WS-17 video capture card.




Figure 9.7-1 WS-17 video capture card pins

9.8 WS216 video capture card pins

WS216 video capture card has two external DVI-I pins (Figure 9.8-1). Video and audio connection is performed with the help of DVI-I/BNC and DVI-I/RCA stubs correspondingly. Simultaneous connection of up to 8 cameras and up to 8 sound sources to one external pin of WS216 video capture card is possible. The Watchdog cable is connected to the J1 pin. DI/DO card is connected to the J2 pin.




Figure 9.8-1 WS216 video capture card pins

9.9 FS15 video capture card pins

FS15 video capture card has five external pins— one TRS (3,5 mm, *mini-jack*) pin and four BNC pins (Figure 9.9-1). Cameras are connected via BNC pin. Simultaneous connection of up to 4 cameras is possible. Sound is connected via TRS pin. The Watchdog cable is connected to the J1 pin.




Figure 9.9-1 FS15 video capture card pins

9.10 FX8 video capture card pins

FX8 video capture card has two external DVI-I (24+5) pins (Figure 9.10-1). Video and audio connection is performed with the help of DVI-I/BNC and DVI-I/RCA stubs correspondingly. Simultaneous connection of up to 8 cameras and up to 4 sound sources to one external pin of FX8 video capture card is possible. The Watchdog cable is connected to the J1 pin. DI/DO card (low profile) is connected to the J2 pin.




Figure 9.10-1 FX8 video capture card pins

9.11 FX4 video capture card pins

FX4 video capture card has one external DVI-I (24+5) pin (Figure 9.11-1). Video and audio connection is performed with the help of DVI-I/BNC and DVI-I/RCA stubs correspondingly. Simultaneous connection of up to 16 cameras and up to 4 sound sources to one external pin of FX4 video capture card is possible. The Watchdog cable is connected to the J1 pin. DI/DO card (low profile) is connected to the J2 pin.




Figure 9.11-1 FX4 video capture card pins

9.12 FX16 video capture card pins

FX16 video capture card has two external DVI-I (24 + 5) pins (Figure 9.12-1). Video and audio connection is performed with the help of DVI-I/BNC and DVI-I/RCA stubs correspondingly. Simultaneous connection of up to 8 cameras and up to 8 sound sources to one external pin of FX16 video capture card is possible. The Watchdog cable is connected to the J1 pin. DI/DO card (low profile) is connected to the J2 pin.




Figure 9.12-1 FX16 video capture card pins

9.13 FS115 video capture card pins

FS115 video capture card has one external DVI-I pin (Figure 9.13-1). Video and audio connection is performed with the help of DVI-I/BNC and DVI-I/RCA stubs correspondingly. Simultaneous connection of up to 4 cameras and 1 sound source to one external pin of FS115 video capture card is possible. The Watchdog cable is connected to the J1 pin. DI/DO card (low profile) is connected to the J2 pin.




Figure 9.13-1 FS115 video capture card pins

9.14 FX116 video capture card pins

FX116 video capture card has two external pins - D-SUB 25 and D-SUB 26 (Figure 9.14-1). Simultaneous connection of up to 8 cameras and 16 sound sources to external pins of FX116 video capture card is possible. Video connection is performed with the help of D-SUB-25/BNC stub and audio connection is performed with the help of D-SUB-26/RCA stub.




Figure 9.14-1 FX116 video capture card pins

9.15 FX416 video capture card pins

FX416 video capture card has two external pins - D-SUB 25 and D-SUB 26 (Figure 9.15-1). Simultaneous connection of up to 16 cameras and 16 sound sources to external pins of FX416 video capture card is possible. Video connection is performed with the help of D-SUB 25/BNC stub and audio connection is performed with the help of D-SUB 26/RCA stub.




Figure 9.15-1 FX416 video capture card pins

9.16 VRC6004 video capture card pins

VRC6004 video capture card has four external BNC pins (Figure 9.16-1). Cameras are connected with the help of BNC pin. Simultaneous connection of up to 4 cameras is possible. DI/DO card is connected to the J1 pin.




Figure 9.16-1 VRC6004 video capture card pins

9.17 VRC6008 video capture card pins

VRC6008 video capture card has two external D-SUB-15 pins (Figure 9.17-1). D-SUB-15/BNC interface cable is used for simultaneous connection of up to 8 cameras and 8 audio channels to the external D-SUB-15 pin of VRC6008 video capture card. DI/DO card is connected to the J2 pin. Pin J1 corresponds to analog video out.




Figure 9.17-1 VRC6008 video capture card pins

9.18 VRC6416 video capture card pins

VRC6416 video capture card has two external DVI pins (Figure 9.18-1). DVI /BNC interface cable is used for simultaneous connection of up to 16 cameras and 16 sound sources to external DVI pins of VRC6416 video capture card. DI/DO card is connected to the J1 pin.




Figure 9.18-1 VRC6416 video capture card pins

9.19 VRC7008L video capture card pins

VRC7008L video capture card has a DVI pin (Figure 9.19-1). DVI /BNC interface cable is used for simultaneous connection of up to 8 cameras and 8 sound sources to external DVI pin of VRC7008L video capture card. DI/DO card is connected to the J1 pin. J2 pin corresponds to analog video out.




Figure 9.19-1 VRC7008L video capture card pins

9.20 VRC6404 HD video capture card pins

VRC6404 HD video capture card has BNC pins through which cameras are connected. Up to 4 cameras can be connected. There is the 15-pin SATA (J4) power socket. D2 pin is used to connect DI/DO card.




Figure 9.20-1 VRC6404 HD video capture card pins

9.21 FX HD4 video capture card pins

FX HD4 video capture card has 4 external HDMI pins (Figure 9.21-1) to connect video and audio devices. The Watchdog cable is connected to the J1 pin.




Figure 9.21-1 FX HD4 video capture card pins

9.22 DS-4016HCI(R) video capture card pins

DS-4016HCI(R) video capture card has two external DB-15pins to connect 16 video channels and 4 audio channels. The DB15-male to BNC cable is to connect cameras and sound. Extra 12 audio channels (5 - 16) are connected to J21 pin. J1 and J2 pins are to connect audio outputs via the CD_IN-interface.

Note. At the time of writing this manual audio is not integrated into Intellect software.




Figure 9.22-1 DS-4016HCI(R) video capture card pins

10 Appendix 6. Electrical and technical specifications of DI/DO cards

10.1 Electrical and technical specifications of DI/DO cards

DI/DO cards are multichannel digital-analogue converters and transmitters of up to 4 control signals to executive devices (relays) that are to be used in video surveillance systems installed with FS-5, FS-6, FS-16 and FS-8 video capture cards.

While working with DI/DO cards it is necessary to take into account the following electrical specifications:

1. Current state of a sensor.

Depending on the value of resistance between input contacts on the line, the current state of a sensor can be:

- 1.1 close (below 3 kilohms);
- 1.2 open (over 10 kilohms);
- 1.3 undefined (from 3 to 10 kilohms).

Note. Undefined state may be determined by the system as close or open.

2. State of a relay at the output.

State of a relay at the output should be «Open» for DI/DO card. The following conditions are to be met:

- 2.1 maximum current through the open collector– 150 milliamperes;
- 2.2 resistance – 24 volts;
- 2.3 minimal resistance of connected relay– 160 ohms.

Technical specifications of DI/DO cards should be beared in mind while connecting the sensors (Table 10.1-1).

Table 10.1-1 Technical specifications of DI/DO cards

Parameter	4/4 DI/DO cards	16/4 DI/DO cards
Guard loops (sensors)	4	16
Breakdown voltage	1000 V up to 1 minute	1000 V up to 1 minute
Control output (relays)	4	4
Open collector (interface)	24, 30 ma	24, 30 ma

10.2 Electrical and technical specifications of 4/4 DI/DO (low profile) cards

4/4 DI/DO (low profile) card is to be used in video surveillance systems installed with FS115/FX4/FX8/FX16 video capture cards.

Electrical and technical specifications of 4/4 DI/DO (low profile) cards are given in Table 10.2-1.

Table 10.2-1 Electrical and technical specifications of 4/4 DI/DO (low profile) card

Parameter	DI (sensor)	DO (relay)
-----------	-------------	------------

Parameter	DI (sensor)		DO (relay)
Number of guard loops	4		4
Triggering time	0.1 ms		OFF -> ON: 3.0 ms ON -> OFF: 2.5 ms
Maximum value of current strength and voltage			direct current: 2 A/24 V alternating current: 1 A/120 V
Triggering level	Up to 5 V	Up to 12 V	
	2.5 B – OFF	4.5 B –OFF	
	2.1 B – ON	2.1 B – ON	

10.3 Electrical and technical specifications of MO USBIO 4x4 devices

Power is supplied to MO USBIO 4x4 device via the USB. Maximum permissible current consumed by the device is not more than 500 ma.


The MO USBIO 4x4 device has a galvanic isolation of DI/DO circuits (sensors and relays) against the USB (breakdown voltage is 1000 V up to 1 minute). Electrical and technical specifications of MO USBIO 4x4 device are given in Table 10.3-1.

Table 10.3-1 Electrical and technical specifications of MO USBIO 4x4 device

Parameter	Relay (output circuit)	Sensor (input circuit)
Number of loops	4	4
Maximum permissible current	400 ma (in any direction)	50 ma (in any direction)
Ampere rating	-	8 ma (in any direction)
Voltage rating	-	24 V (in any direction)
Maximum permissible voltage	60 V (in any direction)	-
Embedded power supply	-	24 V

10.4 Electrical and technical specifications of SL USBIO («4x4», «16x8», «24x4») card

Pinout of an external pin of the SL USBIO card is given in Figure 10.4-1.



Pinout of an external pin of SL USBIO 16x8 and USBIO 24x4 cards

Figure 10.4-1 Pinout of an external pin of SL USBIO card

Description of channels of SL USBIO 16x8 and SL USBIO 24x4 cards is given in Table 10.4-1.

Table 10.4-1 Pinout of an external pin of SL USBIO 16x8 and SL USBIO 24x4 cards

USBIO 16x8				USBIO 24x4			
Contact	Application	Contact	Application	Contact	Application	Contact	Application
1	Sensor 1	32	Sensor 14	1	Sensor 1	32	Sensor 14
2	Sensor 1	33	Sensor 14	2	Sensor 1	33	Sensor 14
3	Sensor 2	34	Sensor 15	3	Sensor 2	34	Sensor 15
4	Sensor 2	35	Sensor 15	4	Sensor 2	35	Sensor 15
5	Sensor 3	36	Sensor 16	5	Sensor 3	36	Sensor 16
6	Sensor 3	37	Sensor 16	6	Sensor 3	37	Sensor 16
7	Sensor 4	38	Not used	7	Sensor 4	38	Not used
8	Sensor 4	39	Not used	8	Sensor 4	39	Not used
9	Sensor 5	40	Not used	9	Sensor 5	40	Not used
10	Sensor 5	41	Relay 3 (+)	10	Sensor 5	41	Relay 3 (+)
11	Sensor 6	42	Relay 3 (-)	11	Sensor 6	42	Relay 3 (-)
12	Sensor 6	43	Not used	12	Sensor 6	43	Sensor 17
13	Sensor 7	44	Not used	13	Sensor 7	44	Sensor 17
14	Sensor 7	45	Not used	14	Sensor 7	45	Sensor 18
15	Sensor 8	46	Not used	15	Sensor 8	46	Sensor 18
16	Sensor 8	47	Not used	16	Sensor 8	47	Sensor 19
17	Not used	48	Not used	17	Not used	48	Sensor 19
18	Relay 1 (+)	49	Not used	18	Relay 1 (+)	49	Sensor 20
19	Relay 1 (-)	50	Not used	19	Relay 1 (-)	50	Sensor 20
20	Relay 2 (+)	51	Relay 5 (+)	20	Relay 2 (+)	51	Sensor 21
21	Relay 2 (-)	52	Relay 5 (-)	21	Relay 2 (-)	52	Sensor 21
22	Sensor 9	53	Relay 6 (+)	22	Sensor 9	53	Sensor 22
23	Sensor 9	54	Relay 6 (-)	23	Sensor 9	54	Sensor 22

USBIO 16x8				USBIO 24x4			
Contact	Application	Contact	Application	Contact	Application	Contact	Application
24	Sensor 10	55	Relay 7 (+)	24	Sensor 10	55	Sensor 23
25	Sensor 10	56	Relay 7 (-)	25	Sensor 10	56	Sensor 23
26	Sensor 11	57	Relay 8 (+)	26	Sensor 11	57	Sensor 24
27	Sensor 11	58	Relay 8 (-)	27	Sensor 11	58	Sensor 24
28	Sensor 12	59	Not used	28	Sensor 12	59	Not used
29	Sensor 12	60	Not used	29	Sensor 12	60	Not used
30	Sensor 13	61	Relay 4 (+)	30	Sensor 13	61	Relay 4 (+)
31	Sensor 13	62	Relay 4 (-)	31	Sensor 13	62	Relay 4 (-)

Electrical and technical specifications of SL USBIO card are given in Table 10.4-2.

Table 10.4-2 Electrical and technical specifications of SL USBIO card

Parameter	Characteristic
Polling interval for all alarm inputs	250 ms for all contacts. Not configured.
Galvanic isolation of input/output	1000 V
Interface connection to PC	USB 2.0 up to 5 m
Alarm contacts	- Maximum current – 0.5 A - Voltage – 100 V - Power – 10 W
Relay contacts	- Permissible voltage - up to 80 V - Minimum triggering voltage - 1.0 V - Minimum triggering current - 5 ma
Real-time clock for event logging	Yes
ROM	For 1000 alarm events
Power supply	Using USB port or PSU, voltage - 9-50 V, consumption - 500 ma