



Additional utilities for the Axxon PSIM software

PSIM 1.0.0-1.0.1 (english)

Last update 07/03/2024

1. Additional utilities for the Axxon PSIM software	4
1.1 Summary of the Axxon PSIM utilities	7
1.2 The utility for reading video capture card code and dongle	8
1.2.1 The purpose of the CodeReader.exe utility	9
1.2.2 Starting and shutting-down the utility	10
1.2.3 Using the CodeReader.exe utility	11
1.2.4 Portable version CodeReader_portable.exe	12
1.3 Converter.exe utility for converting video and audio archives	13
1.3.1 The purpose of the Converter.exe utility	14
1.3.2 Starting and shutting-down the Converter.exe utility	15
1.3.3 Converter.exe interface	17
1.3.3.1 The Archive's Converter dialog box	18
1.3.3.2 The Export Settings dialog box	20
1.3.3.3 A dialog box for choosing the video codec	23
1.3.3.4 A dialog box for choosing the audio format	24
1.3.4 Using the Converter.exe utility	25
1.3.4.1 General description of the Converter.exe utility	26
1.3.4.2 Selecting an archive to be played or converted	27
1.3.4.3 Searching for a video recording	29
1.3.4.3.1 Searching for a fragment in a recording	30
1.3.4.3.2 Searching for a frame in a recording	31
1.3.4.4 Recording playback	32
1.3.4.5 Converting video and audio archives to AVI files	33
1.3.4.6 Exporting recordings and frames	34
1.3.4.7 Using a command prompt to work with the Converter.exe utility	36
1.3.4.8 Printing a frame	38
1.3.4.9 Exporting video with titles	39
1.4 Tweaki.exe utility for advanced setup of the Axxon PSIM software system	41
1.4.1 The purpose of the tweaki.exe utility	42
1.4.2 Starting and shutting-down the Tweaki.exe utility	43
1.4.3 Interface of the Tweaki.exe utility	44
1.4.3.1 The Settings panel of the Windows section	45
1.4.3.2 The Settings panel of the Axxon PSIM section	47
1.4.3.2.1 The Settings panel of the DNS section	50
1.4.3.2.2 The Settings panel of the Visitor management system section	51
1.4.3.2.3 The Settings panel of the Distributed configuration section	52
1.4.3.2.4 The Settings panel of the MSDE (MS SQL) configuration section	54
1.4.3.3 The Settings panel of the Video subsystem section	55
1.4.3.4 The Settings panel of the Testing video capture cards section	58
1.4.3.5 The Settings panel of the PTZ section	59
1.4.3.6 The Settings panel of the POS PSIM section	60
1.4.3.7 The Settings panel of the Version section	61
1.4.4 Typical tasks concerning system extended settings	62
1.4.4.1 Enabling and configuring the debug mode of Axxon PSIM	63
1.4.4.2 Extended setup of the distributed architecture	66
1.4.4.3 Changing computer names and IP addresses in the Axxon PSIM configuration database	67
1.4.4.4 Limiting memory usage by an MS SQL server	68

1.4.4.5	Re-indexing the audio and video recordings archive	69
1.4.4.6	Enabling the Pure video/CUDA hardware acceleration	70
1.4.4.7	Testing video capture cards	71
1.5	The utility for collecting configuration data on servers and RWS for the Technical Support	72
1.5.1	The purpose of the Support.exe utility	73
1.5.2	Starting and shutting-down the Support.exe utility	74
1.5.3	The Support interface description	75
1.5.4	Collecting information about videosevers and remote workstations using the Support.exe utility	76
1.6	The Fps.exe utility for productivity estimation	78
1.6.1	The purpose of the Fps.exe utility	79
1.6.2	Starting and shutting-down the Fps.exe utility	80
1.6.3	Using the Fps.exe utility	81
1.7	The ddi.exe utility for editing database templates and external settings files	85
1.7.1	Editing psim.dbi and psim.ext.dbi database templates using the ddi.exe utility	86
1.7.2	Editing the external setting file (Axxon PSIM.ddi) using the ddi.exe utility	88
1.7.2.1	General information on editing the external setting file	89
1.7.2.2	The Names tab	90
1.7.2.3	The Events tab	91
1.7.2.4	The Reactions tab	92
1.7.2.5	The Icons tab	93
1.7.2.6	The States tab	94
1.7.2.7	The Transition rules tab	95
1.7.2.8	Example of editing the Axxon PSIM.ddi file to reduce database load	96
1.8	The Arpedit.exe utility for creating user dialog windows	97
1.8.1	User's Manual for ArpEdit	98
1.8.1.1	Introduction into User's Manual for ArpEdit	99
1.8.1.2	General principles of operating ArpEdit	100
1.8.1.2.1	Starting and shutting down ArpEdit	101
1.8.1.2.2	Description of the interface elements of the ArpEdit utility	103
1.8.1.2.3	Creating ArpEdit objects	104
1.8.1.2.4	Setting object display variables	106
1.8.1.3	Creating dialog boxes	112
1.8.1.3.1	Creating a dialog box form	113
1.8.1.3.2	Saving the dialog box form	118
1.8.1.3.3	Accessing the dialog box from Axxon PSIM	119
1.8.1.3.4	Example of creating a dialog bog to count the number of movements	121
1.8.1.4	Working with badge forms	123
1.8.1.4.1	Creating a badge form	124
1.8.1.4.2	Saving badge forms	128
1.8.1.4.3	Printing badges	129
1.8.1.5	APPENDIX 1. Interface elements of the ArpEdit utility	130
1.8.1.5.1	System menu	131
1.8.1.5.2	Toolbar	132
1.8.1.5.3	Workspace	133

1.8.1.6 APPENDIX 2. Entering text using the editor	134
1.9 Configuration check tool	135
1.9.1 Starting and shutting down the Configuration check tool	136
1.9.2 Configuration check tool interface description	138
1.9.3 Using the Configuration check tool	140
1.9.3.1 Creating a template	141
1.9.3.2 Downloading and editing the template	143
1.9.3.3 Verifying and correcting the configuration	144
1.10 Index.exe utility for reindexing archive files	146
1.10.1 The purpose of Index.exe utility	147
1.10.2 Starting and shutting down the utility	148
1.10.3 Using the Index.exe utility	149
1.11 The shedule.exe utility for creating a replication query file	150
1.11.1 The purpose of the shedule.exe utility	151
1.11.2 Starting and shutting-down the schedule.exe utility	152
1.11.3 Using the schedule.exe utility	154
1.11.3.1 Creating the query file for replication	155
1.11.3.2 Saving the query file	156
1.11.3.3 Opening the query file	157
1.12 The SyncProtocol.exe utility to synchronize event log database	158
1.12.1 The purpose of the SyncProtocol.exe utility. Starting and shutting-down the utility	159
1.12.2 Synchronization of event log database using the SyncProtocol.exe utility	160
1.13 The Axxon Player utility for viewing and converting the video archive	161
1.14 The openRTSP.exe utility for checking RTSP workability	162
1.15 The Convert.exe utility for correcting modification dates of video archives	163
1.15.1 The purpose of the Convert.exe utility	164
1.15.2 Starting and shutting-down the Convert.exe utility	165
1.15.3 Restoring changed creation dates using the Convert.exe utility	166
1.15.4 Working with the Convert.exe utility using the command prompt	167
1.16 The SignCheck.exe utility for checking the authenticity of exported frames	168
1.16.1 Starting and shutting-down the SignCheck.exe utility	169
1.16.2 The purpose of the SignCheck.exe utility	171
1.16.3 Using the SignCheck.exe utility	172
1.17 The idb.exe utility for converting databases, selecting database templates and making backup copies of databases	173
1.17.1 The purpose of the idb.exe utility	174
1.17.2 Running and shutting down the utility	175
1.17.3 Interface elements of the idb.exe window	176
1.17.4 Using the idb.exe utility	179
1.17.5 Working with idb.exe utility with the use of keys	181
1.17.6 Extracting event protocol into an individual database	182
1.17.7 Creating the database backup copy	188
1.17.8 Restoring database from backup copy	191

Additional utilities for the Axxon PSIM software

Summary of the Axxon PSIM utilities

The utility for reading video capture card code and dongle

- The purpose of the CodeReader.exe utility
- Starting and shutting-down the utility
- Using the CodeReader.exe utility
- Portable version CodeReader_portable.exe

Converter.exe utility for converting video and audio archives

- The purpose of the Converter.exe utility
- Starting and shutting-down the Converter.exe utility
- Converter.exe interface
 - The Archive's Converter dialog box
 - The Export Settings dialog box
 - A dialog box for choosing the video codec
 - A dialog box for choosing the audio format
- Using the Converter.exe utility
 - General description of the Converter.exe utility
 - Selecting an archive to be played or converted
 - Searching for a video recording
 - Searching for a fragment in a recording
 - Searching for a frame in a recording
 - Recording playback
 - Converting video and audio archives to AVI files
 - Exporting recordings and frames
 - Using a command prompt to work with the Converter.exe utility
 - Printing a frame
 - Exporting video with titles

Tweaki.exe utility for advanced setup of the Axxon PSIM software system

- The purpose of the tweaki.exe utility
- Starting and shutting-down the Tweaki.exe utility
- Interface of the Tweaki.exe utility
 - The Settings panel of the Windows section
 - The Settings panel of the Axxon PSIM section
 - The Settings panel of the DNS section
 - The Settings panel of the Visitor management system section
 - The Settings panel of the Distributed configuration section
 - The Settings panel of the MSDE (MS SQL) configuration section
 - The Settings panel of the Video subsystem section
 - The Settings panel of the Testing video capture cards section
 - The Settings panel of the PTZ section
 - The Settings panel of the POS PSIM section
 - The Settings panel of the Version section
- Typical tasks concerning system extended settings
 - Enabling and configuring the debug mode of Axxon PSIM
 - Extended setup of the distributed architecture
 - Changing computer names and IP addresses in the Axxon PSIM configuration database
 - Limiting memory usage by an MS SQL server
 - Re-indexing the audio and video recordings archive
 - Enabling the Pure video/CUDA hardware acceleration
 - Testing video capture cards

The utility for collecting configuration data on servers and RWS for the Technical Support

- The purpose of the Support.exe utility
- Starting and shutting-down the Support.exe utility
- The Support interface description
- Collecting information about videosevers and remote workstations using the Support.exe utility

The Fps.exe utility for productivity estimation

- The purpose of the Fps.exe utility
- Starting and shutting-down the Fps.exe utility
- Using the Fps.exe utility

The ddi.exe utility for editing database templates and external settings files

- Editing psim.dbi and psim.ext.dbi database templates using the ddi.exe utility
- Editing the external setting file (Axxon PSIM.ddi) using the ddi.exe utility
 - General information on editing the external setting file
 - The Names tab
 - The Events tab
 - The Reactions tab
 - The Icons tab
 - The States tab
 - The Transition rules tab
 - Example of editing the Axxon PSIM.ddi file to reduce database load

The Arpedit.exe utility for creating user dialog windows

- User's Manual for ArpEdit
 - Introduction into User's Manual for ArpEdit
 - General principles of operating ArpEdit
 - Starting and shutting down ArpEdit
 - Description of the interface elements of the ArpEdit utility
 - Creating ArpEdit objects
 - Setting object display variables
 - Creating dialog boxes
 - Creating a dialog box form
 - Saving the dialog box form
 - Accessing the dialog box from Axxon PSIM
 - Example of creating a dialog box to count the number of movements
 - Working with badge forms
 - Creating a badge form
 - Saving badge forms
 - Printing badges
 - APPENDIX 1. Interface elements of the ArpEdit utility
 - System menu
 - Toolbar
 - Workspace
 - APPENDIX 2. Entering text using the editor

Configuration check tool

- Starting and shutting down the Configuration check tool
- Configuration check tool interface description
- Using the Configuration check tool
 - Creating a template
 - Downloading and editing the template
 - Verifying and correcting the configuration

Index.exe utility for reindexing archive files

- The purpose of Index.exe utility
- Starting and shutting down the utility
- Using the Index.exe utility

The shedule.exe utility for creating a replication query file

- The purpose of the shedule.exe utility
- Starting and shutting-down the schedule.exe utility
- Using the schedule.exe utility
 - Creating the query file for replication
 - Saving the query file
 - Opening the query file

The SyncProtocol.exe utility to synchronize event log database

- The purpose of the SyncProtocol.exe utility. Starting and shutting-down the utility

- Synchronization of event log database using the SyncProtocol.exe utility

The Axxon Player utility for viewing and converting the video archive

The openRTSP.exe utility for checking RTSP workability

The Convert.exe utility for correcting modification dates of video archives

- The purpose of the Convert.exe utility
- Starting and shutting-down the Convert.exe utility
- Restoring changed creation dates using the Convert.exe utility
- Working with the Convert.exe utility using the command prompt

The SignCheck.exe utility for checking the authenticity of exported frames

- Starting and shutting-down the SignCheck.exe utility
- The purpose of the SignCheck.exe utility
- Using the SignCheck.exe utility

The idb.exe utility for converting databases, selecting database templates and making backup copies of databases

- The purpose of the idb.exe utility
- Running and shutting down the utility
- Interface elements of the idb.exe window
- Using the idb.exe utility
- Working with idb.exe utility with the use of keys
- Extracting event protocol into an individual database
- Creating the database backup copy
- Restoring database from backup copy

Export to PDF

Summary of the Axxon PSIM utilities

Additional *Axxon PSIM* software utilities are separate software applications intended to perform additional operations when setting up and working with *Axxon PSIM* software. This document describes the following utilities:

1. The utility for reading video capture card code and dongle
2. Converter.exe utility for converting video and audio archives
3. Tweaki.exe utility for advanced setup of the Axxon PSIM software system
4. The utility for collecting configuration data on servers and RWS for the Technical Support
5. The Fps.exe utility for productivity estimation
6. The SignCheck.exe utility for checking the authenticity of exported frames
7. The Convert.exe utility for correcting modification dates of video archives
8. The ddi.exe utility for editing database templates and external settings files
9. The Arpedit.exe utility for creating user dialog windows
10. The idb.exe utility for converting databases, selecting database templates and making backup copies of databases
11. Configuration check tool
12. Index.exe utility for reindexing archive files
13. The shedule.exe utility for creating a replication query file
14. The Axxon Player utility for viewing and converting the video archive

The utility for reading video capture card code and dongle

The purpose of the CodeReader.exe utility

The CodeReader.exe utility is designed to read the dallas code of the cryptochip (chip) of the video capture card, which determines the card type, HID of computer and the number of the Guardant dongle.


 **Note.**

For proper operation of the utility Axxon PSIM™ is to be shut down.

Starting and shutting-down the utility


To start the CodeReader.exe utility, do one of the following:


1. Start the utility from the Windows taskbar. Click **Start**, then **All Programs**, then **Axxon PSIM**, then **Tools**, then **Read hardware codes**. The CodeReader.exe utility is available for the following types of Axxon PSIM™ installation: Server and Remote Admin Workstation.



2. Start the utility from the **Tools** folder of the *Axxon PSIM* folder. Example: C:\Program Files\Axxon PSIM\Tools\CodeReader.exe.


The Code Reader dialog box will open.



To shut down the CodeReader.exe utility, click the  button.

Using the CodeReader.exe utility

The CodeReader.exe utility allows determining the type of installed video capture card by its dallas code(s), HID of computer, as well as the number of the Guardant dongle. To read this information, start the utility (see the [Starting and shutting-down the utility](#) section). The type of video capture card, its dallas code(s) and the number of the Guardant dongle and HID will be displayed in the Code Reader dialog box.



The number of dallas codes depends on the number of chips on the video capture card. Figure shows that the FS6 card with 4 chips has been used.

Portable version CodeReader_portable.exe


The portable version of the utility for reading the video capture card codes and dongles is the executable file CodeReader_portable.exe. This file can be downloaded from the official AxxonSoft website.

The CodeReader_portable.exe file can be launched on any computer even without Axxon PSIM installed.

⚠ Attention!

For the portable version of the utility to operate, you need to install the latest versions of the Visual C++ redistributable packages for Visual Studio.

To check the availability of the Visual C++ redistributable packages for Visual Studio, select **Start -> Control Panel -> Programs -> Programs and Features**.



If there are no redistributable packages, you can download them from the official website at: <https://learn.microsoft.com/en-us/cpp/windows/latest-supported-vc-redist?view=msvc-170>, or install the file that is available in Axxon PSIM installation directory in the **Redist -> Dotnet4.5** folder.

The purpose and interface of the portable version, as well as the procedure for working with it are similar to the standard version of the CodeReader.exe utility – see [The utility for reading video capture card code and dongle](#).

Converter.exe utility for converting video and audio archives

The purpose of the Converter.exe utility

Important!

Correct operation of the Converter.exe utility on Windows 10 and newer OSes is not guaranteed.

The Converter.exe utility is designed to play video and audio archives, and to convert them to standard formats: MPEG, DivX, etc.

Besides video and audio playback, Converter.exe utility is used for:


1. Converting audio and video files.
2. Copying the files from the archive to another folder with no data loss.

Note.

If video and audio were synchronized at the time of recording, the converted video file will contain sound track.

The utility can be started from the **Tools** folder of the *Axxon PSIM* program folder or from the **Start** menu: **Start -> Programs -> Axxon PSIM -> Utilities -> Playback and Conversion**.


The utility dialog box is shown in the figure.



Starting and shutting-down the Converter.exe utility


To start the Converter.exe utility, do one of the following:

1. Start the utility from the Windows taskbar. Click **Start**, then **Programs**, then **Axxon PSIM**, then **Video player and file converter**. The Converter.exe utility is available from the **Start** menu with the following installation types of the Axxon PSIM software: Server, Remote administrator workstation, Remote client.



2. Start the utility from the Tools folder of the *Axxon PSIM* program folder. Example: C:\Axxon PSIM\Tools\converter.exe.

Archive Converter dialog box will open.




To close the Converter.exe utility, either click the cross button in the top right corner of the dialog box, or press Alt+F4 on the keyboard.

Converter.exe interface


The Archive's Converter dialog box

The dialog box of the converter.exe utility is shown in the figure.



The Archive's Converter dialog box comprises of the following elements:


1. The screen to play back recordings (1);
2. The control panel for video and audio recordings playback (2).
The elements of the control panel are described in the table.




Nº	Element name	Description
1	Recording start date and time	Fields for entering the approximate start date and time of the video or audio recording
2	Recording end date and time	Fields for entering the approximate end date and time of the video or audio recording
3	Go to first / last frame	Buttons for quick moving of the slider to the beginning or the end of the recording

4	Device	Drop-down list field for selecting the device (camera, microphone), for which the recording should be found in the archive
5	Device number	Drop-down list field for selecting the number of the device, for which the recording should be found in the archive
6	Search	Button for starting the search of recordings in the archive of the chosen device. The recordings are searched in the entire archive of the device. After the search is completed it is possible to specify the approximate beginning and end date and time for required recording
7	Playback panel	The panel contains typical standard functions (from left to right): backward, play, pause, stop, forward
8	Time scale	The scale allows monitoring the playback progress and moving between the frames. To move between the frames, drag the slider or use the playback panel buttons in a per frame playback mode
9	Export setup	The button for opening the Export Setup dialog box
10	Exported recording limits	The buttons for setting the first and the last frames of the exported record
11	Hide/show the list	The button for hiding and showing the list of selected recordings
12	Add to list	The button for adding the selected recording (recording segment) to the list
13	Print frame	The button prints the current frame
14	Frame export	The button exports the current frame in a specified format. A dialog box opens for selecting the folder on the disk and entering the file name
15	Export to AVI or archive	The button for starting the export of the recording (a recording segment) in the specified format. A dialog opens for selecting the device name, which made the recording. On export start, a folder is created for saving the exported recordings (by default, C:\Backup)

The Export Settings dialog box

To open the **Export Settings** dialog box, click the  button in the **Archive's Converter** window. The **Export Settings** dialog box will open, allowing to specify export parameters.



No	Parameter name	Field type	Description	Format	Default value	Value range
The Choose folder group						
1	Destination	Type-in the value	Type-in the folder on the disk to store the exported files (by default the Backup folder is created on disk C:)	-	-	-
2	Volume Size, MB	Type-in the value	Type-in the maximum value of the volume (file) size containing one or more recordings. If the size of recording for export exceeds the set one, then it will not be split. When the recording is added to the volume, the size of recording is expected to equal the mean value of sizes of all added recordings. A new recording is added to the volume if it does not exceed the volume size. A real size of recording can differ from the assumed one, therefore the volume size can exceed the assumed one. If the Break To Alarms checkbox is checked, each volume will contain one recording only. The field is disabled if the Native Archive parameter is activated	MB	650	0 to 2000 MB


3	Frames per second	Select in a drop-down list	Type-in the amount of grooming of the video recording	fps	RealTime	0.5; 1; 3; 5; 15; 30; RealTime
4	Native Archive AVI File	Select a radio-button	If the Native Archive radio-button is selected, then archive fragments will be exported keeping the creation time, but with no AVI conversion. If the AVI File radio-button is selected, then the fragment is converted to the AVI format using the specified codec	-	AVI File	1. Native Archive 2. AVI File
5	Break To Alarms	Checkbox	The checkbox is for selecting the way of storing the archive export fragments to volumes (files of specified size): the recordings for each alarm will be saved to separate volumes (files)	-	Unchecked	Unchecked – the file (volume) will contain a fragment of the size specified in the Volume Size, MB field Checked – the volume will contain a fragment related to one alarm only
6	Native Format	Checkbox	If the Native Format checkbox is checked, then video recordings are exported to AVI file without recompression, i.e. in the same format as in Axxon PSIM archive. To playback these AVI files on the computer without Axxon PSIM software package installed, install components from Axxon PSIM distributive beforehand: 1. \Redist\VC2005_SP1\vccredist_x86.exe 2. \Redist\CamMonitor\CamMonitorInstaller.exe Note. To playback AVI files use Windows Media Player	-	Unchecked	Unchecked – Axxon PSIM archive is exported to AVI file with recompression Checked - Axxon PSIM archive is exported to AVI file without recompression
The Frame Export group						
7	Bitmap Jpeg	Select a radio-button	If the Bitmap radio-button is selected, then the file is saved in Bitmap format. If the Jpeg radio-button is selected, then the file is saved in Jpeg format			
8	Quality	Set the slider	The parameter specifies the quality level of the exported file. The value of 100% results in no quality loss	%	80	0 to 100
The Compression group						
9	Video	Click the button	The button is for selecting and setting up the video codec used to compress video recordings. If the Native Archive radio-button is selected or the Native Format checkbox is checked, then this button is disabled	-		-
10	Field next to the Video button	Not to be edited	The field shows the info on selected video codec. If the Native Archive radio-button is selected, then this field is disabled	-	Full Frame (Uncompressed), Quality: 0	The list of codecs found by the utility
11	Audio	Click the button	The button is for selecting and setting up the quality of the exported audio. The Native Archive radio-button is selected, then this button is disabled	-	-	-
12	Field next to the Audio button	Not to be edited	The field shows the selected audio format	-	PCM, 8000 kHz; 16 bit; Mono	The list of quality levels detected
The Screen group						
13	Overlay	Checkbox	If the Overlay checkbox is checked, there is DirectDraw conversion	-	Checked	Checked – use DirectDraw for conversion Unchecked – do not use DirectDraw for conversion

14	Always On Top	Checkbox	If the Always On Top checkbox is checked, then Converter window is always over all other windows	-	Unchecked	Checked – the window is displayed on top Unchecked – the window is not displayed on top
15	Keep Aspect Ratio	Checkbox	If the Keep Aspect Ratio checkbox is checked, the aspect ratio of Converter window is fixed	-	Unchecked	Checked – 3:2 ratio is kept when the size of the dialog box is changed Unchecked – 3:2 ratio is not kept when the size of the dialog box is changed
16	Split AVI files	Checkbox	Activates export of selected video recordings to the separate AVI files. Note. <i>If the checkbox is not checked, video recordings from one camera are exported to one AVI file</i>	-	Checked	Checked - video recordings are exported to the separate AVI files Unchecked – video recordings are exported to one AVI file
17	Digital signature	Checkbox	Activates adding digital signature that is used for checking frame authenticity to exported frames. Note. <i>Checking frame authenticity is performed using SignCheck.exe utility (see The SignCheck.exe utility for checking the authenticity of exported frames and video recordings section)</i>	-	Unchecked	Checked – digital signature is added Unchecked – digital signature is not added

If a microphone was selected as a device in the dialog box of Converter.exe utility, only the **Audio** button and the **Screen** group are enabled.

A dialog box for choosing the video codec

The Video button in the **Export Setup** dialog box opens a dialog box for choosing a video codec to be used for video compression.




No	Parameter name	Field type	Description	Format	Default value	Value range
1	Compressor	Select from drop-down list	The button allows selecting and setting up the video codec used to convert and compress the video image	Codec name	Full frames (no compression)	All video codecs recognized by the operating system
2	Compression quality	Drag the slider	The slider allows setting the compression level. The zero position of the slider represents the highest compression and lowest quality. Changing this parameter is enabled if the codec is selected in the Compression Program field	%	0	0 to 100
3	Configure	Click the button	The button opens the settings panel of the video codec. See the codec manual for details	-	-	-
4	About	Click the button	The button opens an information box with codec details	-	-	-

Note.

If AVI format is used, the resultant file size should not exceed 2 GB.

A dialog box for choosing the audio format

The **Sound** button in the **Export Setup** dialog box opens a dialog box for choosing an audio format.



No	Parameter name	Field type	Description	Format	Default value	Value range
1	Name	Select from drop-down list	The field allows choosing the name for the selected audio format	Format name	Untitled	Untitled CD Quality Radio Quality Telephone Quality Compact disk
2	Format	Select from drop-down list	The field for selecting the format	Format name	PCM	The list of audio formats used by the utility
3	Attributes	Select from drop-down list	The list of sound characteristics: playback/recording frequency (8000 kHz), digitizing level (8, 16, etc bits), channel type (mono/stereo)	Parameter values	PCM, 8000 kHz, Mono	The list of characteristics, recognized by the operating system
4	Save as...	Click the button	<p>The button allows creating a unique name for the selected format. To save a format under a unique name:</p> <ol style="list-style-type: none"> 1. Select Untitled in the Name field. 2. Select the values in the Format and Attributes fields. 3. Click the Save As button 4. Enter a unique name in the Save This Format As field and click OK. <p>The newly created name will appear in the Name drop-down list.</p>	String	-	-

Using the Converter.exe utility

General description of the Converter.exe utility

The Converter.exe utility is designed to convert and play back audio and video recordings from the archive and save them to a specified folder.


Using the Converter.exe utility includes:

1. Starting the utility (see [Starting and shutting-down the Converter.exe utility](#)).
2. Selecting an archive (see [Selecting an archive to be played or converted](#)).
3. Finding a recording in the selected archive (see [Selecting an archive to be played or converted](#)).
4. Playback of the recording (see [Recording playback](#)).
5. Finding the required recording fragment or frame (see [Searching for a video recording](#)).
6. Setting the export or conversion parameters (see [Converting video and audio archives to AVI files](#)).
7. Exporting the fragment or printing the frame (see [Exporting recordings and frames](#)).
8. Shutting-down the Converter.exe utility (see [Starting and shutting-down the Converter.exe utility](#)).

Selecting an archive to be played or converted


To search an archive for a recording, do the following:

1. Select the device the recording was made by, and its number (1).
2. Click the **Search** button (2).



3. Select the location of the archive (folder with archives for specific date and time) on an appropriate disk.



4. Click the  button.
5. Specify the time limits in the date/time fields (3).

The first frame of the required recording will be displayed in the video playback screen.

i Note.

In case of searching for an audio recording, no visible signs of finding the recording will be shown. To check that a recording was found, play it.

i Note.

Speed of records search directly depends on their number. The search process can take a lot of time if the archive depth is rather big and reading is performing from the network disk.

i Note.

If video files that are to be opened were not recorded, but copied, then start the Convert.exe utility to open the archive (see [The Convert.exe utility for correcting modification dates of video archives](#) section):

- If the archive is created in the same time zone as it is viewed, then start the utility with the fullmode parameter:
convert.exe fullmode
- If the archive is created in different time zone than it is viewed, then move the archive to the current time zone by starting the utility with the following parameters in the command prompt:
convert.exe fullmode TZ +hh:mm
where +hh:mm is the time shift between the current time zone and the time zone of the archive.






Otherwise, the folders with video files fail to open.

Searching for a video recording

After the approximate time interval is selected using the date/time fields, and the required archive is found, it may be necessary to find a particular fragment or frame to be played or exported.

Searching for a fragment in a recording



To find the required video fragment in the selected recording, do the following:

1. Click the **Play** () button in the playback control panel.
2. When the required fragment appears, click the **Pause** () button.
3. Click the **Fragment Start** () button to make the current frame the start of the fragment.
4. Click the **Play** () button in the playback control panel.
5. When the required fragment ends, click the **Fragment End** () button to make the current frame the end of the fragment. All subsequent frames will be omitted.



The resultant recording fragment will then be available for conversion or export, maintaining the format and the creation date.

Searching for a frame in a recording

To find a particular frame in the selected recording, do the following:

1. Click the **Play** () button in the playback control panel.
2. When the required frame appears, click the **Pause** () button to enter the per frame playback mode.


 **Note.**

If the recording is to be played back in the per frame playback mode starting with the first frame, then click the **Pause** () button instead of the **Play** () button.

3. Keep clicking the **Fragment Forward** () and **Fragment Back** () buttons, to browse the frames until the required frame appears on the screen.

The resultant frame may be printed or used as a starting frame for a fragment (see [Searching for a fragment in a recording](#) section).

 **Note.**



To quit the per frame playback mode, click the **Pause** () button once more.

Recording playback

The recording selected by date and time, can be played in Converter.exe player using the playback control panel.



The panel contains five control buttons (left to right on the figure): **Back**, **Play**, **Pause**, **Stop**, **Forward**, allowing to play, pause, stop and browse the records.

1. If the **Stop** button is down (clicked), then it is possible to move between the recording segments by clicking the **Forward** or **Back** buttons. The recording segment means one of the following:
 - a segment of video recording between the commands to start and stop recording if the recording was initiated manually (for example, via a script or the camera's context menu);
 - a segment of video recording between the beginning and the end of the detection tool triggering, taking into account the periods of pre- and post-recording in case the recording was initiated by any detection tool.
2. A short press of the **Play** button starts playing the recording segment from start to end. If the recording contains several recording segments, the **Play** button should be clicked to play each of them.
3. To play a record consisting of several segments without stopping, press and hold the **Play** button for 1-2 seconds. The button then changes its appearance from  to . To stop playback, click **Stop**.
4. To play the recording in the frame-by-frame mode: a) click **Play**, b) click **Pause**, c) keep clicking **Forward** or **Back** to view frames one by one.
5. To view the recording segment in accelerated mode click the **Play** button and then click the **Forward** to accelerate twice relatively the previous speed. The current playback speed is displayed in titles above video image.
6. To view the record section in slow motion, click the **Play** button and then click the **Back** to slow down twice relatively the previous speed. The current playback speed is displayed in titles above video image.

Converting video and audio archives to AVI files

Video and audio archives are converted into AVI format according to Converter.exe settings, using the **Export Setup** dialog box. The level of compression of the exported recording is determined by the following parameters:

1. **Frames Per Second** parameter – setting the parameters of the recording grooming;
2. **Video** button – selection of the video codec, in case of video archive export;
3. **Sound** button – set the sound quality parameters (frequency, bitrate, etc), in case of audio archive export.



Note.

If AVI format is used, the resultant file size should not exceed 2 GB.


Exporting recordings and frames

Export of the recordings is one of the main functions of the Converter.exe utility. There are two ways of exporting records from an archive:


1. Export to AVI option converts (compresses) a recording and breaks it down into volumes (files of the size specified in the Export Setup dialog box).

To export the recording as AVI, do the following:

- a. Find the recording in an archive (see the [Selecting an archive to be played or converted](#) section).
- b. In the **Export Setup** dialog box, select the **Export to AVI** radio-button.
- c. Click the **Video** or **Sound** button to specify the conversion parameters. Click the **OK** button.
- d. Click the **Export to AVI/Archive** button () to start exporting.
- e. Enter the name of the device folder to save the recording to (1), then click **Continue** (2).



The export progress will be shown in the title bar of the Converter.exe window.



The title bar will read **Complete**, when exporting is completed. To verify the results, open the Backup folder and find the file named after the device from which archive the recording was exported.

2. The Export to Archive option allows copying the files from an archive to another location on the disk with no conversion, maintaining the recording creation date and an option for breaking it down into volumes.


To export a recording in the same format as it is stored in the archive, do the following:


- a. Find the recording in the archive (see the [Selecting an archive to be played or converted](#) section).
- b. In the **Export Setup** dialog box, select the **Export to Archive** radio-button.
- c. Specify volume size in the **Export Setup** dialog box. Click the **OK** button.
- d. Click the **Export to AVI/Archive** button () to start exporting.

Note.

If AVI format is used, the resultant file size should not exceed 2 GB.

The Converter.exe utility allows exporting frames into bitmap and JPEG formats. Do the following:

1.
 - a. Find the required frame (see the [Searching for a frame in a recording](#) section).
 - b. In the **Export Setup** dialog box, specify the parameter values in the **Frame Export** group. Click the **OK** button.
 - c. Click the **Export Frame** button ().
 - d. Specify the location to save the exported file to in the **Save As** dialog window.



The file name will be generated automatically in the following format: 1) name and number of the camera where the frame comes from; 2) creation date; 3) creation time. The file extension corresponds to the file format selected in the **Export Setup** dialog box.

- e. Click the **Save** button.

Using a command prompt to work with the Converter.exe utility

Video and frames can be exported with the help of a command prompt using the following commands:

Converter.exe Disc:\File,Number_Cam,StartDate StartTime,StopDate StopTime,CameraName

Converter.exe Disc:\File,Number_Cam,StartDate StartTime,,CameraName



Note.

If **StopDate** and **StopTime** parameters are not specified, then ',' is to be specified instead.

The table describes the command parameters.


Parameter	Description
Disk	Disk for storing exported files
File	Name of a catalogue or file. Note 1. <i>If the catalogue or file specified in the command does not exist, it will be created automatically.</i> Note 2. <i>To export archive (video record in the original format) only catalogue name is to be specified.</i>
Number_Cam	Number of a camera which performs the recording
StartDate	Date of record start (dd-mm-yy)
StartTime	Time of record start (hh:mm:ss)
StopDate	Date of record end (dd-mm-yy). Note. <i>Parameter is not in use while exporting the separate frames</i>
StopTime	Time of record end (hh:mm:ss) Note. <i>Parameter is not in use while exporting the separate frames</i>
Camera Name	Name of the camera that is to be displayed in the titles on the exported video, as well as the name of the folder created in the specified export folder used for storing exported files

The example of using the command prompt to export files is shown in the figure.

```
Select C:\Windows\System32\cmd.exe
Microsoft Windows [Version 10.0.19044.1889]
(c) Microsoft Corporation. All rights reserved.


C:\Program Files (x86)\Axxon PSIM\Tools>Converter.exe C:\Export,1,18-08-22 16:34:03, 18-08-22 16:34:15,Camera 1
C:\Program Files (x86)\Axxon PSIM\Tools>Converter.exe C:\Export\export.avi,1,18-08-22 16:34:03, 18-08-22 16:34:15, Camera 1
C:\Program Files (x86)\Axxon PSIM\Tools>Converter.exe C:\Export\export.jpg,1,18-08-22 16:34:03, 18-08-22 16:34:15, Camera 1
C:\Program Files (x86)\Axxon PSIM\Tools>Converter.exe C:\Export\export.jpg,1,18-08-22 16:34:03, 18-08-22 16:34:15, Camera 1
```

As a result the "export" folder containing the exported files is created on the local disk "C".



Printing a frame


To print a frame, do the following:

1. Find the required frame (see the [Searching for a frame in a recording](#) section).
2. Click the **Print Frame** button ().
3. A standard dialog box for printing and printer setup will be opened.

Exporting video with titles

Video with titles is exported as follows:

1. Run the Converter.exe utility (see [Starting and shutting-down the Converter.exe utility](#)).
2. Call for **Export Settings** dialog window in the opened window of Converter.exe utility and set its groups **Choose folder**, **Frame Export**, **Compression** and **Screen** (see. Interface description of [The Export Settings dialog box](#)).
3. Set the titles displaying in the **Titles group** in the dialog window **Export Settings**; table shows parameters description of the given.



Nº	Parameter name	Parameter description	Value range
1	Point of sale dropdown list	Name of cash terminal, titles from which should be laid over the video recording while viewing and exporting the frames and recordings with the help of Converter.exe utility	Empty value – titles from all the titrates overlay function. No – overlay function is off. Number of cash terminal (from one and above) – function of displaying the titles concerning the given cash terminal.
2	Checkbox Name, Date, Time	When the given checkbox is activated, lines, containing name and number of a camera, date and time of creation of the given video frame, will be laid over the video recording	Yes – lines, containing name and number of a camera, date and time of creation of the given video frame , will be laid over the video recording. No – lines, containing name and number of a camera, date and time of creation of the given video frame , will not be laid over the video recording.
3	Editing text fields X, Y, W, H	Coordinates and area size, taken by titles in the video recording. Is expressed in percentage relative to the screen size of video recording playback	From 0 and above. Depends on the screen size of video recording playback.
4	Font button	Font selection of titles displaying	-



Note.

If the cash terminal is selected, its value will not be saved with the repeated run of Converter.exe utility. On default displaying titles from all the titers is set.

4. To apply the settings it is necessary to click **OK** button. To cancel settings one should click the cross mark in the upper right corner of **Export Settings** dialog window.
5. Dialog window of Converter.exe utility for exporting the required file will open in result (see [Exporting recordings and frames](#)).

Export of video recordings with titles is completed.

Tweaki.exe utility for advanced setup of the Axxon PSIM software system

The purpose of the tweaki.exe utility

The tweaki.exe utility is used for configuring *Axxon PSIM* by editing the sections of the Windows registry, where the setup parameters for the *Axxon PSIM* core and modules are stored:

- For 64-bit systems, the sections are HKLM\SOFTWARE\Wow6432Node\AxxonSoft and HKCU\SOFTWARE\Wow6432Node\AxxonSoft.
- For 32-bit systems, the sections are HKLM\SOFTWARE\AxxonSoft and HKCU\SOFTWARE\AxxonSoft.

The utility should be run as the same Windows user who is used to start *Axxon PSIM*, otherwise the new settings may not apply. This is because the choice of the Windows account determines to which registry section the changes will be written.

Attention!

Invalid values of the registry keys may lead to the system failure.

The tweaki.exe utility provides the following functionality:


1. Setup of *Axxon PSIM* startup (see [The Settings panel of the Windows section](#));
2. Enabling the debug mode of *Axxon PSIM* (see [Enabling and configuring the debug mode of Axxon PSIM](#));
3. Advanced setting of the Video surveillance monitor (see [The Settings panel of the Video subsystem section](#));
4. Advanced setting of events logging (see [The Settings panel of the Axxon PSIM section](#));
5. Advanced setting of video signal processing by Server (see [The Settings panel of the Video subsystem section](#));
6. Advanced setting of distributed architecture (see [Extended setup of the distributed architecture](#));
7. Changing network names and IP-addresses in the configuration database (see [Changing computer names and IP addresses in the Axxon PSIM configuration database](#));
8. Limiting the RAM used by MS SQL server (see [Limiting memory usage by an MS SQL server](#));
9. Advanced setting of audio or video recording to an archive (see [The Settings panel of the Video subsystem section](#));
10. Re-indexing audio and video archives (see [Re-indexing the audio and video recordings archive](#));
11. Selecting the analog video output operation mode [The Settings panel of the Video subsystem section](#));
12. Testing the operability of video capture cards (see [Testing video capture cards](#));
13. Advanced setting of PTZ devices (see [The Settings panel of the PTZ section](#));
14. Advanced setting of *POS PSIM* (see [The Settings panel of the POS PSIM section](#));
15. Displaying versions of *Axxon PSIM* modules (see [The Settings panel of the Version section](#)).

Starting and shutting-down the Tweaki.exe utility

To start the tweaki.exe utility, do one of the following:

1. Start the utility from the Windows taskbar. Click **Start => All Programs => Axxon PSIM => Tools => Advanced settings utility**. The tweaki.exe utility is available from the **Start** menu with the following installation types of *Axxon PSIM*: Server, Remote administrator workstation, Remote client.
2. Start the utility from the **Tools** folder of the *Axxon PSIM* program folder: C:\Axxon PSIM\Tools\Tweaki.exe.

The **Axxon PSIM Advanced Setup** dialog box appears after running the tweaki.exe utility.




To shutdown the tweaki.exe utility and save the changes click **OK**. To shutdown the tweaki.exe utility without saving the changes, click **X**.

Interface of the Tweaki.exe utility

The user interface of the tweaki.exe utility consists of two interrelated elements:


1. Tree of sections (1).
2. Settings panel for each section (2).




Sections tree of the tweaki.exe dialog box has static structure and is used for navigation in the utility. To access the settings panel for the required section, left-click the corresponding tree tab.

The Settings panel of the Windows section

The **Windows** section is used to set Windows running Windows OS. The settings panel for the **Windows** section is shown in the figure.




The parameters of the **Windows** setting panel are described in the table.

No	Parameter name	Field type	Description	Re pr es en tat ion	D ef a ul t v al ue	Value range
The Shell group						
1	The Explorer/ File switch	Set in the position	Selection of Windows working shell Attention! <i>Disable UAC to run the Axxon PSIM software package as the shell. Configuration of the local security policy is required for full disabling of UAC in the Windows 8 and Windows 8.1 OS – see OS settings for correct operation of Remote Admin Workstation or Server</i>	-	Ex pl er	Explorer – Microsoft Explorer is loaded as working Windows OS shell (corresponds to standard Windows OS settings). File – Axxon PSIM starts as a working shell of Windows OS
2	The File field with  button. Active for the File switch position	Button is pressed	Opens standard Windows window «Open» to select shell file of OS Windows. Full path to the file is displayed in the field	-	-	The psim.exe or psim_host.exe executive file is selected as a shell
The Autologon group						
3	The Enable checkbox	Check box	Activates automatic log on of the user to OS Windows	Bo le an ty pe	No	Yes – automatic log on of the user is activated No – automatic log on of the user is not activated


4	The Username field	Type in the value	Set the username for logging on the OS Windows	-	-	Up to 64 characters. Depends on the settings of Windows user account (stored locally or on domain server)
5	The Password field	Type in the value	Set the password for logging on the OS Windows	-	-	8 to 14 characters Depends on the settings of Windows user account (stored locally or on domain server)
6	The Domain field	Automatically	Displays the name of domain server (if there is any), where data concerning user account is stored (user name and password)	-	-	Depends on domain net settings (net settings of OS Windows correspondingly)
7	Restart Axxon PSIM on user login checkbox	Setting checkbox	Specifies the way of restart the <i>Axxon PSIM</i> software installed as a service on user login	Boolean type	Yes	Yes – the <i>Axxon PSIM</i> software installed as a service restarts under the current user if it belongs to the PSIM Users group No – The <i>Axxon PSIM</i> software installed as a service doesn't restart under the current user even for users belonging to the PSIM Users group



The Settings panel of the Axxon PSIM section

The **Axxon PSIM** section is used for *Axxon PSIM* advanced setup. The settings panel for the **Axxon PSIM** section is shown in the figure.



The parameters of the *Axxon PSIM* settings panel are described in the table.

No	Parameter name	Method of setting the parameter value	Description	Representation	Default value	Value range
1	The Core IP address	Enter the value in the field /use the button. Set on the Client	Sets the IP address of the <i>Axxon PSIM</i> server to which the <i>psim_host.exe</i> module is connected by default. In case of pressing  button, IP address of the local computer is set	IP address	127.0.0.1	Depends on net settings of the Server. In case of connection failure dialog window requiring IP address is displayed
2	Keyboard prefix	Enter the value in the field	Sets the prefix for a special keyboard. When a button is pressed on this key-board the <i>Axxon PSIM</i> detects when the button was pressed on this very keyboard	Symbol	—	Usually, a tilde (~), code 126
The Logging subsystem group						


3	Debug mode	Select the value from the drop-down list	Sets the mode of the <i>Axxon PSIM Debug window</i> displaying (see The Debug window)	List of available modes of Debug window displaying	Starting with weekly build 1.0.1.172, the Debug 4 mode is enabled by default. Before this build— Disabled is a default mode	<p>Disabled—Debug window is not displayed</p> <p>Debug 1—Debug window is displayed and a log file containing recordings about modules errors is created</p> <p>Debug 2—Debug window is displayed and a log file containing recordings about modules errors and alerts is created</p> <p>Debug 3—Debug window is displayed and a log file containing recordings about all the modules events is created</p> <p>Debug 4—Debug window is displayed and a log file containing recordings about all the modules events, and also additional menu that is individual for each module (used by programmers) are created</p>
4	Log-storing time (hours)	Enter the value in the field	Sets the time of keeping log files	Sequence	48 hours	> 0
5	Counters logging time (sec)	Enter the value in the field	Assigns the time interval in seconds for logging processor load, memory usage, and disk usage	Sequence	60	Positive whole numbers not less than 60 and zero. If the value 0 is specified, sensor data is not included in the log file
6	Save logs	Set the checkbox	Enables logs saving	Boolean type	Yes	<p>Yes—logs are saved</p> <p>No—logs are not saved</p>
7	Redirect to debugger	Set the checkbox	Enables the debugger	Boolean type	None	<p>Yes—the debugger is in use</p> <p>No—the debugger is not in use</p>
8	Maximum size (MB)	Enter the value in the field	Defines the maximum size of RAM that log files can use. Log files are archived after that size is reached	Sequence	100 MB	<p>>= 100</p> <p>Values less than 100 Mb are ignored</p>
The JPG and AVI files export path group						
9	The Default (Axxon PSIM\Export)/Other switch	Set in the position	Sets the folder for exported frames from <i>Axxon PSIM</i> video archive (see Frame export)	—	Default (Axxon PSIM\Export)	<p>Default (Axxon PSIM\Export)—exported to the C:\Users%\current user name%\Documents\Axxon PSIM\export\ folder</p> <p>Other—exported to the selected folder</p>
10	The Other field with the  button	Click the button /enter the value in the field	<p>Sets the path name to the folder, where frames from video archive are to be exported when the switch is set in the Other position.</p> <p>Note. The specified path will be applied to the ExportDir registry key located in <i>HKLM\SOFTWARE\WOW6432Node\AxxonSoft\AxxonPSIM\Video</i> (see Registry keys reference guide)</p>	Path name	—	—
11	Open folder	Click the button	Opens the current folder for frame export	—	—	—
12	Record path	Set the checkbox	<p>The checkbox allows you to prohibit changing the export directory when exporting an archive period</p> <div style="border: 1px solid gray; padding: 5px; margin-top: 10px;"> <p> Note</p> <p>The selected value is written to the ExportDirFixed registry key located in <i>HKLM\SOFTWARE\WOW6432Node\AxxonSoft\AxxonPSIM\Video</i> (see Registry keys reference guide).</p> </div>	Boolean type	No	<p>Yes—export catalogue change is forbidden</p> <p>No—export catalogue change is allowed</p>
No group						

13	Receive uncompressed video	Set the checkbox	Enables receiving uncompressed video from the Server. As a rule is set on the Client	Boolean type	No	Yes —Client receives uncompressed video from the Server No —Client receives compressed video from the Server
14	Event viewer over all windows	Set the checkbox	Enables displaying the Event viewer window over all windows	Boolean type	No	Yes —the Event viewer window is displayed over all windows No —the Event viewer window is displayed if a corresponding screen is selected
15	Only local protocol	Set the checkbox	Enables logging the events registered in the given computer to the Events protocol database. Note. <i>This parameter can be set on the settings panel of the C omputer object—see Configuring events logging</i>	Boolean type	No	Yes —events registered in the given computer are recorded to the Events protocol database No —all required events are recorded to the Events protocol database
16	Sort tree objects by ID	Set the checkbox	Enables sorting of objects in the tree by identifier. Note 1. <i>If sorting by name is chosen, and there are numbers in the object name, then the objects will be sorted in alphabetical order. For example, an object with the name "115" will be above the object with the name "15", because in the name "115" the second number is 1, and in the name "15" the second number is 5.</i> Note 2. <i>This key also affects the sorting of objects in the tree when adding the objects to a layer in the Map Editor utility</i>	Boolean type	No	Yes —objects in the tree are sorted by identifier No —objects in the tree are sorted by name
17	Disable protocol	Set the checkbox	Disables events logging to the Event viewer database on this computer. Note. <i>This parameter can be set on the settings panel of the C omputer object—see Configuring events logging</i>	Boolean type	No	Yes —events are not logged to the Event viewer database No —events are logged to the Event viewer database
18	Used memory dump	Set the checkbox	Enables logging .dmp file with a copy of main memory with incorrect shutting down at least one of the system modules to the <i>Axxon PSIM</i> root folder	Boolean type	No	Yes —memory dump is created No —memory dump is not created
19	Support old scripts	Set the checkbox	Enables the support of program tools in <i>Axxon PSIM</i>	Boolean type	No	Yes —both scripts and programs are supported No —only scripts are supported
20	Time synchronization	Set the checkbox	Sets time synchronization of all computers in the distributed system with system time of this computer. Time is automatically synchronized at midnight every 24 hours or when <i>Axxon PSIM</i> is started on the Server that is the source of time synchronization	Boolean type	No	Yes —synchronization is enabled No —synchronization is disabled
21	Overlay in Event protocol	Select the value from the drop-down list	Sets the overlay mode for processing the video signals that can be viewed with the help of the Event protocol object	Names of overlay modes	Overlay 2	None —video signals are not processed by video card Overlay 1 —Direct3D is used Overlay 2 —DirectDraw is used
22	Application language	Select the value from the drop-down list	Assigns the <i>Axxon PSIM</i> interface language	Names of installed languages	—	Depends on the set of installed languages. See Axxon PSIM Software System's interface language

The Settings panel of the DNS section

The **DNS** section is used for setting the automatic connection between the Client and reserve video Servers in case of connection loss with the main Server. In the **DNS** section, it is necessary to specify network names and IP addresses of reserve video Servers as they are not listed in the Windows registry by default.

The settings panel of the **DNS** section is shown in the figure.



The parameters of the settings panel of the **DNS** section are described in the table.

Nº	Parameter name	Method for setting the parameter value	Parameter description	Representation	Default value	Value range
1	System identifier	Enter the value in the field	Sets the network name of the reserve video Server if the connection with main Server is lost	-	-	Depends on the network settings of the reserve video Server
2	IP addresses	Enter the value in the field.	Sets the IP address of the selected reserve video Server	IP address	-	Depends on the network settings of the reserve video Server
3	Allow all names	Click the button	Automatically adds the computers IP addresses, set in the System identifier column, to the IP address column if these IP addresses are enabled and identified	-	-	-



Note


To delete a specified server, select it in the list (click the row) and press Ctrl+Del on the keyboard.

The Settings panel of the Visitor management system section

The **Visitor management system** section is designed for creating common photo database of the *Access Manager* module (is not included into *Axxon PSIM* base configuration, see [Creating a single photograph database](#)). In this section it is necessary to specify netnames of computer where the photos are to be stored. Photos are to be stored in the **Person** folder (<Axxon PSIM>\Bmp\Person).

Note.


The **Person** folder is automatically created when the *Access Manager* module is installed.




The Settings panel of the Distributed configuration section

The **Distributed configuration** section is for *Axxon PSIM* common database adjustment when real computer netnames do not coincide with the names in the database (for instance when the computer with the database is replaced). The section is also used for adjusting IP-address of selected computer in the database.

The settings panel for the **Distributed configuration** section is shown in the figure.



The parameters of the settings panel are described in the table.


Nº	Parameter name	Field type	Description	Representation	Default value	Value range
1	The Select database button	Click the button	Opens the standard Data Link Properties dialog box to choose the database, where netname and/or IP-address are to be changed.	-	-	-
2	The Use current DB button	Click the button	Selection of main <i>Axxon PSIM</i> database	-	-	-
3	The Available systems table	Automatically	Displays the list of netnames of computers that are in selected database	-	-	Netnames of computers connections between which are set on the Architecture tab
4	The New system ID field with  button	Button is clicked and value is selected from the list/ typed in the field.	Specifies a new netname of a computer selected in the Available systems table	-	-	Depends on the current net settings of the required computer. If the network name is longer than 15 characters, then first 15 characters are to be specified as the network name in this field

5	The Update protocol checkbox	Checkbox	Replaces the computer's netname in the Events protocol table of the selected main Axxon PSIM database	Boolean type	No ne	Yes – computer's netname is replaced in the Events protocol table No – computer's netname is not replaced in the Events protocol table
6	The Clear protocol checkbox	Checkbox	Clears the event log from the Events protocol table of the selected main Axxon PSIM database	Boolean type	No ne	No – the list of registered events is not cleared Checked – the list of registered events is cleared
7	The Update DB button	Click the button	Runs the process of updating the selected database in accordance with given settings	-	-	-
8	The Update protocol field	Automatically	Displays updating process of the selected database	-	-	Depends on the structure of the selected database and the given settings
The Change IP address group						
9	The dropdown list with IP-addresses	Select from the list	Specifies IP-address that is to be changed in the selected database	IP-addresses of computers in the selected database	-	Depends on the number of computers connections between which are set on the Architecture tab
10	Field of setting IP-address	Type-in the value in the field	Specifies a new IP-address to be changed in the selected database	IP-address	12 7.0 . 0.1	Depends on the current net settings of the required computer
11	The Edit button	Click the button	Changes the IP-address of the required computer in the selected database	-	-	-

The Settings panel of the MSDE (MS SQL) configuration section

The **MSDE (MS SQL) configuration** section is designed for setting the limits of RAM space for MS SQL Server operation with databases of SQL format. This limitation enhances the performance of the system.

The settings panel for the **MSDE (MS SQL) configuration** section is shown in the figure.




The parameters of the settings panel are described in the table.

Nº	Parameter name	Field type	Description	Representation	Default value	Value range
1	The Select database button	Click the button	Opens the standard Data Link Properties dialog box for choosing the database of MS SQL format the RAM space for which is to be limited.	-	-	-
2	The Use current DB button	Click the button	Selects the main Axxon PSIM database	-	-	-
3	The Maximum memory usage (MB) indicator	Enter the value in the field	Sets the space of RAM in MB for SQL Server operation	MB	4096	Depends on full space of RAM.
4	The SQL database size field	Automatically	Displays the current size of all MS SQL databases on the Server	Positive real number with amount precision – two decimals	-	Depends on the capacity of storage where the database is.

The Settings panel of the Video subsystem section

The **Video subsystem** section is used for advanced configuration of the video subsystem in order to enhance the performance of Axxon PSIM.

The settings panel for the **Video subsystem** section is shown in the figure.



The parameters of the settings panel are described in the table.

No	Parameter name	Method of setting the parameter value	Parameter description	Representation	Default value	Value range
1	Ring	Enter the value in the field	Sets free disk space; when the limit is reached, the earliest recordings will be deleted on loop (see General information on video archiving). If two or more disks are used for video archiving, archiving on current disk is performed till there is FreeMbCritical of free disk space (1000 MB by default, see the info on the key in Registry keys reference guide). Free space set by the Ring parameter is used for recording temporary files. This means that when the limit set by the Ring parameter is reached, the maximum size of the temporary file is Ring (registry key FreeMb). Video can contain less frames than set by the Frame count parameter. <i>Note. Old recordings may get deleted before the remaining disk space reaches the specified value if the disk space is less than 15000</i>	MB	5000	Depends on the hard disk space
2	Frame count	Enter the value in the field	Sets the maximum number of frames in one recording file	Frame	1500	1500 to 10000. We don't recommend changing the default value

3	Recording time	Enter the value in the field /select the value from the list	Sets the length of the file in seconds, restricting fragment's size not by number of frames, but by time of its recording	Time in seconds	0	Unlimited
4	Restart recording on entering the archive	Enter the value in the field /select the value from the list	Enables the restart of recording on entering the archive	Integer	No	<p>0—video fragment that was being recorded at the moment of entering the archive is forcibly stopped, and a new one starts. As a result, the user who enters the archive sees a freeze frame corresponding to the moment of entry</p> <p>>0—the recording is restarted when entering the archive, while positioning in the archive is carried out with a shift back to the specified value in seconds</p> <p>-1—recording is not stopped at the moment of entering the archive</p>
5	Rebuild index	Click the button	Deletes the file that stores indexes. After deleting the file, click the Rebuild index button to restart <i>Axxon PSIM</i> and create a new file with updated indexes	-	-	-
6	Priority	Select the value from the drop-down list	Sets the execution priority of all <i>Axxon PSIM</i> processes	Names of priority processes	Boolean	Realtime, High, Above normal, Normal, Below normal, Low
7	Analog video output	Select the value from the drop-down list	Selects the operation mode of the analog output	Names of available modes	All	<p>All—video signal from a camera is displayed on a separate analog monitor</p> <p>One—video signals from cameras that are connected to different video capture devices, are displayed on a separate analog monitor</p>
8	Use virtual grabber	Set the checkbox	Allows access to virtual Video capture devices settings in <i>Axxon PSIM</i> . <i>Note. Desktop Experience Feature must be enabled when using a virtual video capture device on server OS and avi files</i>	Boolean type	Clear	<p>Set—the Virtual and Virtual bench values are available from the Type drop-down list on the settings panel of the Video capture device objects</p> <p>Clear—the Virtual and Virtual bench values aren't available for the Video capture device objects</p>
9	Hide mask	Set the checkbox	Disables displaying the video hidden by the motion detection mask. Video area marked by motion detection mask will be hidden by a grey fill. This feature works only on uncompressed video from FS or FX local video capture cards	Boolean type	Clear	<p>Clear—video hidden by the mask is displayed</p> <p>Set—video hidden by the mask video isn't displayed</p>
10	Automatic font size selection for export	Set the checkbox	Enables the relative font size for captions (camera No. and time) when exporting a frame or fragments of the video archive	Boolean type	Clear	<p>Clear—when exporting a frame, regardless of the video resolution, the caption size remains constant as set by the SubtitlesFontSize registry key, see the Registry keys reference guide</p> <p>Set—when exporting a frame, the caption size is scaled depending on the video resolution</p>
11	Gradual increment of camera tile	Set the checkbox	Enables a gradual increase of the Surveillance window on the custom layout by double-clicking the left mouse button. All Surveillance windows on the layout must be of the same size to ensure proper operation of the key	Boolean type	Clear	<p>Clear—Surveillance window is expanded to the entire Video surveillance monitor by double-clicking the left mouse button</p> <p>Set—by double-clicking the left mouse button, the Surveillance window is expanded gradually: the first double-click expands it two times of the initial size, the second double-click expands it three times of the initial size, and so on. The Surveillance windows adjacent to it are hidden on the layout</p>
12	Swap frame fields	Set the checkbox	Switches <i>Axxon PSIM</i> from basic to additional driver if there are video artifacts when using the basic driver	Boolean type	Clear	<p>Clear—<i>Axxon PSIM</i> operates with basic driver</p> <p>Set—<i>Axxon PSIM</i> operates with additional driver</p>
13	Use PureVideo /CUDA hardware acceleration	Set the checkbox	Enables PureVideo/CUDA support on the Server when decompressing video from IP devices if PureVideo HD card of the second or third generation (NVIDIA VP2 and VP3) is installed. Used to reduce CPU load due to resources of graphics processor	Boolean type	Set	<p>Clear—PureVideo/CUDA isn't used</p> <p>Set—PureVideo/CUDA is used</p>

14	Pause playback at archive entry	Set the checkbox	The Pause button is clicked when entering the archive	Boolean type	Clear	<p>Set—the Pause button is clicked when entering the archive, you can navigate through the archive using arrow keys</p> <p>Clear—the Pause button isn't clicked when entering the archive</p>
15	Step of digital zoom scale	Enter the value in the field /select the value from the list	Specifies the fractional step of video image zooming	Numbers with the fixed point	2.00	<p>Maximum value depends on the maximum scale of digital zoom (see 17).</p> <p>Minimum value is 1.00</p>
16	Maximum ratio of digital zoom	Enter the value in the field /select the value from the list	Specifies the maximum value of digital zoom of video image	Numbers	16	1-16
17	Cameras without video compression	Enter the value in the field	Specifies the numbers of cameras connected to the video capture cards with compression. There is no compression for these cameras, i.e. the compressor settings in <i>Axxon PSIM</i> are ignored	Camera serial number	-	Depends on the number of cameras registered in the system



Note

Setting the non-zero value to the **Recording time** parameter does not disable the **Frame count** parameter. If the values for both parameters are set, then the file recording will be performed in accordance with the value which comes first. For instance, if the value of **Recording time** is equal to 10 seconds and **Frame count** is equal to 500 frames (by default) and in 10 seconds the fragment consists of 80 frames, then 80-frame file will be recorded.


The Settings panel of the Testing video capture cards section

The **Testing video capture cards** section is designed to test the connection of the cameras to the video capture card.

Note.

To use this functionality *Axxon PSIM* is to be logged off. Otherwise there is "Cards not found" message.

The settings panel for the **Testing video capture cards** section is shown in the figure.




The parameters of the settings panel are described in the table.

No	Parameter name	Field type	Description	Representation	Default value	Value range
1	The Board dropdown list	Dropdown list	Specifies the video capture card which camera connections are to be checked	List of video capture cards	-	Depends on the number of installed video capture cards
2	The Test button	Click the button	Starts the testing process of the video capture card. The <i>Axxon PSIM</i> system is to be closed at the time of testing.	-	-	-
The Channels state table						
3	The Channel column	Automatically	Displays the channels numbers of the selected video capture card	-	-	From 1 to 16
4	The State column	Automatically	Displays the state of camera connections to the channels of the selected video capture cards			Attach – camera is attached Detach – camera is detached

The Settings panel of the PTZ section

The **PTZ** section is used for setting the telemetry control elements.

The settings panel for the **PTZ** section is shown in the figure.




The parameters of the **PTZ** settings panel are described in the table.

No	Parameter name	Field type	Description	Representation	Default value	Value range
1	The Delay between commands (ms) field	Type-in the value	Sets the delay time between executing the commands for PTZ devices This parameter is not supported by IP cameras.	ms	250	No limitations. It is not recommended to change the default value.
2	The Delay by priority (ms) field	Type-in the value	Sets the delay time before switch from the PTZ control to a user with lower or equal priority.	ms	30 000	No limitations. It is not recommended to change the default value.
The Joystick group						
3	The Sensitivity (1-10) field	Enter the value in the field	Sets sensitivity of the joystick: the less value the more sensitivity. If value of parameter is small then camera will react on even small deviations of the joystick. If value of parameter is great the camera will stay fixed until significant deviation of joystick	Sensitivity in conditional units	5	1-10

The Settings panel of the POS PSIM section


The POS section is designed for setting the *POS PSIM* module for controlling cashier operations (is not included in *Axxon PSIM* basic version). Detailed information about *POS PSIM* configuring using the *tweaki.exe* utility is presented in [The settings panel for the POS sections using the *tweaki.exe* utility](#) section in the Administrator's Guide documentation for *POS PSIM* software package.



The Settings panel of the Version section

The **Version** section provides information about *Axxon PSIM* software modules: versions, paths to executable files and .dll libraries, file sizes and dates of creation and modification.

The settings panel for the **Version** section is shown in the figure.




Typical tasks concerning system extended settings

Enabling and configuring the debug mode of Axxon PSIM

On the page:

- [Enabling debug mode](#)
- [Configuring log file parameters](#)

Debug mode is a special operation mode when the **Debug window** is open, and is designed for analyzing the progress of *Axxon PSIM* software operation and for prompt debugging in case errors occur. Log files are created in this mode—they are stored on the disk for a specific time period.




Enabling debug mode


Starting with weekly build 1.0.1.172, the **Debug 4** mode is enabled by default. In previous versions, the **Debug mode** is disabled by default. To enable the **Debug mode**, do the following::

1. Shut down *Axxon PSIM*.
2. Start the *Tweaki.exe* utility (see the [Starting and shutting-down the Tweaki.exe utility](#))
3. Select the **Axxon PSIM** node in the tree on the left side of the utility dialog box.
4. Change the parameter **Debug mode** from **Disabled** to **Debug 1**, **Debug 2**, **Debug 3** or **Debug 4** (see description of modes in [The Settings panel of the Axxon PSIM section](#)).
5. Click the **OK** button.
6. Start *Axxon PSIM*.

The **Debug window** item will appear in the *Axxon PSIM* main control menu.



7. Select **Debug window** in the main control menu to open the **Debug window**. The selected item will be marked with a tick.



To hide the **Debug window**, select the **Debug window** item in the menu once more.

Note

The debug mode slows the system down and uses a lot of system resources. We strongly recommend to enable debug mode for debugging purposes only and to disable it when all the settings are completed.

Note

Find details in the [The Debug window](#) section of [The Script object. Programming using the JScript language](#).

Configuring log file parameters

You can set log keeping parameters both on the *Axxon PSIM* setting panel in the Tweaki.exe utility (see [The Settings panel of the Axxon PSIM section](#)) and using some registry keys:

1. The **Time of log keeping (hours)** parameter means the same as DebugTime registry key. It specifies the number of hours for keeping log files. 48 hours by default.
2. The **Maximum size (MB)** parameter means the same as DebugSize registry key. It specifies the number of megabytes provided for log. 100 MB by default.
3. The DebugZipDays registry key enables the logs archiving in the .gz format and specifies the time period for their keeping. 2 days by default.

Log files are rewritten when the maximum of one of the parameters is reached.

When the **Debug 4** debug mode is enabled, the video.run log file displays the most detailed information about the file system and memory usage of each camera every 10 seconds. To reduce the number of info lines, displayed every 10 seconds, to 6 (this will reduce the size of the log file), it is necessary to add the StatusInfo=0 key.

An example of the displayed information if StatusInfo=1 or no key:

```
Uptime: 00:00:12, memory: 423.0 MB
[FS]Health ok.
[FS]Ring cycles count: 0
[FS]Total index in memory size: 62.7 KB
[FS]Total recorders: 4, MemFile: -1, memFile total size: 16.0 MB, last frame skipped time: none,
WritingQueueSize: 1500, avg speed: 18.99 MB/sec.
[FS]Total readers: 0 (cached frames: 0)
[FS]Total cameras: 4, internal VMDA detectors: 0, external VMDA detectors: 0. zone detectors: 0.
[FS]Camera 1. Writing queue: 1 frames(0% of 1500), size: 0.00 MB(0 ms). Streams(1): 1, total VMDA detectors 0
(int: 0, ext: 0), zone: 0. Grabber_IP_CAM queue size: 0.
[FS]Camera 2. Writing queue: 0 frames(0% of 1500), size: 0.00 MB(0 ms). Streams(1): 2, total VMDA detectors 0
(int: 0, ext: 0), zone: 0. Grabber_IP_CAM queue size: 0.
[FS]Camera 3. Writing queue: 0 frames(0% of 1500), size: 0.00 MB(0 ms). Streams(1): 3, total VMDA detectors 0
(int: 0, ext: 0), zone: 0. Grabber_IP_CAM queue size: 0.
[FS]Camera 4. Writing queue: 0 frames(0% of 1500), size: 0.00 MB(0 ms). Streams(1): 4, total VMDA detectors 0
(int: 0, ext: 0), zone: 0. Grabber_IP_CAM queue size: 0.
Total registered senders: 1
Objects:
VideoFrame: 38(max: 77 at '09-09-22 14:40:13.014')
AudioFrame: 0(max: 5 at '09-09-22 14:40:08.816')
Msg: 73(max: 130 at '09-09-22 14:40:06.733')
```

```
Active[1]
SendVideoFrame(local=1,compressed=1) to 'TAG-5509.1': value: 0 (max 0), delay = 46 ms, 09-09-22 14:40:15.548
Inactive[0](no new data for more than 15 seconds)
```

An example of the displayed information if StatusInfo=0:

```
Uptime: 00:00:12, memory: 427.0 MB
[FS]Health ok.
[FS]Ring cycles count: 0
[FS]Total index in memory size: 52.9 KB
[FS]Total recorders: 4, MemFile: -1, memFile total size: 16.0 MB, last frame skipped time: none,
WritingQueueSize: 1500, avg speed: 7.42 MB/sec.
[FS]Total readers: 0 (cached frames: 0).
```

Find more about registry keys in [Registry keys reference guide](#).

Example.

The **Time of log keeping (hours)** is 720 hours (1 month) and the **Maximum size (MB)** is 100 MB.

One week later the size of log file is 100 MB. It starts being rewritten though the log is kept less than it was specified.

And if DebugZipDays has the value equal to the time period in days to keep logs, then logs are not rewritten – they are archived in the *.gz format and are kept for so long as it was specified in DebugZipDays parameter.

Extended setup of the distributed architecture

Extended setup of the distributed architecture is performed in the **DNS** section; it is intended to create reserve connections between the Client and other cores (Servers) in case of losing connection with the main core. Reserve connections are to be set up for each Client individually.

To create a reserve connection between the Client and a core, do the following:


1. Stop the *Axxon PSIM* software if it was running.
2. Start the Tweaki.exe utility (see the [Starting and shutting-down the Tweaki.exe utility](#)).
3. Select the **DNS** node in the tree on the left side of the utility dialog box (see [The Settings panel of the DNS section](#)).
4. Specify the core computer name and IP-address in the table.
5. Click **OK**.

Changing computer names and IP addresses in the Axxon PSIM configuration database

The **Distributed configuration** node allows changing the computer name and/or IP address in the *Axxon PSIM* database.

To change the computer name in the configuration database, do the following:

1. Shut down *Axxon PSIM* if it runs.
2. Start the *tweaki.exe* utility (see [Starting and shutting-down the Tweaki.exe utility](#)).
3. Select the **Distributed configuration** in the tree on the left side of the utility dialog box (see [The Settings panel of the Distributed configuration section](#)).
4. Select the database containing the computer name to be changed using the **Select database (1)** or **Use current DB (2)** buttons.



As a result the **Available systems (3)** table will show all computer names registered in the selected database.

5. To select the computer name to be changed in the **Available systems** table, right-click an appropriate row. The row will be highlighted.
6. Click the button next to the **New system ID (4)** field to see the drop-down list of available computer names. Select the required computer name in the list. The selected name will appear in the **New system ID** field. Name can also be entered in the field manually.
7. Set one of the following checkboxes: **Update Protocol (5)** checkbox to replace the computer name in the events log, or the **Clear protocol** checkbox to delete all records in the log. Only one of two checkboxes should be set.
8. Click the **Update DB (7)** button. The progress of replacing computer names for a new one will be displayed in the field below the **Update DB** button (8).

To change the IP address in the configuration database, do the following:


1. Do steps 1-4 of the previous instructions.
2. Select the IP address to be replaced from the drop-down list (9).
3. Enter a new IP address into the field (10).
4. Click the **Edit (11)** button.

The IP address in the database will be changed.

Limiting memory usage by an MS SQL server

A certain amount of disk space is allocated for the SQL server for storing its data, functions and other internal structures. Allocated RAM is determined by default by the total RAM resources available for the SQL server in the system. The Tweaki.exe utility allows limiting the amount of RAM allocated for the SQL server. Do the following:

1. Close the *Axxon PSIM* software if it is open.
2. Start the Tweaki.exe utility (see [Starting and shutting-down the Tweaki.exe utility](#) section).



3. Select the **Configure MSDE (MS SQL)** node in the tree on the left side of the utility dialog box (see [The Settings panel of the MSDE \(MS SQL\) configuration section](#)).
4. Select the MS SQL database to limit the allocated RAM by doing one of the following using **Select database (1)** or **Use current DB (2)** buttons.
5. In the **Maximum memory usage (MB) (3)** enter the required amount of memory to be allocated for the SQL server.
6. Click the **OK** button (4).

Re-indexing the audio and video recordings archive

To re-index the audio and video archives, do the following:

1. Close the *Axxon PSIM* software if it is open.
2. Start the *Tweaki.exe* utility (see the [Starting and shutting-down the Tweaki.exe utility](#)).
3. Select the **Video Subsystem** node in the tree on the left side of the utility dialog box (see [The Settings panel of the Video subsystem section](#)).
4. Click the **Rebuild Index** button to delete the INDEX folder with .idx files containing the indexes to the video recording files in the archive.



Note.

Pressing the button **Rebuild index** sets the value of parameter `IndexRebuilding=1` in the register's branch of OS Windows: `HKLM\SOFTWARE\AxxonSoft\PSIM\VIDEO` for 32-bit system (`HKLM\SOFTWARE\Wow6432Node\AxxonSoft\PSIM\VIDEO` for 64-bit). Alterarchive reindexing the value of the parameter `IndexRebuilding=0` is automatically set. When *Axxon PSIM* software is run together with `IndexRebuilding=1` parameter, the archive is reindexed without any attempt to reas it from *.idx files.

5. Click **OK**.
6. Start the *Axxon PSIM* system again. A new INDEX folder will be created in the video archive folder, containing new indexes.

This completes re-indexing of the database.

Enabling the Pure video/CUDA hardware acceleration

It is possible to enable the PureVideo/CUDA hardware acceleration when video signals are decompressed from IP devices. In this case decompression may be carried out by Server's graphics processor and this reduces the load on CPU.

Attention!

It is recommended to update the driver of the card that supports the PureVideo/CUDA hardware acceleration. Drivers are available for downloading at the official web page of NVIDIA (www.NVIDIA.com).

Note.

Detailed information about the PureVideo/CUDA hardware acceleration is given in reference manual of NVIDIA company.

The PureVideo/CUDA hardware acceleration functionality is implemented correctly when Server meets the following requirements of the software platform:

1. Is managed by OS Windows XP/Vista/7.
2. The PureVideo HD video card of the second or third generation is installed (NVIDIA VP2 and VP3).

Note.

Widespread models of video cards that support the PureVideo/CUDA:

1. NVIDIA GeForce GTX 295;
2. NVIDIA GeForce GTX 285;
3. NVIDIA Quadro NVS 450;
4. NVIDIA GeForce 9800 GT;
5. NVIDIA Quadro NVS 420;
6. NVIDIA Quadro NVS 295.

Note.

In the *Axxon PSIM* software package the PureVideo/CUDA hardware acceleration is applied only for video signals' decompression in H264 codec.

Note.

If the resolution more than 1920x1088 is set in the camera, then the PureVideo/CUDA hardware acceleration is not used for *video signals' decompression*.

To enable the PureVideo/CUDA hardware acceleration, do the following:

1. Shutdown the *Axxon PSIM* software package if it was run on the computer.
2. Run the *Tweaki.exe* utility (See the [Starting and shutting-down the Tweaki.exe utility](#) section).
3. Select the **Video subsystem** section in the tree in the upper left corner of the utility's dialog box (see [The Settings panel of the Video subsystem section](#)).
4. Set the **Use PureVideo/CUDA hardware acceleration** checkbox.
5. Click the **OK** button.
6. Go to the settings panel for the **Camera** object.
7. In the **Decompressor** drop-down list select the **H264CudaVP2Decoder** value.
8. Click the **Apply** button.

The PureVideo/CUDA hardware acceleration is now enabled.

Testing video capture cards

To test a video capture card, test its channels using the **Testing video capture cards** module of the Tweaki.exe utility. Do the following:

1. Shut down the *Axxon PSIM* software if it is started.
2. Start the Tweaki.exe utility (see the [Starting and shutting-down the Tweaki.exe utility](#) section).
3. Select the **Testing video capture cards** node in the tree on the left side of the utility dialog box (see [The Settings panel of the Testing video capture cards section](#)).
4. Press **Test** button.

The **Board** field will display the name of the video capture card, and the **Channels state** table will show the information about each channel of the card (number and status). The confirmation of successful testing will be displayed to the right of the **Channels state** table.

The utility for collecting configuration data on servers and RWS for the Technical Support

The purpose of the Support.exe utility

The Support.exe utility is designed for collecting information about the configuration and operating status of the hardware, OS Windows and the Axxon PSIM™ system. The utility generates an archive that can be used by AxxonSoft Technical Support Service for troubleshooting purposes. In case of system malfunction or errors in the Axxon PSIM™ system, do the following:

1. Go to the AxxonSoft tech support server: <https://support.axxonsoft.com/>.
2. Register a new account on the tech support server or log in the registered account.
3. Create an issue for tech support. Attach an archive generated by Support.exe utility.

Information on the issue progress will be sent to the email specified at registration.


 [How to get technical support](#)

Starting and shutting-down the Support.exe utility

To run Support.exe utility, use one of the following methods:

1. From the **Start** menu of OS Windows: **Start -> All programs -> Axxon PSIM -> System's information gathering utility**
2. From the **Tools** folder of the Axxon PSIM program folder: <Axxon PSIM>\Tools\Support.exe

After running the Support.exe, the **Support – Collecting info about system** utility dialog box is displayed.




To close the Support.exe utility, click the **Close** button.

The Support interface description

Support.exe utility interface includes the following elements:

1. Short directions for using the Support.exe (1).
2. A group of settings for specifying data set collection time period (2).
3. **Collect** button to run the process of gathering information (3).
4. Field of displaying the information (4).
5. Table to display and select steps of gathering information, it includes two columns – **Step** and **Status**. In the **Step** column, the short characteristics of information gathering process step is displayed and the step can be cancelled before the information gathering starts. In the **Status** column there is displayed process-bar and time, spent on information gathering (5).



To close the Support.exe utility, click the **Close** button.

Collecting information about videosevers and remote workstations using the Support.exe utility

To collect the information using the Support.exe utility, do the following:

1. Start the utility.
2. If necessary set the dump and log files collection parameters:
 - a. In the **Collect dump files for ___ days** field specify the number of days for which dump files are to be included into the data set for technical support (1).
 - b. In the **Collect log files for ___ days** field specify the number of days for which log files are to be collected into the data set for technical support (2).
3. By default, all available system information is collected. If necessary, uncheck the boxes next to the information collection steps that should be skipped (3). If unchecked, information is not collected at the corresponding step.
Some stages of information collection are mutually exclusive, for example, you cannot simultaneously select the **Creating an archive copy of the MS SQL Sever database** and **Creating the archive copy of the DB without the protocols** checkboxes.
Some steps cannot be excluded, including **Compressing files** and **Removing temporary files**.
4. Click the **Collect** button (4).

The data collection process will start. Upon completion, the result of information gathering on each step is displayed in the **Status** column (5), while the information area will show the link to the newly generated file – support.7z (6).

Support - Collecting info about system

This application can be used for collecting data about the system and about the installed AxxonSoft software. Click Collect to create support_[date]_[time].7z file. After that you can send it to AxxonSoft technical support group.

Collecting dump-files for the last days **1**

Collecting log-files for the last days **2**

4 **Completed!** [Open folder with file support_19-08-2022_16-00-27.7z](#) **6**

<input checked="" type="checkbox"/>	Step 3	Status 5
<input checked="" type="checkbox"/>	Step 1 : Receiving info about installed software	OK (0 s)
<input checked="" type="checkbox"/>	Step 2 : Receiving info about the version of installed modules	OK (10 s)
<input checked="" type="checkbox"/>	Step 3 : Receiving info about the system	OK (0 s)
<input checked="" type="checkbox"/>	Step 4 : Receiving info about the DirectX subsystem	OK (3 s)
<input checked="" type="checkbox"/>	Step 5 : Receiving info about HDD	OK (2 s)
<input checked="" type="checkbox"/>	Step 6 : Receiving info about the key files	OK (0 s)
<input checked="" type="checkbox"/>	Step 7 : Getting information about the registry settings	OK (0 s)
<input checked="" type="checkbox"/>	Step 8 : Copying configuration files	OK (0 s)
<input checked="" type="checkbox"/>	Step 9 : Copying settings files	OK (0 s)
<input checked="" type="checkbox"/>	Step 10 : Copying files of scripts and dialogs	OK (0 s)
<input checked="" type="checkbox"/>	Step 11 : Copying log files	OK (0 s)
<input checked="" type="checkbox"/>	Step 12 : Receiving info about TCP/IP(UDP) ports in use	OK (0 s)
<input checked="" type="checkbox"/>	Step 13 : Receiving info about the types of installed CPU	OK (5 s)
<input checked="" type="checkbox"/>	Step 14 : Getting information about the archives on all disks	OK (0 s)
<input checked="" type="checkbox"/>	Step 15 : Receiving info about the installed hardware	OK (0 s)
<input checked="" type="checkbox"/>	Step 16 : Receiving info about the installed Guardant dongles	Error!
<input checked="" type="checkbox"/>	Step 17 : Creating an archive copy of the MS SQL Server database	OK (0 s)
<input type="checkbox"/>	Step 18 : Creating the archive copy of the DB without the protocols	
<input checked="" type="checkbox"/>	Step 19 : Removing old dump- and log-files	OK (0 s)
<input checked="" type="checkbox"/>	Step 20 : Compressing files	OK (1 s)
<input checked="" type="checkbox"/>	Step 21 : Removing temporary files	OK (0 s)

Follow the **Open Folder with Support.7z File** link to view the archive (6). The archive is saved in C:\Users\%current user name%\Documents\Support\.

The Fps.exe utility for productivity estimation

The purpose of the Fps.exe utility

Productivity measurement fps.exe utility is used to estimate productivity of video processing.

Estimation is done in the following way:

1. Segmentation of the given video fragment for a set of frames in jpeg format.

 **Note.**

If the video fragment is not set, the utility generates pattern set of frames. When necessary the utility may store the created set for frames to the selected directory.

2. Compression and/or decompression of the created frame set.
3. Calculation of productivity parameters – number of processed fps with defined resolution and colour.

 **Note.**


Compression is not available on the Client. Playback of a previously recorded video, or a video being received over the network in real time, is available.


Starting and shutting-down the Fps.exe utility

To start fps.exe, do one of the following procedures:

1. Start the utility from the Windows taskbar. Click **Start**, then **Programs**, then **Axxon PSIM**, then **Tools**, then **FPS testing utility**.
The fps.exe utility is available from the **Start** menu with the following installation types of the *Axxon PSIM* software: Server, Remote administrator workstation, Remote client.
2. Start the utility from the **Tools** folder of the *Axxon PSIM* program folder: <Axxon PSIM>\Modules64\fps.exe.

After starting the fps.exe utility there will be a dialog window **Video processing FPS tester**.



To close fps.exe utility click  in the right upper corner of the utility's dialog window.

Using the Fps.exe utility

On the page:

- [Selecting the video source](#)
- [Setting the check parameters](#)
- [Running the check and reading into its results](#)

To check productivity of video processing, do the following:

1. Start the fps.exe utility (see [Starting and shutting-down the Fps.exe utility](#)).
2. Select the video source.
3. Set the check parameters.
4. Run the check and read into its results.

Selecting the video source

The video source can be either an archive file or a video server archive recorded on specific cameras.

Note.

The field **Video Source File** is not required to run the check on an emulated pattern set of frames.

If the video source is an archive file, select it as follows:

1. Click **File** and then double click the required file in the Windows standard **Open** box (1).




2. The full name of the selected file is displayed in the **Video source** field (2).

If the video source is a video server archive, make sure the *Axxon PSIM* is running on that server and all the required cameras are created in the hardware tree before performing the check.

Select the archive video source as follows:

1. Click **Server** (1). The **Cameras** dialog box opens.




2. In the **IP** field, specify the IP address of the *Axxon PSIM* video server (2).
3. Click **Get** (3). If connection with the server is established, the **Cameras** field displays the list of cameras.
4. Set the check boxes next to the cameras to check performance using their archive (4) or set the **Select all** check box to select all the cameras in the list (5).
5. Click **OK** (6).
6. The selected cameras are added into the **Video source** field (7).

Setting the check parameters

Set the parameters of performance check as follows:

1. Activate **Compression check** checkbox to check how many fps the given computer can compress (1).



2. Activate **Decompression check** checkbox to check how many fps the given computer can decompress(2).
3. Select the **Copy for stream** check box to create a separate copy of each stream file in the RAM in order to avoid conflicts during the check (3). This function increases memory consumption when running the fps.exe utility.
4. Select the required compressor version from the drop-down list **Codec** (4).
5. Enter the required number of emulated cameras in the field **Channels amount** (5).


Note.

This setting is actual only with emulation of pattern set of channels.

6. In the **Number of CPU cores in use** field specify the number of CPU cores to be used for performance check (6).
7. Select the required value of frames compression from the dropdown list **Quality** (inversely to compression level) (7).
8. When necessary, set the directory where frames extracted from the video would be unzipped by clicking next to the **Jpeg images storage folder** field (8).

Running the check and reading into its results

Click the **Start** button to run video processing tester (1).




As a result, parameters of video processing productivity will be displayed in the title bar of the utility window (2).

Productivity parameter	Description of parameter
Compression	total number of frames that can be compressed in one second
Decompression	total number of frames that can be decompressed in one second
Ratio	compression ratio
Version	selected version of the compressor
Width	frame width
Height	frame height
Color	if the frame is in color
CPU	number of CPU cores in use
Compressors \$ decompressors per thread	number of compressor instances per CPU

If the **Jpeg images storage folder** is selected, the frames for testing video processing will be recorded to the selected .jpeg files storage folder.

The example of the emulated frame is shown below:



To stop the testing process, click the **Stop** button (3).

The ddi.exe utility for editing database templates and external settings files

The ddi.exe utility is designed for editing external system settings files (*.ddi) and the templates of the main database (psim.dbi and psim.ext.dbi).

The ddi.exe utility is started from the **Start -> All Programs -> Axxon PSIM -> Tools -> System configuration** menu.

The ddi.exe utility is available from the **Start** menu with the following installation types of *Axxon PSIM*: Server, Remote administrator workstation, Remote client.

The utility can also be started from the **Tools** folder of the *Axxon PSIM* program folder.

After the changes are made to *.ddi and/or *.dbi files, update the main database. For this use the idb.exe utility (see [The idb.exe utility for converting databases, selecting database templates and making backup copies of databases](#) section).

 **Note.**

If changes were made to .ddi or .dbi files using the ddi.exe utility and these files were installed along with *Axxon PSIM*, then these files will be deleted while deleting with configuration upload. .ddi and .dbi files added manually will be saved.

Editing psim.dbi and psim.ext.dbi database templates using the ddi.exe utility

To edit the template of the main database, open it using the **File -> Open** menu. The template files are stored in the root of the *Axxon PSIM* program folder.

Note.


To open the recently used file, select the **Last files** item in the **File** menu or open the context menu in the **Names** tab.

Note.

The **Paste from file** item in the **File** menu allows opening several files by adding tables, described in other dbi files, to the open dbi file.

psim.dbi file contains the list of main tables and fields of the database. User-defined tables and fields are stored in a separate file – psim.ext.dbi. This file is made separate from the main file, to eliminate the need to re-insert user-defined tables and fields into the main file, in case of *Axxon PSIM* system update. The contents of these files are merged upon *Axxon PSIM* start-up.

To view the database template, open the **DBI** tab in the top left corner of the window. The list of the tables of the main *Axxon PSIM* database will be displayed in the left panel. The right panel will show the list of fields of the selected database.



To delete, add, edit or copy object fields, use the table on the left of the utility box.

The following parameters of the table fields are displayed:

1. **Field name** – the name of the field in the database.
2. **Type** – data type of the field contents. Available types:
 - a. BIT – checkboxes taking logical values Yes and No;
 - b. CHAR – fields with a few symbols;
 - c. DATETIME – date and time in the following format: date – dd-mm-yyyy, time – hh:mm:ss;
 - d. DOUBLE, INTEGER, SMALLINT – numerical fields of corresponding types;
 - e. TEXT – fields with the text.
3. **Size** – maximum number of units of the specified format in a field.
4. **Description** – field name shown in the interface.

The database is to be refreshed after the changes were made.

Editing the external setting file (Axxon PSIM.ddi) using the ddi.exe utility

To edit the external settings file (psim.ddi), open it using the **File** -> **Open** menu. This file is stored in the root of the *Axxon PSIM* program folder.

 **Note.**

To open the recently used file, select the **Last files item** in the **File** menu or open the context menu in the **Names** tab.

 **Note.**

The **Paste from file** item in the **File** menu allows opening several files by adding tables, described in other ddi files, to the open ddi file.

The external settings file contains the information about objects and events loaded into the system configuration, graphical symbols for various object states on the map, and the transition rules from one object state to another.

The purpose of editing can be software localization or expanding/limiting its functionality (for example, removing unused objects from the system).

 **Note.**

Changing the external settings file may lead to system failure. Create a backup copy of the file before editing it.

The database is to be refreshed after the changes were made.

General information on editing the external setting file

To start using the utility, open the **DDI** tab in the top left corner of the utility dialog box.

The left side of the dialog box will display all system objects loaded into the configuration. The right side of the dialog box shows the properties panel for the selected object. This panel consists of several tabs: **Names, Events, Reactions, Icons, States, and Transition rules**.

To delete, add, edit or copy object properties, right-click a cell in the tab or the list of system objects to open the context menu. You can also use **Ctrl+C** and **Ctrl+V** to copy and paste lines from one object to another. Select the whole line(s) or just a cell(s) in it to copy by **Ctrl+C**. Delete lines with **Delete** key.


To edit the object properties, use the tables on the right of the ddi.exe utility box.

The Names tab

This tab contains the table with three fields:

1. **Object** – object ID in the system.
2. **Name** – the name of the object in the system.
3. **Group name** – the name of the group the object will be assigned to upon creation. If this field is left blank, no group will be created. Objects of different types may be assigned to the same group given that they have the same parent object (e.g., **Sensor** or **Relay** can be included to the "Sensors and Relays" group and so on).

By default all objects, the description of which the ddi file contain, are displayed in the table. To find an object, type-in the object name or ID in the **Search by name** field. As a result the table will contain all object names in the system that exactly or partially match the word typed in this field.



The Events tab

This tab contains the list of the system events that the selected object can create. Each event has the following editable parameters:

1. **Name.** The event identifier.
2. **Description.** A short description of the event.
3. **Processing messages.** The type of window to open on event occurrence: alarm window or information window.
4. **Support audio.** The attached .wav files to be played when the event occurs.
5. **Disable network connection.** A local event only. If this checkbox is set, other computers on the network will not be notified when the event occurs.
6. **Disable logging.** By default, all events are displayed in the Event log. Set the checkbox not to log the event or record it in the database.
7. **Windows log.** Set the checkbox to log the event (see step 6) to Windows log. If the event is not logged, then it cannot be logged to Windows log.

The screenshot shows the 'Events' tab in the DDI & DBI Editor. The main table lists various system events with their names, descriptions, processing messages, and checkboxes for support audio, disable network connection, disable logging, and windows log.

Name	Description	Processing messages	Support audio	Disable network connection	Disable logging	Windows log
UPS_ONLINE	UPS - AC power suppl...	INFORMATION	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
UPS_ONBATT	UPS - Switch on battery	ALARM	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
UPS_LOWBATT	UPS - Low battery	ALARM	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
UPS_COMMLOST	UPS - Connection lost	ALARM	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
UPS_SHUTTING	UPS - Shutting down	ALARM	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
UPS_REPLACEBATT	UPS - Battery replace...	ALARM	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
UPS_FATAL_ERROR	UPS - Connection error	ALARM	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
VCORE	HUB - CPU core voltage	ALARM	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
CPU_FAN	HUB - FAN rpm	ALARM	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
CPU_TEMP	HUB - CPU temp	ALARM	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
SYS_TEMP	HUB - Chassis temp	ALARM	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
+5V	HUB - +5V Voltage error	ALARM	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
+12V	HUB - +12V Voltage er...	ALARM	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
-5V	HUB - -5V Voltage error	ALARM	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Parameters for event "UPS - AC power supply restored":

Parameter	Name	Type	Element	Value
*				



Note

You can create only the events that are available for the selected object (created at the stage of the system programming). Initially all of them are in the psim.ddi file.

The Reactions tab

This tab lists all reactions that the object can make in response to events. Each reaction has the following properties:

1. **Reaction** – reaction ID.
2. **Description** – short description of the reaction.
3. **Arming** – additional property of the reaction, arming a region.

The screenshot shows the 'DDI & DBI Editor' window. On the left is a file explorer with a list of objects including ACTIVEEX, ARCH, ARCHPANEL, ATM, ATMX25_CLIENT, ATMX25_SERVER, ATM_ITV, CAM, CAM_FACECAPTURE, CAM_IP_DETECTOR, CAM_TITLE, CAM_ECHD, CAM_VMDA, CAM_VMDA_DETECTOR, CAM_VMDA_DETECTOR2, CAM_ZONE, CONFIG, DEPARTMENT, DIALOG, DISPLAY, DMD, DRS, EVENT_COUNTER, EVENT_VIEWER, GATE, GRABBER, GRAY, GRELE, HTTP, KEYB, LEVEL, LMCFTP, LMCGATE, MACRO, MAIL_MESSAGE, MAIN, MAP, MAPPLAYER, MAPPLATFORM, MESSAGE, MMS, and MONITOR. The 'GRAY' object is selected. The main area shows the 'Reactions' tab with a table:

Reaction	Description	Arming region
ARM	Arm	<input checked="" type="checkbox"/>
DISARM	Disarm	<input checked="" type="checkbox"/>
CONFIRM	Classify alarm	<input type="checkbox"/>
*		<input type="checkbox"/>

Below the table is a section titled 'Parameters of action "Arm":' with a table:

Parameter	Name	Type	Element	Value
*				


The status bar at the bottom indicates 'Total objects: 89'.

Note.


You can create only the reactions that are available for the selected object (created at the stage of system programming). Initially all of them are in the psim.ddi file.

The Icons tab

This tab lists the graphical symbols (icons) that represent the selected object on the map. The part of the name used for identifying the file in the .bmp, .jpg or .png format is specified in the **File name** column. Image files are to be stored in the **Bmp** folder in the Axx on PSIM program folder (for example, C:\Program Files\Axxon PSIM\Bmp).



If default icons are to be in use for the same states of objects of the same type, the def icon should be specified on this tab (**By default**). See [The States tab](#) section for more information.



The States tab

This tab lists all states of the selected object. The states have the following properties:

1. **Name** – state ID.
2. **Image** – part of the name in the .bmp format that represent the object state on the map. For example, if the zone_fire file name was selected in the **Icons** tab, and the image of the selected ARMED state is arm, then the zone_fire_arm.bmp file will be in the **Bmp** folder.

The default icon for the states can be set. For this, set the def icon (**By default**) on the **Icons** tab. For example, if there is no zone_fire_arm.bmp icon for the ARMED state, then the def_arm.bmp icon will be searched. This avoids duplicating icons if one state for the different types of the object icon should be displayed identically.

Note.


If the file ID is not set in the **Icons** tab, then the file name will consist of the object ID and part of the file name specified in the Image column.

Note.

If the object is displayed on the map as a polygon, circle or line, then the color of these figures can be set for each state. For this specify the color in the R:G:B:A format after the icon name (separated by \$) in the **Image** column or specify the color only in this format instead of the icon name. Here are the examples of the **Image** column contents:

- 255:0:0** – red color is set for the state.
- alarm\$255:0:0** – icon and red color are set for the state.

1. **Description** – short description of the state.
2. **Blinking on alarm** – option of displaying object state.




The Transition rules tab

Transition rules connect the events generated by objects, and the states of these objects. Each rule consists of the starting state of the object, an event, and an ending state that the object will take after the event.

The table lists the transition rules from one object state to another. Each rule has the following properties:


1. **Event** – identifier of the event triggering the transition.
2. **Transition from state** – identifier of the object state before the event took place. If this field is left blank, the rule will apply to all starting states.
3. **Transition to state** – identifier of the resultant state of the object.



Example of editing the Axxon PSIM.ddi file to reduce database load

When changing the ddi file events, reactions, etc. can be added, modified or deleted.
To reduce database load modify the psim.ddi file as follows:

1. Open the psim.ddi file in the ddi.exe utility.
2. Select the **CAM** object.



3. Go to the **Events** tab.
4. Set the **Disable network connection** and **Disable logging** checkboxes checked for the **MD_START** (Alarm) and **MD_STOP** (Alarm end) events.
5. Save the file.
6. Update the database using the idb.exe utility (the **Update database** button, see [Interface elements of the idb.exe window](#)).

When these actions are performed the events from the main motion detection tool are not recorded and sent to other cores. This reduces the database load.

Important!

When updating *Axxon PSIM* the modified psim.ddi file is substituted with the file by default.

In order the psim.ddi file is not substituted it is to be saved with another name at step 5 - e.g. "psim_1.ddi". Thus, 2 files of external settings are saved in the Languages catalog: source file and modified one. The idb.exe utility loads them in alphabetical order. As a result the psim_1.ddi file is loaded the last one and its parameters are applied when database is updated.

If the event list in psim_1.ddi is different from the original psim.ddi, e.g. some events are added or deleted, then the event list is merged by idb.exe DB update.

When installing a new *Axxon PSIM* version the psim_1.ddi file is not affected by the installation wizard and changes are saved.

Important!

When deleting *Axxon PSIM* without saving the configuration the entire *Axxon PSIM* catalog (including modified files) is deleted. In this case the modified files are to be manually backed up, e.g. to C:\Temp, under after reinstallation they are to be copied to <Axxon PSIM installation folder>\Languages\en.

The Arpedit.exe utility for creating user dialog windows

The Arpedit.exe utility is designed for creating dialog boxes. It allows tailoring *Axxon PSIM* system to particular monitoring and security tasks of the customer.

The Arpedit.exe utility is in the "Arpedit" folder (<Installation directory>\Axxon PSIM\Tools\Arpedit). Detailed information on the utility is given in [User's Manual for ArpEdit](#) (it is located in pdf format in the same folder too).

User's Manual for ArpEdit

Introduction into User's Manual for ArpEdit

On the page:

- [The purpose of the document](#)
- [The purpose of ArpEdit](#)

The purpose of the document

The *User's Manual for ArpEdit* is a reference tool and contains information needed to work with the *ArpEdit*. This utility is included in the basic distribution of the *Axxon PSIM* software package.

The following materials are included in this manual:

1. General information on *ArpEdit*.
2. User guidelines for *ArpEdit*.

The purpose of *ArpEdit*

ArpEdit is designed to perform the following functions:

1. Creating badge forms for the **Access Control Service** module (in the form of files with the .arp extension).
2. Creating user dialog boxes (in the form of files with the .dlg extension).

Note.


The dialog box is connected to Axxon PSIM via a system operator **object query window** and displayed as a result of the macro commands that are specifically designed to work with this dialog box. Thus, the *ArpEdit* utility allows you to completely adapt *Axxon PSIM* to solve particular problems of control and security at a production facility.

General principles of operating ArpEdit

Starting and shutting down ArpEdit


Launching *ArpEdit* can be done in one of the following ways:

1. Launch from the *Axxon PSIM* installation directory. To launch the *ArpEdit* utility from the *Axxon PSIM* installation directory, follow these steps:
 - a. Go to the folder where you installed *Axxon PSIM* (default directory is C:\Program files\Axxon PSIM).
 - b. Go to the **Tools\Arpedit** folder.
 - c. Launch the file *arpedit.exe*.
2. Launch from the **Start** menu. To launch the *ArpEdit* utility from the **Start** menu, select the menu item **Create dialog windows**, located in **Start Axxon PSIM**.




Closing the operation of the *ArpEdit* utility may be done in one of the following ways:

1. In the system menu of the *ArpEdit* utility, in the **File** heading, select **Exit**.



2. Click .

If the document contains any unsaved changes, a **Report editor** dialog box appears.



To confirm the changes, click **Yes**. To exit the program without saving the changes, click **No**.

The utility window will close.


Description of the interface elements of the ArpEdit utility

The *ArpEdit* utility window contains the following key interface elements:

Note.

More information on the interface elements of the ArpEdit utility can be found in the appendix (see [APPENDIX 1. Interface elements of the ArpEdit utility](#)).

1. The System menu. Provides access to file operations, editing functions and window display settings for the *ArpEdit* utility (1).




2. Toolbar. Provides access to key features of the utility (2).
3. Workspace. Contains elements of the badge or dialog box, add users, and allows for the management of placement and sizes (3).
4. The status bar displays information about the actions produced by the utility (4).


Creating ArpEdit objects

ArpEdit objects are divided into the user interface and variable elements. To create a new object in the workspace, follow these steps:

1. Select a section of the workspace where you want to add an item, click on it. The selected part will be highlighted in blue.



2. Go to the ArpEdit toolbar.



3. Select the object to be added by clicking the left mouse button on the appropriate icon on the toolbar (see description below).
4. Click the left mouse button at the point in the workspace in which to place the upper left corner of the object.

Note.

The dimensions of the created object can be changed in two ways:

1. By dragging the right or bottom edge of the object with the mouse.
2. By setting new values for the height and width of the object in the field box (see [Setting field variables](#)).

The position of the created object can also be modified in two ways:

1. Dragging the object with the mouse from the top or left edge.
2. By setting the new position of the object in the field variable window (see [Setting field variables](#)).

ArpEdit objects:



Name	Description	Purpose
Text	Fixed text field	Display fixed text field



Name	Description	Purpose
Variable	Variable text field, hidden text box, button or drop-down list	<ol style="list-style-type: none"> 1. Displays information from the database when creating badges 2. Variable when creating dialog boxes



Name	Description	Purpose
Line	A line of given length and direction	Design element



Name	Description	Purpose
Frame	Set rectangular frame sizes	Design element



Name	Description	Purpose
Square	Set filled square sizes	Design element



Name	Description	Purpose
Image	Image placed at a specific location	Insert client photographs in the badge form for printing


Creating a new object is finished.

Setting object display variables

Setting field variables


To set the field variables, follow these steps:

1. In order to set the field variables, it is necessary to select the variables of the object in the workspace, and open the **Variables** field in one the following ways:


- a. Click  on the toolbar;
- b. In the object functional menu, select **Properties**.


Note.

The object functional menu is opened by right-clicking anywhere inside the object.



2. The **Field variables** window will appear.




3. In the text field (1) enter information describing the field:
 - a. Enter text in **Text field**, which will be displayed in the text field.
 - b. For **Variable**, enter the variable name.
 - c. For an **Image**, enter the image address in quotes. The image must be placed in one of the following folders:
 - i. In the *Axxon PSIM* software installation folder (e.g. C:\Program Files\Axxon PSIM), then in the field (1) enter the image name, e.g. "image.bmp".
 - ii. In the Bmp folder of the *Axxon PSIM* software installation folder (e.g. C:\Program Files\Axxon PSIM\Bmp), then enter the image file address as "Bmp\image.bmp" or "Bmp/image.bmp".
4. If you would like to fill in the text field with data from a text file or enter a large amount of data, then click the  button (2) and use a text editor (see the section in [APPENDIX 2. Entering text using the editor](#)).
5. Set the **Alignment** settings for the desired justification of the text within a selected object (3).
6. Select units of measure which will be used to size the object:

- a. If the size of the object will be given in millimeters, then check the **in mm** box (5).
- b. If the size of the object will be given in characters [symbols], then check the **Width in symbols** box (9).

Note.

The size of the object is given in characters [symbols] by default.

7. Set the position of the upper left of the object in one of the following ways:
 - a. Specify the absolute coordinates of the object. In this case you should indicate the position of the upper left corner by setting the X-axis in the **X** field, and the Y-axis in the **Y** field: (6)
 - b. Specify the relative coordinates of the object. In this case you should check the **Relative** box (4).
8. The width and height of the object can be set in one of the following ways:
 - a. Specify the width of the object in the **W** field, and the height of object in the **H** field (7).
 - b. Specify the coordinates of the lower-right corner. To do this, check the **X2, Y2** box (8). The **W** and **H** fields will be by **X2** and **Y2**. After this, specify the coordinates of the lower-right corner of the object using the **X2** field for the x-axis and the **Y2** field for the y-axis.




9. Specify the line thickness in the **Line thickness** field in the desired units (10).
10. If a custom object should be on the badge or there is a dialog window, but it should not be visible to the user, then check the **Hidden** box (11).
11. If the object must be part of a group, check the **Group** box (12).
12. Click **OK** (13).

Setting the variables is completed.


Setting the text font

To set the text font, follow these steps:

1. Select **Font** from the menu.



2. Using the standard font selection menu, set the text display settings.




Setting the text font is completed.


Setting the color

To set the color, follow these steps:

1. Select **Color** from the menu.



2. Using the standard color selection menu, select the color desired for the object.




Setting the color of the object is completed.


Setting the background color of the object

To set the background color of the object, follow these steps:

1. Select **Background color** from the menu.



2. Using the standard color selection menu, select the background color desired for the object.



Setting the background color of the object is completed.

Creating dialog boxes

Creating a dialog box form


In the *Axxon PSIM* dialog box, objects will be displayed in the *ArpEdit* workspace.


Create a dialog box form in the following order:






1. Create design elements in the workspace.
2. Create variables in the workspace.
3. Configure the design elements in the workspace.

Create design elements

The design element types in the dialog box correspond to their appearance on the workspace. You can add the following design elements to the dialog box form:


1. Square. Adding a square in the workspace is done by clicking on the  on the *ArpEdit* toolbar (1).




2. Line. Adding a line in the workspace is done using one of the following buttons:    on the *ArpEdit* toolbar (2).
3. Text field. Adding a text field in the workspace is done by clicking on the  on the *ArpEdit* toolbar (3).
4. Frame. Adding a frame in the workspace is done by clicking on the  on the *ArpEdit* toolbar (4).

Creating design elements is completed.

Creating variables


Creating variables in the workspace is done using the  on the *ArpEdit* toolbar. Depending on the variable setting they may be displayed in the dialog box as follows:

1. Editable text field (1). Additional configuration after adding is not needed (5).



2. Button (2). In order to display a variable as a button in the dialog box, you must configure it after adding it to the workspace, as follows (6):

- a. Click  on the toolbar. The **Field options** window will open.




- b. Place a colon in front of the variable name (1).
 - c. In the **Calculation formula** field, specify the variables for the DoReact function using quotes "," – which will be used with the button is clicked (2).
 - d. Click **OK**.
3. Drop-down list (3). In order to display a variable as a drop-down menu in the dialog box, you must configure it after adding it to workspace, as follows (7):

- a. Click  on the toolbar.

- b. Double click on the frame around the variable name. The **Field options** window will open.

The screenshot shows the 'Field's options' dialog box. The 'Field' text box contains 'var'. The 'List filling' text box contains 'value1|value2|value3'. The 'Pulldown list' checkbox is checked and circled with a '1'. The 'Fill with DB table' checkbox is unchecked and circled with a '2'. The 'List' checkbox at the bottom left is unchecked. The dialog has 'OK' and 'Cancel' buttons at the bottom right.


- c. Check the **Drop-down menu [Pulldown list]** box (1).
- d. If you would like to manually specify menu values, then you must enter the desired value in the **Fill list** field, using the character "|" as the separator between values (2). To enter a large amount of text or to paste text from a file, click  and use the editor (see the section in [APPENDIX 2. Entering text using the editor](#)).
- e. Click **OK**.

Creating variables is completed.

Setting up workspace objects


After adding interface elements and variables to the workspace, it is necessary to configure them. Configuring interface elements includes specifying their display variables (see the section on [Setting object display variables](#)).

To configure a variable, follow these steps:

1. Click  on the toolbar.
2. Double click the left mouse button on **Variable** menu item that you wish to set. The **Field options** window will open.
3. Enter the name of the variable in the **Text field (1)**.

Note.

If there is a colon in front of the variable name (for example :var), the when creating a dialog box it will be displayed as a button with the same name (var). At the same time, in the **Calculation formula** field (3) the variables for the DoReact function will be displayed, delineated by the “|” character.




4. Enter the **Default value** in the field, of the variable that will be the default value (2).
5. Set the switches (3) to the position corresponding to the type of variable.
6. Specify the format for the variable. To do this you need to check one or more of the checkboxes in front of the format corresponding to the variable (4).
7. If you do not want to allow the value of the variable in the dialog box to be changed, then check the **Non-edit** box (5).
8. If you want the value of the variable to be present in the dialog box, but not visible, then check the **Hidden** box (6).
9. Click **OK** (7).

Configuring variables is completed.


Saving the dialog box form

To save the dialog box form, follow these steps:

1. Select **File**, then click **Save (1)** or **Save as... (2)** to save the file under a new name.



2. Using the standard save file dialog, save the file with a .dlg extension [suffix].



Note.

The file extension should be entered manually in this case.

Important!


In order to have access to the saved dialog form file in *Axxon PSIM*, it should be saved in the following folder: <Path to installation directory of Axxon PSIM>/Program.

Saving the dialog bog form is completed.

Accessing the dialog box from Axxon PSIM

To access the dialog box from *Axxon PSIM*, follow these steps:


1. Create an **Operator query window** under the **Computer** object in the **Hardware** tab of the **Configure systems** menu.



Important!

When you create an Operator query window in the number field you should specify the name of the saved dialog box form in the relevant director.


2. Go to the settings panel of the Operator query window.



3. Specify the window coordinates: in the **X** field specify the coordinates along the horizontal axis, in the **Y** field specify the coordinates along the vertical axis (1).
4. From the drop-down menu, in the **Type** column, select the type of object that trigger a dialog box (2).
5. From the drop-down menu, in the **Number** column, select the number of selected objected types (3).
6. Double click the left mouse button on the **Name** column (4). The cell will be automatically completed with the name of the selected object.
7. Specify the action to be performed upon the occurrence of a specified event, in the **Event** column (5).
8. Click **Apply**.

Note.

In the example shown in the illustration above, the dialog box, created in the form, will be displayed from the macro.



Dialog boxes are used for programming the *Axxon PSIM* software package. More information on the built-in programming language can be found in the *Axxon PSIM Software Package. Programming Guide*.

Configuring the **Operator query window** is described in detail in the [Administrator's Guide](#).

Example of creating a dialog bog to count the number of movements

This section provides an example of how to create a dialog box to count the number of movements. To create such a dialog box, follow these steps:

1. Create a text field with the text **Number of movements [Alarms:] (1)**.

Alarms:


param

2. Create variables (2).

3. Click  on the toolbar.

4. Double click on the frame around the variable name. The **Variable field** window will open.

5. For the name of the variable, name it **param (1)**.




The screenshot shows the 'Field's options' dialog box. The 'Field' text box contains the text 'param', which is circled and labeled with a '1'. To its right, the 'Non-edit' checkbox is checked, also circled and labeled with a '2'. Other options in the dialog include 'Hidden', 'Autogain', 'Prev.value', 'Calculation formula', 'String', 'Integral', 'Real', 'Date', 'Monetary unit', 'Time', 'Logical', 'Pull down list', 'Fill with DB table', and 'List filling'. The dialog also features a 'List' checkbox at the bottom left and 'OK' and 'Cancel' buttons at the bottom right.

6. Check the **Non-edit** box (2).


7. Save the file with the name **motion.dlg** in the following folder: <Axxon PSIM installation directory>\Program

8. Run *Axxon PSIM*.

9. Create a directory try for the **Operator query window** in *Axxon PSIM* with the number **motion**.



10. In *Axxon PSIM* create a **Program** under the **Programs** tab in the **Programming** dialog box of **System settings (1)**.



11. Write the following code **(2)**:

```
OnInit(){
param="0";
}
OnEvent("CAM","1","MD_START"){
DoReact("DIALOG","motion","CLOSE");
param=str(atoi(param)+1);
DoReact("DIALOG","motion","RUN","param<" + param + ">");}
```

12. From the drop-down **Time zone** menu, select **Always (3)**.
13. Click **Apply (4)**.

This script indicates that if the video camera in sector 1 detects movement, then a **motion** operator query window will open, showing the number of movement alarms (**param**).



Working with badge forms


The *ArpEdit* utility supports work with the *Visitor Management System* (see [Visitor Management System Module Settings and Operation Guide](#)) module and allows you to create badge forms and output them for printing.


Creating a badge form

Before you start to create badge forms, you need to make sure that you have created an **Access Control Service** object, as well as departments and users in *Axxon PSIM*.

To create badge forms in the *Access Control Service*, follow these steps:

1. Select the workspace section where the items will be added to the interface. Each section represents a single page.
2. Create the required number of variables, as follows:


- a. Add a variable to the workspace by clicking  on the toolbar (1).




- b. Click  on the toolbar.

- c. Double click the left mouse button on the border of the **Variable** that you wish to set. This will open the **Field options** window.

- d. In the **Field** box [field], enter the name of the variable corresponding to the table in the *Axxon PSIM* database: `dbo.OBJ_PERSON`, from which data will be accessed for printing the badges (1).
3. Add the required design elements from the *ArpEdit* toolbar.
4. In order to allow the printing of photographs of employees on each pass for badge users, the **Image** should be set as follows:

5. Select the required **Image** and click  on the toolbar. The **Field options** window will open.



6. In the **Field options** window, specify the following text string: "<Axxon PSIM installation directory>\bmp\Person\'+id+'.bmp" (1). When outputting the badge to the printer, the **id** variable will be automatically read from the data base, and photography assigned to that ID by *Axxon PSIM* will be printed on the badge.

Design elements used for badge forms:



Name	Description	Function
Text	Uneditable text field	Will display uneditable text information



Name	Description	Function
Line	Line of any given length and direction	Design element



Name	Description	Function
Frame	Rectangular frame of a specified size	Design element



Name	Description	Function
Square	Filled rectangle of a specified size	Design element



Name	Description	Function

Image	An image placed at a specified location	Insert user photographs on badge forms when printing
--------------	-----------------------------------------	------------------------------------------------------


After adding all the required elements in the workspace, you must set the display variables (see section on [Setting object display variables](#)).

Creating badge forms is completed.


Saving badge forms

To save created badge forms, follow these steps:

1. From the **File** menu, select **Save** or **Save as...** to save a file with a new name.




2. Using the standard save file menu, save the badge form file with a .arp extension.



Saving badge forms is complete.

Printing badges

To output badges for printing, select **Printer network [Print's Grid]** from the **File** menu.




Outputting the badge to the printer is completed.

APPENDIX 1. Interface elements of the ArpEdit utility

System menu

The *ArpEdit* utility system menu provides access to the following functions:

1. File operations: creating, opening, saving, printing (**1**).



2. Text editing features (**2**).
3. *ArpEdit* utility window display settings. In this menu, you can enable or disable the display of the toolbar and status bar (**3**).

Toolbar

The main way to manipulate objects in *ArpEdit* is via a toolbar, that has buttons to control the utility.




Description of the buttons in the *ArpEdit* utility toolbar:

Button image	Name	Function
Manipulation of <i>ArpEdit</i> documents		
	New	Create new document
	Open	Open file
	Save	Save text document
Managing an <i>ArpEdit</i> document		
	Orient vertically	When this element is activated, the page is oriented vertically
	Orient horizontally	When this element is activated, the page is oriented horizontally
	Display sections	Displays sections (pages) of the document (up to five)
	Show grid	Displays the mapping grid for the workspace
	Snap to grid	Snaps the object to the grid
	Zoom in	Increases the size of objects in the workspace
	Zoom out	Decreases the size of objects in the workspace
	Display options	Opens a settings window with display settings for the selected object
	Sort fields	Displays the fields in order by section
Adding objects to the <i>ArpEdit</i> workspace		
	Text	Insert a text field in the workspace
	Field	Insert a Variable (editable text field) in the workspace
	Horizontal line	Insert a horizontal line in the workspace
	Vertical line	Insert a vertical line in the workspace
	Frame	Insert a frame in the workspace
	Square	Insert a square (shaded rectangle) in the workspace
	Image	Insert an image in the workspace
	Line	Insert a line in any direction in the workspace
Object management		
	Separate text	Separate text using a linefeed as a separator
	Delete	Delete the selected object
	Form	Access the editor for variable parameters
	Form options	Set parameters for the connection with the data source

Workspace

The ArpEdit utility workspace is designed for the placement of objects in ArpEdit. When the Show sections button is activated, the workspace will be divided into sections by horizontal lines.





Each section will have its own page. To start editing a section, select it by clicking on the dividing line with the left mouse button. The selected section will be highlighted in blue.

APPENDIX 2. Entering text using the editor


You can enter text in the variable settings using the built-in *ArpEdit* editor. This editor should be used when you want to fill in a text field with data from a text file or a large amount of data.

To enter text using the editor, follow these steps:

1. Click  next to the text field.



2. Open the **Editor** window.



3. Enter text in the text field (1).
4. If you want to paste the text into a text field from a text file, then click **File...** (2) using the standard open file dialog box, select the required text file. Text from the selected file will appear in the text field (1).
5. Click **OK** (3).

Entering text using the editor is completed.


Configuration check tool

The Configuration check tool is designed for checking the settings of all created objects in the Axon PSIM™ software and restoring the correct configuration if any changes occurred. Restoring is performed from the configuration template which can be created at any moment in accordance with current settings.


Starting and shutting down the Configuration check tool

To start the Configuration check tool, do the following:

1. Go to the **Interfaces** tab of the **System settings** dialog box.
2. Create the **Configuration check** object on the base of the **Display** object.



3. Go to the settings panel for the **Configuration check** object.



4. To configure the position of the **Configuration check** object, set the coordinates of upper left corner in **X**, **Y** fields and values of window's width and height in **W**, **H** fields, and select the computer monitor for which the coordinates are set.

5. To save the changes, click the **Apply** button.

As a result the **Verifying configuration** tool dialog box is displayed.

Configuration check utility

File Configuration Debug

- Computer COMPUTER
 - Backup archive 1
 - Backup audio archive 1
 - Video capture device 1
 - MEDIA_SERVER COMPUTER
 - Audio card 1

Parameters from configuration(current)

_marker	
arch_days	
cam_id	
client	0
connection	
disable_protocol	0
display_id	1
drives	C:\
drives_a	C:\
flags	
guid	{BB31D7B1-6A28-ED11-866E-000C29853B3}
is_backup	
is_load	
is64bit	0
local_protocol	0
mic_id	
name	Computer COMPUTER
parent_id	
password	


Parameters from configuration(current)

Template

Parameters from template

_marker	
arch_days	
cam_id	
client	0
connection	
disable_protocol	0
display_id	1
drives	C:\
drives_a	C:\
flags	
guid	{BB31D7B1-6A28-ED11-866E-000C29853B3}
is_backup	
is_load	
is64bit	0
local_protocol	0
mic_id	
name	Computer COMPUTER
parent_id	
password	

_marker

To shut down the tool, click the  button on the main control panel of *Axxon PSIM* software and select the **Close all** menu item;

oper.: User 1

- Close all
- Display 1

Configuration check tool interface description

The dialog box of the Configuration check tool has four main interface elements:

1. The toolbar (1).
The tool's control menu is located here.
2. The objects tree of *Axxon PSIM* software (2).
The objects tree of *Axxon PSIM* software is displayed here. Clicking the left mouse button on any object in the objects tree, the configuration of its parameters is displayed in parameters field (points 3-4).
3. The field of object parameters from *Axxon PSIM* configuration (3).
The current configuration is displayed in this field. These parameters are not available for editing.
4. The field of object parameters from a template (4).

Parameters of the selected object from the configuration template field are displayed here. These parameters are available for editing.



Note.

At the first start of the Configuration check tool, the current configuration of selected object is displayed in this field.

Configuration check utility

File Configuration Debug 1

Computer COMPUTER

Backup archive 1

Backup audio archive 1

Video capture device 1 2

MEDIA_SERVER COMPUTER

Audio card 1

Parameters from configuration(current)

_marker	
arch_days	
cam_id	
client	0
connection	
disable_protocol	0
display_id	1
drives	C:\
drives_a	C:\
flags	
guid	{BB31D7B1-6A28-ED11-866E-000C29853B3}
is_backup	
is_load	
is64bit	0
local_protocol	0
mic_id	
name	Computer COMPUTER
parent_id	
password	

Parameters from configuration(current)

Template

Distinguish

Remove differences

3

Parameters from template

_marker	
arch_days	
cam_id	
client	0
connection	
disable_protocol	0
display_id	1
drives	C:\
drives_a	C:\
flags	
guid	{BB31D7B1-6A28-ED11-866E-000C29853B3}
is_backup	
is_load	
is64bit	0
local_protocol	0
mic_id	
name	Computer COMPUTER
parent_id	
password	

4

_marker

Using the Configuration check tool

To start the operation, start the Configuration check tool (see the [Starting and shutting down the Configuration check tool](#) section).

Creating a template

To create a template in the Configuration check tool, do the following:

1. In the objects tree, set the checkboxes next to those objects which parameters configuration will be included in a template.



2. Click the left mouse button upon the object which parameters configuration is to be edited.

Note.

The set checkbox next to the required object is an obligatory term in order to edit the parameters.

As a result there is a list of object parameters with values, available for editing in the parameters from template field.

Note.

In the parameters from *Axxon PSIM* configuration field there is a list of object parameters with values set in *Axxon PSIM* software. They can not be edited.

Parameters from configuration(current)	
_marker	
arch_days	
cam_id	
client	0
connection	
disable_protocol	0
display_id	
drives	C:\
drives_a	C:\
flags	
guid	{BB31D7B1-6A28-ED11-866E-000C29853B3}
is_backup	
is_load	
is64bit	0
local_protocol	0
mic_id	
name	Computer COMPUTER


Note.

At the first start of the Configuration check tool, the current configuration of selected object is displayed in this field.


_marker	
brand	
firmware	
flags	
guid	{118098E6-8418-ED11-96C1-B8A3866BC024}
ip	
max_speed	10
min_speed	0
model	

3. Edit the object parameters. To edit the selected parameter, click the left mouse button upon the corresponding line with its value and edit it.
4. Repeat steps 3 for all objects, which parameters configurations are to be edited.
5. Go to the **File** menu of the control panel and select the **Save template** item.

Configuration check utility



6. Name a file and select the storage directory in the appeared window.




7. Click the **Save** button.

The template is now created.


Downloading and editing the template

To download and edit the template, do the following:

1. Go to the **File** menu on the control panel and select the **Load template** item.



2. Select a template file in the appeared window and click the **Open** button.



The objects tree is displayed as a result. The active checkbox is next to the objects which configuration has been saved in the template.




3. To edit the template, repeat steps 1-7 of the **Creating a template** section.

The template is now downloaded and edited.


Verifying and correcting the configuration

To verify the current configuration of objects in *Axxon PSIM* software and restore it from the template, do the following:


1. Download the template for which the object configuration is to be verified in *Axxon PSIM* software (see the [Downloading and editing the template](#) section).
2. Go to the **Configuration** menu on the control panel and click the **Test** button.




As a result the objects which current configuration in *Axxon PSIM* software differs from that one in the template will be marked red in the objects tree.




3. To view object parameters in the template which values are different from those ones in the *Axxon PSIM* software, click the left mouse button upon the object marked red in the objects tree and go to the parameters from the template field.
4. Click the **Distinguish** button in the **Template** field.




As a result the parameters which values are different from those ones in *Axxon PSIM* software are moved to the **Differences** list.



5. Correction (if necessary) of these parameter in *Axxon PSIM* software for those ones from the template may be performed in two ways:
 - a. Click the **Remove differences** button in the Template field.



- b. Go to the **Configuration** menu on the control panel and select the **Correct** item.



The parameter configuration from *Axxon PSIM* templates is now verified and corrected.

Index.exe utility for reindexing archive files

The purpose of Index.exe utility

Index.exe utility reindexes archive files with big data array without restarting the *Axxon PSIM* software.




Note.

Another way to perform reindexing of archive files is to shut down the *Axxon PSIM* software and delete the INDEX folder in the VIDEO folder on the disk with archive. Indexes will be rebuild automatically after the *Axxon PSIM* startup. This method is equal to using of the index.exe utility.

Starting and shutting down the utility

To start reindexing utility run *index.exe* executive file in the **Modules64** folder that is in the catalogue of the *Axxon PSIM* software installation, for example, «C: \Program Files\Axxon PSIM\Modules64».

As a result the window of *index.exe* utility is displayed:



To stop working with *index.exe* utility click **Close**.


Using the Index.exe utility

Attention!

Before you start working with the utility check the value of IndexRebuilding parameter in HKLM\SOFTWARE\AxxonSoft\PSIM\Video for 32-bit systems (HKLM\SOFTWARE\Wow6432Node\AxxonSoft\PSIM\Video for 64-bit) section of OS Windows registry: by default it should be 0. If the parameter value differs from the value by default, you should change it to 0, otherwise the utility will not index the archive.

To reindex archive files after its changing (for example, after copying new video recordings to one or several archive disks), do the following:

1. Start *index.exe* utility (see [Starting and shutting down the utility](#) section).
2. In appeared window select archive disks for reindexing by setting checkbox next to required disks (1). Check **Select All** to set all checkboxes (2).
3. To start reindexing click the **Start** button (3).



Note.

At the time of reindexing all the elements of utility window are not active.

4. Rebuilding process is displayed by progress bar (4) and in the text field (5).
5. When you finish reindexing, shut the window of utility.


Reindexing of archive files is completed.

To reindex archive files without using the dialog box, in the command line start *index.exe* utility with parameters, for instance, `index.exe C, D` command will reindex archive files on disks C and D. To reindex archive files on all disks, use the `all` parameter.

The shedule.exe utility for creating a replication query file

The purpose of the shedule.exe utility


The shedule.exe utility is designed for creating a query file on the Server-Receiver while replicating the archive on unconnected Servers (see [Replicating archive from unconnected servers using the removable storage](#) section).



Note.

The error message is displayed at opening the *schedule.exe* utility when users or the **Camera** objects are not created in the *Axxon PSIM* software under the **Computer/LOCALHOST** object corresponding to the Receiver. It is needed to create required objects and restart the system.

To close the *schedule.exe* utility, click the  button or select **Exit** in the **File** menu.





Using the schedule.exe utility

Creating the query file for replication

To create the query file do the following:

1. Connect the removable storage to the Receiver.
2. Select the user registered the Axxon PSIM™ software in the **Query executor** drop-down list (1).



3. Select the **Computer** object corresponding to the Data source in the **Computer** drop-down list (2).
4. In the corresponding drop-down list select the **Camera** object the archive of which is to be copied (3).
5. Specify the time period for which the archive from selected camera is to be copied in the **From:** and **To:** fields using the mask or calendar that is displayed by clicking the  button (4).
6. Click the **Add** button (5).
The task is added to the list (6).

Note.

Select the task and click the **Delete** button to delete it from the list (7).


7. Repeat steps 2-6 for all required Sources.
8. Save the query file.

The query file is now created.

Saving the query file

To save the query file do the following:

1. Select **Save** in the **File** menu.



2. Select the removable disk where the query file is to be saved in the drop-down list of the opened dialog box (1).



Note.

The Removable disks are not found message will be displayed if the removable storage is not found while saving the query file.

Note.

If there is the PSIMBackup folder on the removable storage, then the dialog box asking to delete this folder is displayed. Click the **OK** button.


3. Click the **OK** button (2). The query file is saved on the selected disk.

The query file is now saved.


Opening the query file

To open the query file do one of the following:

1. Specify the disk where the query file is. For this:
2. Select **Open drive** in the **File** menu.




3. Select the query file in the drop-down list (1).



Note.

The Removable disks are not found message will be displayed if the removable storage is not found while opening the query file.

4. Click the **OK** button (2).
The utility detects and opens the query file which is in the root of selected disk.
5. Select the query file manually. For this:
6. Select **Open file** in the **File** menu.



7. Select the *psim_task.xml* file containing the query parameters using the standard opening dialog.

The query file is now opened.

The SyncProtocol.exe utility to synchronize event log database

The purpose of the SyncProtocol.exe utility.

Starting and shutting-down the utility

Purpose

The SyncProtocol.exe utility is designed to synchronize Server/Client Event log database with databases of other Servers/Clients by command if the auto synchronization is disabled.

The auto synchronization is disabled on the **Computer** settings panel using the **Only local protocols** checkbox. If this checkbox is set checked, then the auto synchronization is not performed – see [Configuring events logging](#).


Before starting synchronization using the SyncProtocol.exe utility it is required to configure synchronization on the **Computer** settings panel by specifying the computers for synchronization and the Event Viewer database connection string – see [Configuring the Event Viewer databases synchronization](#).

There is no synchronization with computers for which sending events is disabled in the **Architecture** tab (see [Configuring the interaction of distributed system components](#)). If the **Send events** checkbox is set checked, but checkboxes for all the events are set unchecked, then the events that cannot be disabled will be synchronized (for instance, SLAVE and macro events).

Starting and shutting-down the utility

Start the SyncProtocol.exe utility from the **Tools** folder in the *Axxon PSIM* installation folder (by default, C:\Program Files (x86)\Axxon PSIM\Tools).

The utility dialog box is shown in the figure.





To shut down the SyncProtocol.exe utility click the  button in the upper-right corner of the window.

Synchronization of event log database using the SyncProtocol.exe utility

Synchronize the event log database using the SyncProtocol.exe utility as follows:

1. Preconfigure the system and start the SyncProtocol.exe utility (see [The purpose of the SyncProtocol.exe utility. Starting and shutting-down the utility](#)).
2. Click the **Synchronize** button (1).



3. The information on the synchronization process is displayed in the **Synchronization log** field (2).
4. When the process is completed shutdown the utility by clicking the  button.

The event log database is now synchronized using the SyncProtocol.exe utility.

The Axxon Player utility for viewing and converting the video archive

Please see the documentation [here](#).

The openRTSP.exe utility for checking RTSP workability

The openRTSP.exe utility is a console application without a graphical user interface. This utility is intended for use in scripts to check workability of the RTSP Server module. Please visit <http://www.live555.com/openRTSP/> for details about the utility.

The openRTSP.exe file is located in the <Axxon PSIM installation directory>\Tools folder.

An example of a script to test the workability of RTSP is given below. This script runs the openRTSP.exe utility by timer, then the utility takes 1 sec of video and checks the status of the RTSP Server. If a rejection from the RTSP Server itself is received, the StreamingServer.run process is restarted.

Note.

Create and configure the **Timer** object for the required check period – see [Creating and using the Timer object](#).

```
function check_cam(addr)
{
  var scmd = "./Tools/openRTSP.exe -V -D 10 -d 1 "+addr;
  DebugLogString("run:"+scmd);

  var s = run_cmd_timeout(scmd, 10000);

  DebugLogString(s);
  if(s.indexOf("Receiving streamed data")< 0)
  {
    DebugLogString("restarting");
    var msg = CreateMsg();
    msg.StringToMsg("SLAVE|COMP_NAME|EXECUTE|restart<1>,command<streamingserver.run>"); //change COMP_NAME to
    the name of the computer where the process runs
    DoReact(msg);
  }
}

if(Event.SourceType == "LOCAL_TIMER" && Event.SourceId == "TEST_RTSP")
{
  check_cam("rtsp://127.0.0.1:5544/1"); //the link is formed as described in the "Configuring the RTSP Server
Module" section
  check_cam("rtsp://127.0.0.1:5545/4");
}
```

The Convert.exe utility for correcting modification dates of video archives

The purpose of the Convert.exe utility


The Convert.exe utility is designed for restoring changed creation dates of video archive files. For example, file creation dates may be changed (corrupted) while transferring an archive from one computer to another. This may lead to incorrect playback of the archive.

Starting and shutting-down the Convert.exe utility

The Convert.exe utility can be operated in two modes:

1. Correction of records creation dates. To use this mode, start the utility from the Tools folder of the *Axxon PSIM* installation folder. Example: C:\Program Files (x86)\Axxon PSIM\Tools\Convert.exe.
2. Correction of records creation and modification dates. To use this mode, start the utility from the Tools folder of the *Axxon PSIM* installation folder with the -FULLMODE parameter.

The Convert.exe utility dialog box will open.



To shutdown the Convert.exe utility, click the **Close** button.

Restoring changed creation dates using the Convert.exe utility

The Convert.exe utility allows restoring the creation date of a video archive file. To make the restoration, start the utility (see the [Starting and shutting-down the Convert.exe utility](#) section). A console window will open starting the process of searching the Video folder on each of the available disks. Then, replacing of modification date for creation date will start automatically. This process will take some time depending on the archive size. For example, restoring dates in a 500 MB archive will take about 10 seconds. When all dates are replaced, the Convert.exe window will close by itself.

Working with the Convert.exe utility using the command prompt

One can work with the Convert.exe utility using Windows command prompt. The following startup parameters are in use:

1. TZ +hh:mm – changing date of file creation and modification for hh hours and mm minutes.
2. PATH – specifies the path to the archive folder with files date of creation (modification) of which is to be restored.
3. FULLMODE – running the utility in order to correct the date of creation and modification.
4. FORMAT is similar to FULLMODE. It also converts archive files to a format optimized for high-resolution archiving. The execution time of the FORMAT operation is comparable the the time required for a full conversion of the archive on the disk, because it requires reading every frame and creating a backup copy of the files while they are being converted. After the format of the archive or record has been updated, the execution time of subsequent conversions in FULLMODE will become the same as during an ordinary conversion.

Examples of commands for working with the Convert.exe utility using the command prompt:

1. Convert.exe PATH "H:\Video\03-09-12 15" FULLMODE
Running this command the Convert.exe utility will restore the date of file creation and modification in H:\Video\03-09-12 15 folder.
2. Convert.exe TZ +01:00
Running this command the time of file creation and modification will change for an hour. For instance, the "17-09-12 13" folder will be renamed as "17-09-12 14".



Note.

These examples assume using a command prompt in <Axxon PSIM>\ Tools folder.


The SignCheck.exe utility for checking the authenticity of exported frames

Starting and shutting-down the SignCheck.exe utility

To start the SignCheck.exe utility, do one of the following:


1. Start the utility from the Windows taskbar. Click **Start**, then **Programs**, then **Axxon PSIM**, then **Tools**, then **Check Digital Signature**.

The SignCheck.exe utility is available from the **Start** menu with the following installation types of the *Axxon PSIM* software: Server, Remote administrator workstation, Remote client.



2. Start the utility from the **Tools** folder of the *Axxon PSIM* program folder. Example: C:\Axxon PSIM\Tools\SignCheck.exe.

The SignCheck dialog box will open.




To close the SignCheck.exe utility, click the **Close** button.

The purpose of the SignCheck.exe utility


The SignCheck.exe utility is designed for checking the authenticity of a frame exported into BMP or JPEG format using the Converter.exe utility.

Using the SignCheck.exe utility

To verify the frame authenticity, do the following:

1. Start the utility (see [Starting and shutting-down the SignCheck.exe utility](#) section).
2. Select the file with exported frame to check, using the  button and a standard dialog box for opening files.

The SignCheck window will show the information about the selected frame.



The following information is displayed:

1. AxxonSoft export frame – digital signature title.
2. Frame time – date and time stamp of this frame in the recording.
3. Export time – date and time of exporting this frame to a file.
4. Camera – ID of the camera from which the recording was made.
5. System – the software that made the recording.
6. Computer – name of the computer this software is installed on.
7. User – user name of this computer.

If the frame cannot be authenticated, or the digital signature is missing, the "Verification failed" message will be displayed.

**The idb.exe utility for converting databases,
selecting database templates and making backup
copies of databases**

The purpose of the idb.exe utility

The idb.exe utility is designed for database administration in *Axxon PSIM* software. It provides the following functionality:


1. [Connecting to the Axxon PSIM database.](#)
2. [Setting up the database synchronization.](#)
3. [Creating backup copies of a database.](#)
4. [Restoring a database from its backup copy.](#)
5. [Changing the database template \(see \[Interface elements of the idb.exe window\]\(#\)\).](#)
6. [Separating the events log into an individual database.](#)

Running and shutting down the utility

Shut down *Axxon PSIM* before running the `idb.exe` utility.

The `idb.exe` utility is run from the *Axxon PSIM* installation directory. For example: «C:\Program Files \Axxon PSIM\idb.exe».


The `idb.exe` dialog box will open.



To confirm the changes and shut down the utility, click the **OK** button. To shut down the utility without saving the changes, click the **Close** button (✕).

Interface elements of the idb.exe window

The figure below shows the idb.exe dialog box.



The table describes the interface elements of the idb.exe utility dialog box.

Nº	Element name	Description	Default value	Allowed values
1	Select data source	The drop-down list for selecting the database: local Configuration database, Event protocol database, or a remote database for synchronization	Basic data	Basic data – local Configuration database Synchro source – remote database for synchronization Protocol – Event protocol database Titles – Captions database Other values are used when working with vertical solutions

2	Description	The information field that displays the description of the selected data source from the Select data source dropdown list	Axxon PSIM main database	<p>"Axxon PSIM" main database – local Configuration database</p> <p>Synchro source – remote database for synchronization</p> <p>"Axxon PSIM" system's external protocols database – Event protocol database</p> <p>Titles database – Captions database</p> <p>Other values depend on the availability of the databases for the installed vertical solutions.</p>
3	Use	The checkbox for enabling or disabling the selected database usage. When set, the Configure button becomes active, which is used for setting up the connection to the database	Checked	<p>Checked – database is connected</p> <p>Clear – database is not connected</p>
4	Move database	The button used to transfer MS SQL Server database files (.mdf and .ldf) to the specified folder. The user should have the rights to create files in this folder. When the files are moved, the database is automatically attached. <i>Note. It is possible to move only the local DB (Basic data data source). When using a remote DB (Synchro source data source), files can not be moved</i>	Active	<p>Active – the idb.exe utility is connected to the MS SQL format database</p> <p>Inactive – the idb.exe utility is not connected to the MS SQL format database</p>
5	Configure	The button opens the Data Link Properties dialog box to configure the database connection. This button is active if the Use checkbox is set	Active	<p>Active – the idb.exe utility is connected to the database</p> <p>Inactive – the idb.exe utility is not connected to the database</p>
6	The Connection string information field	The information field displaying the summary about the database connection parameters	Depends on the database connection parameters, the server configuration or Remote Administrator's workstation configuration	<p>Displays the combination of the following parameters:</p> <p>Provider, Integrated Security, Persist Security Info, Data Source.</p> <p>The Provider parameter can take the following values:</p> <ul style="list-style-type: none"> • SQLOLEDB.1 – when using the MS SQL server format database; • Microsoft.Jet.OLEDB.4.0 – when using the MS Access format server database <p>Other values are not used.</p> <p>The Integrated Security parameter can take the following values:</p> <ul style="list-style-type: none"> • SSPI – authentication on MS SQL server using Windows account information; • parameter not shown – authentication on MS SQL server using the user login /password, or using MS Access format database <p>The Persist Security Info parameter can take the following values:</p> <ul style="list-style-type: none"> • True – allow saving the password for automatic connection to the database; • False – do not allow saving the password for automatic connection to the database <p>The Data Source parameter can take the following values:</p> <ul style="list-style-type: none"> • the name of the MS SQL server used for managing the database; • the path to the .mdb file of the MS Access format database

7	Information field and the Select dbi-file button	The information field and the button for selecting and displaying the database structure .dbi file. The updated database will have the structure specified in this file	C:\Program Files\Axxon PSIM\psim.dbi	The full path to the .dbi file
8	Information field and the Select dbi-file button	The information field and the button for selecting and displaying the information about the .ddi file with system objects, events and reactions	C:\Program Files\Axxon PSIM\Languages\en\Axxon PSIM.ddi	The full path to the .dbi file
9	Create backup copy (MS SQL)	The button for starting the process of creating a backup copy of the database. This button is active if the idb.exe utility is connected to the MS SQL format database	Active	Active – the idb.exe utility is connected to the MS SQL format database Inactive – the idb.exe utility is not connected to the MS SQL format database
10	Restore from backup (MS SQL)	The button for restoring the database from a previously created backup	Active	Active – the idb.exe utility is connected to the MS SQL format database Inactive – the idb.exe utility is not connected to the MS SQL format database
11	Clear protocols	The checkbox that excludes the Event log database from the created database backup copy. It is recommended to set this checkbox if the size of the Event log database is too large, and there is no need to include the Event log in the backup copy. The setting is available only for <i>Axxon PSIM</i> base database	No	Checked – the database backup copy does not include the Event log database Clear – the database backup copy includes the Event log database
12	Update database	The button for starting the process of updating the database structure. The structure is updated according to the .dbi file specified in the Select dbi-file field	Active	Active – the idb.exe utility is connected to the Configuration database Inactive – the idb.exe utility is not connected to the Configuration database
13	Create dbi-file	The button for creating a database structure .dbi file (template)	Active	Active – .dbi file creation is allowed
14	The Protocol information table	The information table that displays the progress of database processing: converting, structure updating, creating backup copy, etc.	Empty	Information messages about the progress of the database processing. The blue "i" icon indicates that the processing step has been successfully completed The red "!" icon indicates the errors in the processing step A blue tick icon indicates the completion of the processing
15	OK	The button for saving the database connection parameters and shutting down the idb.exe utility	Active	Active – saving database connection parameters and shutting down the idb.exe utility is allowed Inactive – the utility is still processing the database

Using the idb.exe utility


The idb.exe utility allows the administration of the databases of the Axxon PSIM system. Instructions on how to use the utility for administering databases are given in [Axxon PSIM™ software database management](#) section.

Note.


The Windows Firewall/ICS service is to be enabled to use the idb.exe utility.

When you switch between databases using the **Select data source** drop-down list (see [Interface elements of the idb.exe window](#)), note that the specified parameters for connecting to the currently selected database are partially reset. This is due to the Microsoft security policy. In order for the settings in the **Connection string** field to be saved, do the following **before** you switch to the administration of another database:

1. Make sure that the database which connection settings should be saved is selected in the **Select data source** list (1).




2. Click the **Configure** button (2).
3. In the window that opens, go to the **All** tab (3).



4. Left double-click on the **Persist Security Info** parameter (4).

5. Set the parameter value to **True** (5).




6. Click **OK** (6).
7. Click **OK** on the **Data Link Properties** window to update the settings and close the window.
8. Click **OK** in the IDB utility window to save the settings.


As a result, the next time you switch to the selected database, the settings for connecting to it will not be reset.

Working with idb.exe utility with the use of keys

It is possible to run idb.exe utility with keys. For this click **Start Run**. Type the path to idb.exe utility and the required key after / in the appeared window.



To display keys, supported by the utility, use the command «idb.exe /?».



idb.exe utility supports the run with the following keys:

1. «/update» – the key of running the hidden updating of database (uses psim.dbi file).
2. «/sync» – the key of database synchronization with the source of data.
3. «/backup» – the key of running the process of creation the backup copy of Axxon PSIM database. Use the -protocol option to exclude the Event protocol database from the backup (i.e., the full command in this case would be: **/backup -protocol**). The backup copy is created to the address «C:\Users\user\Documents\Axxon PSIM». It is used when the idb.exe utility is connected to MS SQL database.
4. «/restore» – the key of running the database recover from the previously created backup copy. It is used when the idb.exe utility is connected to MS SQL database.
5. «/set_cs key=value» – the key of saving the connection string to the system registry (summary on parameters of connection to database).

Extracting event protocol into an individual database

External event protocol is created with the help of the idb.exe utility.

Attention!


If *Time and Attendance* module is in use (the module is a part of *ACFA PSIM* subsystem) use the RemoteProtocolConnector utility to extract event protocol into a separate database – see *Axxon PSIM Web Report System. User Guide* (the most recent version of this document is available in [AxxonSoft documentation repository](#)).

Note

To operate the Report System, which is a part of base *Axxon PSIM*, the method of extracting the event protocol into a separate database is used. The method is described in this section, i.e. using the idb.exe utility. Configuration of the connection to such protocol DB is required in the Report System, which is a part of base *Axxon PSIM* (see [Connecting to the Events Log \(PROTOCOL table\)](#)).


It is necessary to create the **protocol** database beforehand with the help of the MS SQL Server program. Do the following:

1. Open Microsoft SQL Server Management Studio Express;
2. Select **Databases**.



3. Right-click and select **New Database...**

- Specify the protocol database name in the **Database name** line in the **New Database** dialog box.




- To create a new protocol database, click the **OK** button.
- Shut down Microsoft SQL Server Management Studio Express by clicking the **Close** button in the upper right corner of the dialog box.


As a result, the **protocol** database is created.

To enable the external event protocol, do the following:

- Run the `idb.exe` utility (see [Running and shutting down the utility](#)).
- Select the **Protocol** database from the **Select source database** drop-down list.




3. To enable the **Protocol** database, set the **Use** checkbox (1).



4. As a result, the **Configure** button becomes active (2). To connect to the **Protocol** database, click the **Configure** button.

5. As a result, the **Data link properties** dialog box appears. Go to the **Provider** tab.

6. Select the **Microsoft OLE DB Provider for SQL Server** from the **OLE DB Provider(s)** list (1).



7. Click the **Next** button (2).

8. You will be automatically redirected to the **Connection** tab.

9. Do the following in the **Connection** tab:

- a. Select a server name from the **Select or enter a server name** drop-down list (1).

1 WS1\SQLEXPRESS2014 Refresh

2 User name: sa
Password:

Blank password Allow saving password **3**

4 Select the database on the server:
protocol


Attach a database file as a database name:
protocol
Using the filename: ...

5 Test Connection

6 OK Cancel Help

- b. Specify the user name in the **User name** field and specify the password in the **Password** field (2).
- c. Set the **Allow saving password** checkbox (3).

d. Go to the **All** tab.



e. In the **Persist Security Info** field, set the **True** value. This is necessary to correctly save the user password.


Note

Each time you change the server connection parameters, you must set the **Persist Security Info** field value to **True**.

f. Select the **protocol** database in the **Select the database on the server** drop-down list (4).

g. Click the **Test connection** button (5).

h. If the connection to MS SQL Server is successfully established, then the **Test connection succeeded** message appears.




i. Click the **OK** button in the message box. The box closes automatically.


10. Select the dbi file. Click the button next to the **Select dbi-file information** field.

11. As a result, the **Open** dialog box appears.

12. Select the database structure file – C:\Program Files\Axxon PSIM\protocol.dbi.



13. Click the **Update database** button to update the database in accordance with the psim.dbi file specified in the **Select dbi-file** field.



14. As a result, database updating will start. Information about this process is displayed in the **Protocol** table.

15. Database is updated, when there is the **Database Updating is completed!** message in the **Protocol** table.

16. To save *Axxon PSIM* connection parameters to the **Protocol** database, click the **OK** button. As a result the dialog box closes automatically.

External event protocol is created and connected.

Creating the database backup copy


To create the MS SQL database backup copy, use the `idb.exe` utility. To create the backup copy, do the following:

1. Run the `idb.exe` utility (see [Running and shutting down the utility](#)).
2. Select the **Basic data** MS SQL database from the **Select data source** dropdown list.

Note

Select the vertical solution database to create a backup copy of the vertical solution database. For example, for *Face PSIM* the data source is **Face**.

3. If it is not required to include the Event protocol in the backup copy of the database, set the **Clear protocols** checkbox. This checkbox is not available if the vertical solution database is selected.
4. Click the **Create backup copy (MS SQL)** button.
5. As a result, the **Save as** dialog box appears. Select the address and type in the name of saving backup copy.




Note

While creating the MS SQL database backup copy, the created backup copy will be saved on the computer where the database server is installed, in case of *Axxon PSIM* software and database server are located on different computers connected through the network. To save created backup copy on the computer where *Axxon PSIM* is installed, do the following:

- a. Create the folder available through the network on the computer where *Axxon PSIM* is installed. Provide access to the created folder from the computer where the database server is installed.
- b. Specify the path to the created folder in the **Save as** window.

6. As a result, the process of backup copy creation starts. Information on this process is given in the **Protocol** information table.



7. The backup copy is created when the **Creation of a backup copy is completed!** message appears in the **Protocol** table.

Note


The backup copy (MS SQL) can be created using the macro.

8. Click the **OK** button. The dialog box closes automatically.

The MS SQL database backup copy is created.

By default the database backup copy is created at: C:\Documents and Settings\\My documents\AxxonSoft\Axxon PSIM\Data\psim.sql.bak. In case you cannot change the folder for storing the database backup copy while the backup copy creation, do the following:

1. Call the **Run** function (**Start Run**). Type in regedit in the opened dialog box.
2. Click the **OK** button. As a result, the **Registry editor** dialog box opens.
3. Create the string parameter with the BackupFolder name in the HKLM\SOFTWARE\AxxonSoft\PSIM registry thread (see [Adding string parameters to the registry](#)).
4. Set the value of the BackupFolder parameter: type in the address of the folder for storing the database backup copy (e.g. C:\Documents and Settings\AVP\Desktop\Backup).
If it is necessary to store the database copy on the network disk, then the UNC path to the network folder (with the recording access) should be specified on the disk in the \\ServerName\ShareName format. Take into account that all network resources that require additional authentication should be connected using the same username as for running the SQL Server service. To find out and/or change the user that runs the SQL Server service, do one of the following:
 - a. Using the SQL Server Configuration Manager utility.
 - b. Run **Start – Control panel – Administrative tools – Services**, right-click the **SQL Server** service and select **Properties** in the feature menu. In the opened **SQL Server** service dialog box, go to the **Log On** tab.
5. As a result, the string parameter of the key with the specified value is created.



6. Call the **Run** function (**Start Run**). Type in the «C:\Program Files\Axxon PSIM\idb.exe /backup» key in the opened dialog box.
7. Click the **OK** button.

As a result, the psim.sql.bak database backup copy is created in the folder specified as the value of the BackupFolder parameter.

Restoring database from backup copy


The database backup copy is created using the idb.exe utility (see [Creating the database backup copy](#)). Database restoring from backup copy is also performed using the idb.exe utility in the following way:

1. Run the idb.exe utility (see [Running and shutting down the utility](#)).
2. From the **Select data source**: drop-down list select the MS SQL database – **Basic data**.

Note

Select the vertical solution database to create a backup copy of the vertical solution database. For example, for Face *PSIM* the data source is **Face**.

3. Click the **Restore from backup (MS SQL)** button (1).



4. Using the standard dialog box for opening files, select the created earlier file with database backup copy.
5. As a result, the process of database restoring from backup copy will start. Information about process is displayed in the **Protocol** informational table (2).
6. Restoring is completed when the **Restoration from a backup copy is completed!** message will be displayed in the **Protocol** table.
7. To finish the work click the **OK** button. The window will close automatically (3).

Database restoring from backup copy is completed.