



# Bosch APE Integration Module Settings Guide

ACFA PSIM 1.0

Last update 08/26/2022

## Table of Contents

<b>1</b>	<b>Introduction into Bosch APE Module Settings Guide</b> .....	<b>3</b>
1.1	Purpose of the document.....	3
1.2	General information about the Bosch APE integration module.....	3
<b>2</b>	<b>Supported hardware and licensing of the Bosch APE integration module</b> .....	<b>4</b>
<b>3</b>	<b>Configuration of the Bosch APE integration module</b> .....	<b>5</b>
3.1	Configuring the Bosch APE ACS connection to ACFA PSIM.....	5
<b>4</b>	<b>Working with the Bosch APE integration module</b> .....	<b>6</b>
4.1	General information about working with the Bosch APE module.....	6
4.2	Managing the Bosch APE software.....	6
4.3	Managing the Bosch APE entrance.....	7

# 1 Introduction into Bosch APE Module Settings Guide

## On this page:

- [Purpose of the document](#)
- [General information about the Bosch APE integration module](#)

## 1.1 Purpose of the document

This *Bosch APE Module Settings Guide* is a reference manual designed for *Bosch APE* Module configuration technicians.

This Guide presents the following materials:

1. general information about the *Bosch APE* integration module;
2. configuration of the *Bosch APE* integration module;
3. working with the *Bosch APE* integration module.

## 1.2 General information about the Bosch APE integration module

The *Bosch APE* module is a component of an ACS built on the *ACFA PSIM*. It is designed to control and monitor entrances of the *Bosch APE* ACS. Configuring the *Bosch APE* ACS hardware in *ACFA PSIM* is not possible.

Before configuring the *Bosch APE* ACS integration module, it is necessary to install the hardware onsite and perform the initial setup of the *Bosch APE* ACS devices.

### Note

Detailed information about the *Bosch APE* ACS is presented in the official documentation for this system (manufactured by Bosch Sicherheitssysteme GmbH).

## 2 Supported hardware and licensing of the Bosch APE integration module

<b>Manufacturer</b>	Bosch Sicherheitssysteme GmbH Bosch Service Center Postfach 30 02 20 70442 Stuttgart GERMANY Phone: +49 711 400 40990 Web site: <a href="https://www.boschsecurity.com/">https://www.boschsecurity.com/</a>
<b>Integration type</b>	SOFT-SOFT

### Supported equipment

Equipment	Function	Features
Entrances connected to Bosch Access Professional Edition (APE) software	Access control system	For details on the features of the <i>Bosch APE</i> system, see the official reference documentation for the system.

### Licensing


Per 1 head object.

### 3 Configuration of the Bosch APE integration module

#### 3.1 Configuring the Bosch APE ACS connection to ACFA PSIM

The *Bosch APE* ACS connection to *ACFA PSIM* is configured as follows:

1. Create the **Bosch APE** object on the basis of the **Computer** object on the **Hardware** tab of the **System Settings** dialog box.



2. In the **Login** (1) and **Password** fields (2), specify a username and password to connect to the *Bosch APE* software.
3. Click the **Hardware synchronization** button (3) to read the configuration from the *Bosch APE* software and build the hardware tree. As a result, the child objects of **Bosch APE Entrance** will be created, on the panel of which the identifier of the corresponding door will be indicated.



4. Click the **Apply** button (4) to save settings.

## 4 Working with the Bosch APE integration module

### 4.1 General information about working with the Bosch APE module

The following interface objects are used for *Bosch APE* integration module operation:

1. **Map.**
2. **Event viewer.**



For detailed description of configuring these interface objects, please refer to the *Axxon PSIM* software package. [Administrator's Guide](#).


For detailed description of using these interface objects, please refer to the *Axxon PSIM* software package. [Operator's Guide](#).

### 4.2 Managing the Bosch APE software

The *Bosch APE* software is not managed in the **Map** interactive window.

The *Bosch APE* software can have the following states:

	Connected
	Disconnected








### 4.3 Managing the Bosch APE entrance






The *Bosch APE* entrance is managed in the **Map** interactive window using the **Bosch APE Entrance** object functional menu:

<b>Bosch APE Entrance 1.1 [1.1]</b>
Show last events
Close
Unlock
Open
Open once
Lock

The *Bosch APE* entrance object functional menu commands description is given in the table.

The *Bosch APE* entrance can have the following states:

	Break
	Defect
	Link lost
	Lock permanent
	Not exist

	Normal
	Open
	Open permanent
	Open to long
	Unknown state